

| |
|----|
| 1 |
| 2 |
| 3 |
| 4 |
| 5 |
| 6 |
| 7 |
| 8 |
| 9 |
| 10 |
| 11 |
| 12 |
| 13 |
| 14 |
| 15 |
| 16 |
| 17 |

ANALYTICAL REPORT

PREPARED FOR

Attn: Mr. Erwin Kawata
City & County of Honolulu
630 South Beretania Street
Public Service Bldg. Room 310
Honolulu, Hawaii 96843

Generated 10/6/2025 3:27:54 PM

JOB DESCRIPTION

RED-HILL
PFAS: Ka'amilo Wells P1/P2

JOB NUMBER

380-174244-1

Eurofins Eaton Analytical Pomona

Job Notes

This report may not be reproduced except in full, and with written approval from the laboratory. The results relate only to the samples tested. For questions please contact the Project Manager at the e-mail address or telephone number listed on this page.

The test results in this report relate only to the samples as received by the laboratory and meet all requirements of the methodology, with any exceptions noted. This report shall not be reproduced except in full, without the express written approval of the laboratory. All questions should be directed to the Eurofins Eaton Analytical, LLC Project Manager.

Compliance Statement

1. Laboratory is accredited in accordance with TNI 2016 Standards and ISO/IEC 17025:2017.
2. Laboratory certifies that the test results meet all TNI 2016 and ISO/IEC 17025:2017 requirements unless noted under the individual analysis
3. Test results relate only to the sample(s) tested.
4. This report shall not be reproduced except in full, without the written approval of the laboratory.
5. Unless otherwise noted, all analytes for this laboratory were covered under each accreditation/certification below. (DW, Water matrices)

Authorization



Authorized for release by
Maria Lopez, Project Manager
Maria.Lopez@et.eurofinsus.com
(626)386-1100

Generated
10/6/2025 3:27:54 PM



Table of Contents

| | |
|------------------------------------|----|
| Cover Page | 1 |
| Table of Contents | 3 |
| Definitions/Glossary | 4 |
| Case Narrative | 5 |
| Detection Summary | 6 |
| Client Sample Results | 7 |
| Action Limit Summary | 15 |
| Surrogate Summary | 17 |
| Isotope Dilution Summary | 18 |
| QC Sample Results | 19 |
| QC Association Summary | 30 |
| Lab Chronicle | 31 |
| Certification Summary | 32 |
| Method Summary | 33 |
| Sample Summary | 34 |
| Chain of Custody | 35 |
| Receipt Checklists | 36 |

Definitions/Glossary

Client: City & County of Honolulu
Project/Site: RED-HILL

Job ID: 380-174244-1
SDG: PFAS: Ka'amilo Wells P1/P2

Qualifiers

LCMS

| Qualifier | Qualifier Description |
|-----------|--|
| J | Result is less than the RL but greater than or equal to the MDL and the concentration is an approximate value. |

Glossary

| Abbreviation | These commonly used abbreviations may or may not be present in this report. |
|----------------|---|
| ☼ | Listed under the "D" column to designate that the result is reported on a dry weight basis |
| %R | Percent Recovery |
| CFL | Contains Free Liquid |
| CFU | Colony Forming Unit |
| CNF | Contains No Free Liquid |
| DER | Duplicate Error Ratio (normalized absolute difference) |
| Dil Fac | Dilution Factor |
| DL | Detection Limit (DoD/DOE) |
| DL, RA, RE, IN | Indicates a Dilution, Re-analysis, Re-extraction, or additional Initial metals/anion analysis of the sample |
| DLC | Decision Level Concentration (Radiochemistry) |
| EDL | Estimated Detection Limit (Dioxin) |
| LOD | Limit of Detection (DoD/DOE) |
| LOQ | Limit of Quantitation (DoD/DOE) |
| MCL | EPA recommended "Maximum Contaminant Level" |
| MDA | Minimum Detectable Activity (Radiochemistry) |
| MDC | Minimum Detectable Concentration (Radiochemistry) |
| MDL | Method Detection Limit |
| ML | Minimum Level (Dioxin) |
| MPN | Most Probable Number |
| MQL | Method Quantitation Limit |
| NC | Not Calculated |
| ND | Not Detected at the reporting limit (or MDL or EDL if shown) |
| NEG | Negative / Absent |
| POS | Positive / Present |
| PQL | Practical Quantitation Limit |
| PRES | Presumptive |
| QC | Quality Control |
| RER | Relative Error Ratio (Radiochemistry) |
| RL | Reporting Limit or Requested Limit (Radiochemistry) |
| RPD | Relative Percent Difference, a measure of the relative difference between two points |
| TEF | Toxicity Equivalent Factor (Dioxin) |
| TEQ | Toxicity Equivalent Quotient (Dioxin) |
| TNTC | Too Numerous To Count |

Case Narrative

Client: City & County of Honolulu
Project: RED-HILL

Job ID: 380-174244-1

Job ID: 380-174244-1

Eurofins Eaton Analytical Pomona

Job Narrative 380-174244-1

The analytical test results presented in this report meet all requirements of the associated regulatory program listed on the Accreditation/Certification Summary Page, unless otherwise noted. Data qualifiers and/or narrative comments are included to explain any exceptions, if applicable. Regulated compliance samples (e.g. SDWA, NPDES) must comply with associated agency requirements/permits.

- Matrix-specific batch QC (e.g., MS, MSD, SD) may not be reported when insufficient sample volume is available or when site-specific QC samples are not submitted. In such cases, a Laboratory Control Sample Duplicate (LCSD) may be analyzed to provide precision data for the batch.
- For samples analyzed using surrogate and/or isotope dilution analytes, any recoveries falling outside of established acceptance criteria are re-prepared and/or re-analyzed to confirm results, unless the deviation is due to sample dilution or otherwise explained in the case narrative.

Receipt

The samples were received on 10/1/2025 10:00 AM. Unless otherwise noted below, the samples arrived in good condition, and, where required, properly preserved and on ice. The temperatures of the 3 coolers at receipt time were 0.6°C, 1.7°C and 2.4°C.

PFAS

No additional analytical or quality issues were noted, other than those described above or in the Definitions/ Glossary page.

Detection Summary

Client: City & County of Honolulu
Project/Site: RED-HILL

Job ID: 380-174244-1
SDG: PFAS: Ka'amilo Wells P1/P2

Client Sample ID: Ka'amilo Wells P1

Lab Sample ID: 380-174244-1

| Analyte | Result | Qualifier | RL | Unit | Dil Fac | D | Method | Prep Type |
|--------------------------------------|--------|-----------|-----|------|---------|---|--------|-----------|
| Perfluorobutanesulfonic acid (PFBS) | 3.2 | | 2.0 | ng/L | 1 | | 533 | Total/NA |
| Perfluorohexanesulfonic acid (PFHxS) | 3.3 | | 2.0 | ng/L | 1 | | 533 | Total/NA |
| Perfluorohexanoic acid (PFHxA) | 3.6 | | 2.0 | ng/L | 1 | | 533 | Total/NA |
| Perfluorooctanesulfonic acid (PFOS) | 4.4 | | 2.0 | ng/L | 1 | | 533 | Total/NA |
| Perfluorooctanoic acid (PFOA) | 3.8 | | 2.0 | ng/L | 1 | | 533 | Total/NA |
| Perfluoropentanoic acid (PFPeA) | 3.8 | | 2.0 | ng/L | 1 | | 533 | Total/NA |
| Perfluorooctanesulfonic acid (PFOS) | 4.5 | | 2.0 | ng/L | 1 | | 537.1 | Total/NA |
| Perfluorohexanoic acid (PFHxA) | 3.6 | | 2.0 | ng/L | 1 | | 537.1 | Total/NA |
| Perfluorooctanoic acid (PFOA) | 3.8 | | 2.0 | ng/L | 1 | | 537.1 | Total/NA |
| Perfluorohexanesulfonic acid (PFHxS) | 3.5 | | 2.0 | ng/L | 1 | | 537.1 | Total/NA |
| Perfluorobutanesulfonic acid (PFBS) | 3.0 | | 2.0 | ng/L | 1 | | 537.1 | Total/NA |

Client Sample ID: Ka'amilo Wells P2

Lab Sample ID: 380-174244-2

| Analyte | Result | Qualifier | RL | Unit | Dil Fac | D | Method | Prep Type |
|--------------------------------------|--------|-----------|-----|------|---------|---|--------|-----------|
| Perfluorobutanesulfonic acid (PFBS) | 3.0 | | 2.0 | ng/L | 1 | | 533 | Total/NA |
| Perfluorohexanesulfonic acid (PFHxS) | 3.2 | | 2.0 | ng/L | 1 | | 533 | Total/NA |
| Perfluorohexanoic acid (PFHxA) | 3.3 | | 2.0 | ng/L | 1 | | 533 | Total/NA |
| Perfluorooctanesulfonic acid (PFOS) | 4.1 | | 2.0 | ng/L | 1 | | 533 | Total/NA |
| Perfluorooctanoic acid (PFOA) | 3.5 | | 2.0 | ng/L | 1 | | 533 | Total/NA |
| Perfluoropentanoic acid (PFPeA) | 3.4 | | 2.0 | ng/L | 1 | | 533 | Total/NA |
| Perfluorooctanesulfonic acid (PFOS) | 3.6 | | 2.0 | ng/L | 1 | | 537.1 | Total/NA |
| Perfluorohexanoic acid (PFHxA) | 3.1 | | 2.0 | ng/L | 1 | | 537.1 | Total/NA |
| Perfluorooctanoic acid (PFOA) | 3.4 | | 2.0 | ng/L | 1 | | 537.1 | Total/NA |
| Perfluorohexanesulfonic acid (PFHxS) | 3.1 | | 2.0 | ng/L | 1 | | 537.1 | Total/NA |
| Perfluorobutanesulfonic acid (PFBS) | 2.8 | | 2.0 | ng/L | 1 | | 537.1 | Total/NA |

Client Sample ID: FB: Ka'amilo Wells P1

Lab Sample ID: 380-174244-3

No Detections.

Client Sample ID: FB: Ka'amilo Wells P2

Lab Sample ID: 380-174244-4

No Detections.

This Detection Summary does not include radiochemical test results.

Eurofins Eaton Analytical Pomona

Client Sample Results

Client: City & County of Honolulu
Project/Site: RED-HILL

Job ID: 380-174244-1
SDG: PFAS: Ka'amilo Wells P1/P2

Client Sample ID: Ka'amilo Wells P1

Lab Sample ID: 380-174244-1

Date Collected: 09/29/25 11:47

Matrix: Water

Date Received: 10/01/25 10:00

Method: EPA 533 - Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water

| Analyte | Result | Qualifier | RL | Unit | D | Prepared | Analyzed | Dil Fac |
|--|------------------|------------------|---------------|------|---|-----------------|-----------------|----------------|
| 11-Chloroeicosafluoro-3-oxaundecane-1-sulfonic acid (11Cl-PF3OUdS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| 9-Chlorohexadecafluoro-3-oxanonane-1-sulfonic acid(9Cl-PF3ONS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| 4,8-Dioxa-3H-perfluorononanoic acid (ADONA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| Perfluorobutanesulfonic acid (PFBS) | 3.2 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| Perfluorodecanoic acid (PFDA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| Perfluorododecanoic acid (PFDoA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| Perfluoroheptanoic acid (PFHpA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| Perfluorohexanesulfonic acid (PFHxS) | 3.3 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| Perfluorohexanoic acid (PFHxA) | 3.6 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| Perfluorononanoic acid (PFNA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| Perfluorooctanesulfonic acid (PFOS) | 4.4 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| Perfluorooctanoic acid (PFOA) | 3.8 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| Perfluoroundecanoic acid (PFUnA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| Perfluorobutanoic acid (PFBA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| 1H,1H,2H,2H-Perfluorodecane sulfonic acid (8:2 FTS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| 1H,1H,2H,2H-Perfluorohexane sulfonic acid (4:2 FTS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| 1H,1H,2H,2H-Perfluorooctane sulfonic acid (6:2 FTS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| Nonafluoro-3,6-dioxaheptanoic acid (NFDHA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| Perfluoro (2-ethoxyethane) sulfonic acid (PFEEESA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| Perfluoro-3-methoxypropanoic acid (PFMPA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| Perfluoro-4-methoxybutanoic acid (PFMBA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| Perfluoropentanoic acid (PFPeA) | 3.8 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| Perfluoroheptanesulfonic acid (PFHpS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| Perfluoropentanesulfonic acid (PFPeS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| Isotope Dilution | %Recovery | Qualifier | Limits | | | Prepared | Analyzed | Dil Fac |
| 13C3 HFPO-DA | 87 | | 50 - 200 | | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| 13C6 PFDA | 102 | | 50 - 200 | | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| 13C5 PFHxA | 97 | | 50 - 200 | | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| 13C4 PFHpA | 103 | | 50 - 200 | | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| 13C8 PFOA | 107 | | 50 - 200 | | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| 13C9 PFNA | 103 | | 50 - 200 | | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| 13C7 PFUnA | 104 | | 50 - 200 | | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| 13C2 PFDoA | 103 | | 50 - 200 | | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| 13C4 PFBA | 104 | | 50 - 200 | | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| 13C5 PFPeA | 106 | | 50 - 200 | | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| 13C3 PFBS | 105 | | 50 - 200 | | | 10/02/25 03:37 | 10/02/25 17:22 | 1 |

Eurofins Eaton Analytical Pomona

Client Sample Results

Client: City & County of Honolulu
Project/Site: RED-HILL

Job ID: 380-174244-1
SDG: PFAS: Ka'amilo Wells P1/P2

Client Sample ID: Ka'amilo Wells P1

Lab Sample ID: 380-174244-1

Date Collected: 09/29/25 11:47

Matrix: Water

Date Received: 10/01/25 10:00

Method: EPA 533 - Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water (Continued)

| Isotope Dilution | %Recovery | Qualifier | Limits | Prepared | Analyzed | Dil Fac |
|------------------|-----------|-----------|----------|----------------|----------------|---------|
| 13C3 PFHxS | 109 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| 13C8 PFOS | 106 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| 13C2-4:2-FTS | 104 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| 13C2-6:2-FTS | 110 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 17:22 | 1 |
| 13C2-8:2-FTS | 107 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 17:22 | 1 |

Method: EPA 537.1 - Perfluorinated Alkyl Acids (LC/MS)

| Analyte | Result | Qualifier | RL | Unit | D | Prepared | Analyzed | Dil Fac |
|---|------------|-----------|-----|------|---|----------------|----------------|---------|
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:06 | 1 |
| Perfluorooctanesulfonic acid (PFOS) | 4.5 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:06 | 1 |
| Perfluoroundecanoic acid (PFUnA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:06 | 1 |
| N-methylperfluorooctanesulfonamide cetic acid (NMeFOSAA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:06 | 1 |
| N-ethylperfluorooctanesulfonamide acetic acid (NEtFOSAA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:06 | 1 |
| Perfluorohexanoic acid (PFHxA) | 3.6 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:06 | 1 |
| Perfluorododecanoic acid (PFDoA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:06 | 1 |
| Perfluorooctanoic acid (PFOA) | 3.8 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:06 | 1 |
| Perfluorodecanoic acid (PFDA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:06 | 1 |
| Perfluorohexanesulfonic acid (PFHxS) | 3.5 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:06 | 1 |
| Perfluorobutanesulfonic acid (PFBS) | 3.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:06 | 1 |
| Perfluoroheptanoic acid (PFHpA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:06 | 1 |
| Perfluorononanoic acid (PFNA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:06 | 1 |
| Perfluorotetradecanoic acid (PFTA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:06 | 1 |
| Perfluorotridecanoic acid (PFTDA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:06 | 1 |
| 9-Chlorohexadecafluoro-3-oxanonan e-1-sulfonic acid(9Cl-PF3ONS) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:06 | 1 |
| 11-Chloroeicosafluoro-3-oxaundecan e-1-sulfonic acid (11Cl-PF3OUdS) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:06 | 1 |
| 4,8-Dioxa-3H-perfluorononanoic acid (ADONA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:06 | 1 |

| Surrogate | %Recovery | Qualifier | Limits | Prepared | Analyzed | Dil Fac |
|-------------|-----------|-----------|----------|----------------|----------------|---------|
| d5-NEtFOSAA | 101 | | 70 - 130 | 10/02/25 16:08 | 10/03/25 16:06 | 1 |
| 13C2 PFHxA | 103 | | 70 - 130 | 10/02/25 16:08 | 10/03/25 16:06 | 1 |
| 13C2 PFDA | 110 | | 70 - 130 | 10/02/25 16:08 | 10/03/25 16:06 | 1 |
| 13C3-GenX | 110 | | 70 - 130 | 10/02/25 16:08 | 10/03/25 16:06 | 1 |

Client Sample ID: Ka'amilo Wells P2

Lab Sample ID: 380-174244-2

Date Collected: 09/29/25 12:32

Matrix: Water

Date Received: 10/01/25 10:00

Method: EPA 533 - Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water

| Analyte | Result | Qualifier | RL | Unit | D | Prepared | Analyzed | Dil Fac |
|---|--------|-----------|-----|------|---|----------------|----------------|---------|
| 11-Chloroeicosafluoro-3-oxaundecan e-1-sulfonic acid (11Cl-PF3OUdS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| 9-Chlorohexadecafluoro-3-oxanonan e-1-sulfonic acid(9Cl-PF3ONS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:13 | 1 |

Eurofins Eaton Analytical Pomona

Client Sample Results

Client: City & County of Honolulu
Project/Site: RED-HILL

Job ID: 380-174244-1
SDG: PFAS: Ka'amilo Wells P1/P2

Client Sample ID: Ka'amilo Wells P2

Lab Sample ID: 380-174244-2

Date Collected: 09/29/25 12:32

Matrix: Water

Date Received: 10/01/25 10:00

Method: EPA 533 - Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water (Continued)

| Analyte | Result | Qualifier | RL | Unit | D | Prepared | Analyzed | Dil Fac |
|---|------------|-----------|-----|------|---|----------------|----------------|---------|
| 4,8-Dioxa-3H-perfluorononanoic acid (ADONA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| Perfluorobutanesulfonic acid (PFBS) | 3.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| Perfluorodecanoic acid (PFDA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| Perfluorododecanoic acid (PFDoA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| Perfluoroheptanoic acid (PFHpA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| Perfluorohexanesulfonic acid (PFHxS) | 3.2 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| Perfluorohexanoic acid (PFHxA) | 3.3 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| Perfluorononanoic acid (PFNA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| Perfluorooctanesulfonic acid (PFOS) | 4.1 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| Perfluorooctanoic acid (PFOA) | 3.5 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| Perfluoroundecanoic acid (PFUnA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| Perfluorobutanoic acid (PFBA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| 1H,1H,2H,2H-Perfluorodecane sulfonic acid (8:2 FTS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| 1H,1H,2H,2H-Perfluorohexane sulfonic acid (4:2 FTS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| 1H,1H,2H,2H-Perfluorooctane sulfonic acid (6:2 FTS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| Nonafluoro-3,6-dioxaheptanoic acid (NFDHA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| Perfluoro (2-ethoxyethane) sulfonic acid (PFEESA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| Perfluoro-3-methoxypropanoic acid (PFMPA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| Perfluoro-4-methoxybutanoic acid (PFMBA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| Perfluoropentanoic acid (PFPeA) | 3.4 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| Perfluoroheptanesulfonic acid (PFHpS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| Perfluoropentanesulfonic acid (PFPeS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:13 | 1 |

| Isotope Dilution | %Recovery | Qualifier | Limits | Prepared | Analyzed | Dil Fac |
|------------------|-----------|-----------|----------|----------------|----------------|---------|
| 13C3 HFPO-DA | 93 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| 13C6 PFDA | 104 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| 13C5 PFHxA | 98 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| 13C4 PFHpA | 100 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| 13C8 PFOA | 106 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| 13C9 PFNA | 100 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| 13C7 PFUnA | 107 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| 13C2 PFDoA | 103 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| 13C4 PFBA | 109 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| 13C5 PFPeA | 109 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| 13C3 PFBS | 102 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| 13C3 PFHxS | 108 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| 13C8 PFOS | 103 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| 13C2-4:2-FTS | 111 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:13 | 1 |
| 13C2-6:2-FTS | 114 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:13 | 1 |

Eurofins Eaton Analytical Pomona

Client Sample Results

Client: City & County of Honolulu
Project/Site: RED-HILL

Job ID: 380-174244-1
SDG: PFAS: Ka'amilo Wells P1/P2

Client Sample ID: Ka'amilo Wells P2

Lab Sample ID: 380-174244-2

Date Collected: 09/29/25 12:32

Matrix: Water

Date Received: 10/01/25 10:00

Method: EPA 533 - Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water (Continued)

| Isotope Dilution | %Recovery | Qualifier | Limits | Prepared | Analyzed | Dil Fac |
|------------------|-----------|-----------|----------|----------------|----------------|---------|
| 13C2-8:2-FTS | 115 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:13 | 1 |

Method: EPA 537.1 - Perfluorinated Alkyl Acids (LC/MS)

| Analyte | Result | Qualifier | RL | Unit | D | Prepared | Analyzed | Dil Fac |
|--|------------|-----------|----------|----------------|----------------|----------------|----------------|---------|
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:17 | 1 |
| Perfluorooctanesulfonic acid (PFOS) | 3.6 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:17 | 1 |
| Perfluoroundecanoic acid (PFUnA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:17 | 1 |
| N-methylperfluorooctanesulfonamide acetic acid (NMeFOSAA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:17 | 1 |
| N-ethylperfluorooctanesulfonamide acetic acid (NEtFOSAA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:17 | 1 |
| Perfluorohexanoic acid (PFHxA) | 3.1 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:17 | 1 |
| Perfluorododecanoic acid (PFDoA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:17 | 1 |
| Perfluorooctanoic acid (PFOA) | 3.4 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:17 | 1 |
| Perfluorodecanoic acid (PFDA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:17 | 1 |
| Perfluorohexanesulfonic acid (PFHxS) | 3.1 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:17 | 1 |
| Perfluorobutanesulfonic acid (PFBS) | 2.8 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:17 | 1 |
| Perfluoroheptanoic acid (PFHpA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:17 | 1 |
| Perfluorononanoic acid (PFNA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:17 | 1 |
| Perfluorotetradecanoic acid (PFTA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:17 | 1 |
| Perfluorotridecanoic acid (PFTrDA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:17 | 1 |
| 9-Chlorohexadecafluoro-3-oxanonane-1-sulfonic acid (9Cl-PF3ONS) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:17 | 1 |
| 11-Chloroeicosafluoro-3-oxaundecane-1-sulfonic acid (11Cl-PF3OUdS) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:17 | 1 |
| 4,8-Dioxa-3H-perfluorononanoic acid (ADONA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:17 | 1 |
| Surrogate | %Recovery | Qualifier | Limits | Prepared | Analyzed | Dil Fac | | |
| d5-NEtFOSAA | 96 | | 70 - 130 | 10/02/25 16:08 | 10/03/25 16:17 | 1 | | |
| 13C2 PFHxA | 102 | | 70 - 130 | 10/02/25 16:08 | 10/03/25 16:17 | 1 | | |
| 13C2 PFDA | 107 | | 70 - 130 | 10/02/25 16:08 | 10/03/25 16:17 | 1 | | |
| 13C3-GenX | 108 | | 70 - 130 | 10/02/25 16:08 | 10/03/25 16:17 | 1 | | |

Client Sample ID: FB: Ka'amilo Wells P1

Lab Sample ID: 380-174244-3

Date Collected: 09/29/25 11:47

Matrix: Water

Date Received: 10/01/25 10:00

Method: EPA 533 - Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water

| Analyte | Result | Qualifier | RL | Unit | D | Prepared | Analyzed | Dil Fac |
|--|--------|-----------|-----|------|---|----------------|----------------|---------|
| 11-Chloroeicosafluoro-3-oxaundecane-1-sulfonic acid (11Cl-PF3OUdS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| 9-Chlorohexadecafluoro-3-oxanonane-1-sulfonic acid (9Cl-PF3ONS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| 4,8-Dioxa-3H-perfluorononanoic acid (ADONA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| Perfluorobutanesulfonic acid (PFBS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| Perfluorodecanoic acid (PFDA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:23 | 1 |

Eurofins Eaton Analytical Pomona

Client Sample Results

Client: City & County of Honolulu
Project/Site: RED-HILL

Job ID: 380-174244-1
SDG: PFAS: Ka'amilo Wells P1/P2

Client Sample ID: FB: Ka'amilo Wells P1

Lab Sample ID: 380-174244-3

Date Collected: 09/29/25 11:47

Matrix: Water

Date Received: 10/01/25 10:00

Method: EPA 533 - Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water (Continued)

| Analyte | Result | Qualifier | RL | Unit | D | Prepared | Analyzed | Dil Fac |
|---|--------|-----------|-----|------|---|----------------|----------------|---------|
| Perfluorododecanoic acid (PFDoA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| Perfluoroheptanoic acid (PFHpA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| Perfluorohexanesulfonic acid (PFHxS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| Perfluorohexanoic acid (PFHxA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| Perfluorononanoic acid (PFNA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| Perfluorooctanesulfonic acid (PFOS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| Perfluorooctanoic acid (PFOA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| Perfluoroundecanoic acid (PFUnA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| Perfluorobutanoic acid (PFBA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| 1H,1H,2H,2H-Perfluorodecane sulfonic acid (8:2 FTS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| 1H,1H,2H,2H-Perfluorohexane sulfonic acid (4:2 FTS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| 1H,1H,2H,2H-Perfluorooctane sulfonic acid (6:2 FTS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| Nonafluoro-3,6-dioxaheptanoic acid (NFDHA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| Perfluoro (2-ethoxyethane) sulfonic acid (PFEESA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| Perfluoro-3-methoxypropanoic acid (PFMPA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| Perfluoro-4-methoxybutanoic acid (PFMBA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| Perfluoropentanoic acid (PFPeA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| Perfluoroheptanesulfonic acid (PFHpS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| Perfluoropentanesulfonic acid (PFPeS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:23 | 1 |

| Isotope Dilution | %Recovery | Qualifier | Limits | Prepared | Analyzed | Dil Fac |
|------------------|-----------|-----------|----------|----------------|----------------|---------|
| 13C3 HFPO-DA | 89 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| 13C6 PFDA | 101 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| 13C5 PFHxA | 93 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| 13C4 PFHpA | 99 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| 13C8 PFOA | 104 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| 13C9 PFNA | 102 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| 13C7 PFUnA | 101 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| 13C2 PFDoA | 102 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| 13C4 PFBA | 106 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| 13C5 PFPeA | 104 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| 13C3 PFBS | 103 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| 13C3 PFHxS | 108 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| 13C8 PFOS | 104 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| 13C2-4:2-FTS | 111 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| 13C2-6:2-FTS | 114 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:23 | 1 |
| 13C2-8:2-FTS | 109 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 22:23 | 1 |

Method: EPA 537.1 - Perfluorinated Alkyl Acids (LC/MS)

| Analyte | Result | Qualifier | RL | Unit | D | Prepared | Analyzed | Dil Fac |
|---|--------|-----------|-----|------|---|----------------|----------------|---------|
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:27 | 1 |
| Perfluorooctanesulfonic acid (PFOS) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:27 | 1 |
| Perfluoroundecanoic acid (PFUnA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:27 | 1 |

Eurofins Eaton Analytical Pomona

Client Sample Results

Client: City & County of Honolulu
Project/Site: RED-HILL

Job ID: 380-174244-1
SDG: PFAS: Ka'amilo Wells P1/P2

Client Sample ID: FB: Ka'amilo Wells P1

Lab Sample ID: 380-174244-3

Date Collected: 09/29/25 11:47

Matrix: Water

Date Received: 10/01/25 10:00

Method: EPA 537.1 - Perfluorinated Alkyl Acids (LC/MS) (Continued)

| Analyte | Result | Qualifier | RL | Unit | D | Prepared | Analyzed | Dil Fac |
|--|------------------|------------------|---------------|------|---|-----------------|-----------------|----------------|
| N-methylperfluorooctanesulfonamidoacetic acid (NMeFOSAA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:27 | 1 |
| N-ethylperfluorooctanesulfonamidoacetic acid (NEtFOSAA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:27 | 1 |
| Perfluorohexanoic acid (PFHxA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:27 | 1 |
| Perfluorododecanoic acid (PFDoA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:27 | 1 |
| Perfluorooctanoic acid (PFOA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:27 | 1 |
| Perfluorodecanoic acid (PFDA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:27 | 1 |
| Perfluorohexanesulfonic acid (PFHxS) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:27 | 1 |
| Perfluorobutanesulfonic acid (PFBS) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:27 | 1 |
| Perfluoroheptanoic acid (PFHpA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:27 | 1 |
| Perfluorononanoic acid (PFNA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:27 | 1 |
| Perfluorotetradecanoic acid (PFTA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:27 | 1 |
| Perfluorotridecanoic acid (PFTTrDA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:27 | 1 |
| 9-Chlorohexadecafluoro-3-oxanonane-1-sulfonic acid(9Cl-PF3ONS) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:27 | 1 |
| 11-Chloroeicosafluoro-3-oxaundecane-1-sulfonic acid (11Cl-PF3OUdS) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:27 | 1 |
| 4,8-Dioxa-3H-perfluorononanoic acid (ADONA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:27 | 1 |
| Surrogate | %Recovery | Qualifier | Limits | | | Prepared | Analyzed | Dil Fac |
| d5-NEtFOSAA | 97 | | 70 - 130 | | | 10/02/25 16:08 | 10/03/25 16:27 | 1 |
| 13C2 PFHxA | 106 | | 70 - 130 | | | 10/02/25 16:08 | 10/03/25 16:27 | 1 |
| 13C2 PFDA | 100 | | 70 - 130 | | | 10/02/25 16:08 | 10/03/25 16:27 | 1 |
| 13C3-GenX | 102 | | 70 - 130 | | | 10/02/25 16:08 | 10/03/25 16:27 | 1 |

Client Sample ID: FB: Ka'amilo Wells P2

Lab Sample ID: 380-174244-4

Date Collected: 09/29/25 12:32

Matrix: Water

Date Received: 10/01/25 10:00

Method: EPA 533 - Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water

| Analyte | Result | Qualifier | RL | Unit | D | Prepared | Analyzed | Dil Fac |
|--|--------|-----------|-----|------|---|----------------|----------------|---------|
| 11-Chloroeicosafluoro-3-oxaundecane-1-sulfonic acid (11Cl-PF3OUdS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| 9-Chlorohexadecafluoro-3-oxanonane-1-sulfonic acid(9Cl-PF3ONS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| 4,8-Dioxa-3H-perfluorononanoic acid (ADONA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| Perfluorobutanesulfonic acid (PFBS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| Perfluorodecanoic acid (PFDA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| Perfluorododecanoic acid (PFDoA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| Perfluoroheptanoic acid (PFHpA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| Perfluorohexanesulfonic acid (PFHxS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| Perfluorohexanoic acid (PFHxA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| Perfluorononanoic acid (PFNA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| Perfluorooctanesulfonic acid (PFOS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| Perfluorooctanoic acid (PFOA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| Perfluoroundecanoic acid (PFUnA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| Perfluorobutanoic acid (PFBA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |

Eurofins Eaton Analytical Pomona

Client Sample Results

Client: City & County of Honolulu
Project/Site: RED-HILL

Job ID: 380-174244-1
SDG: PFAS: Ka'amilo Wells P1/P2

Client Sample ID: FB: Ka'amilo Wells P2

Lab Sample ID: 380-174244-4

Date Collected: 09/29/25 12:32

Matrix: Water

Date Received: 10/01/25 10:00

Method: EPA 533 - Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water (Continued)

| Analyte | Result | Qualifier | RL | Unit | D | Prepared | Analyzed | Dil Fac |
|---|-----------|-----------|----------|------|---|----------------|----------------|---------|
| 1H,1H,2H,2H-Perfluorodecane sulfonic acid (8:2 FTS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| 1H,1H,2H,2H-Perfluorohexane sulfonic acid (4:2 FTS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| 1H,1H,2H,2H-Perfluorooctane sulfonic acid (6:2 FTS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| Nonafluoro-3,6-dioxahexanoic acid (NFDHA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| Perfluoro (2-ethoxyethane) sulfonic acid (PFEEA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| Perfluoro-3-methoxypropanoic acid (PFMPA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| Perfluoro-4-methoxybutanoic acid (PFMBA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| Perfluoropentanoic acid (PFPeA) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| Perfluoroheptanesulfonic acid (PFHpS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| Perfluoropentanesulfonic acid (PFPeS) | <2.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| Isotope Dilution | %Recovery | Qualifier | Limits | | | Prepared | Analyzed | Dil Fac |
| 13C3 HFPO-DA | 100 | | 50 - 200 | | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| 13C6 PFDA | 108 | | 50 - 200 | | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| 13C5 PFHxA | 107 | | 50 - 200 | | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| 13C4 PFHpA | 110 | | 50 - 200 | | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| 13C8 PFOA | 115 | | 50 - 200 | | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| 13C9 PFNA | 115 | | 50 - 200 | | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| 13C7 PFUnA | 112 | | 50 - 200 | | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| 13C2 PFDoA | 110 | | 50 - 200 | | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| 13C4 PFBA | 106 | | 50 - 200 | | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| 13C5 PFPeA | 112 | | 50 - 200 | | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| 13C3 PFBS | 107 | | 50 - 200 | | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| 13C3 PFHxS | 111 | | 50 - 200 | | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| 13C8 PFOS | 109 | | 50 - 200 | | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| 13C2-4:2-FTS | 111 | | 50 - 200 | | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| 13C2-6:2-FTS | 111 | | 50 - 200 | | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |
| 13C2-8:2-FTS | 117 | | 50 - 200 | | | 10/02/25 03:37 | 10/02/25 22:34 | 1 |

Method: EPA 537.1 - Perfluorinated Alkyl Acids (LC/MS)

| Analyte | Result | Qualifier | RL | Unit | D | Prepared | Analyzed | Dil Fac |
|--|--------|-----------|-----|------|---|----------------|----------------|---------|
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:38 | 1 |
| Perfluorooctanesulfonic acid (PFOS) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:38 | 1 |
| Perfluoroundecanoic acid (PFUnA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:38 | 1 |
| N-methylperfluorooctanesulfonamidoacetic acid (NMeFOSAA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:38 | 1 |
| N-ethylperfluorooctanesulfonamidoacetic acid (NEtFOSAA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:38 | 1 |
| Perfluorohexanoic acid (PFHxA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:38 | 1 |
| Perfluorododecanoic acid (PFDoA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:38 | 1 |
| Perfluorooctanoic acid (PFOA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:38 | 1 |
| Perfluorodecanoic acid (PFDA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:38 | 1 |
| Perfluorohexanesulfonic acid (PFHxS) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:38 | 1 |

Eurofins Eaton Analytical Pomona

Client Sample Results

Client: City & County of Honolulu
 Project/Site: RED-HILL

Job ID: 380-174244-1
 SDG: PFAS: Ka'amilo Wells P1/P2

Client Sample ID: FB: Ka'amilo Wells P2

Lab Sample ID: 380-174244-4

Date Collected: 09/29/25 12:32

Matrix: Water

Date Received: 10/01/25 10:00

Method: EPA 537.1 - Perfluorinated Alkyl Acids (LC/MS) (Continued)

| Analyte | Result | Qualifier | RL | Unit | D | Prepared | Analyzed | Dil Fac |
|---|--------|-----------|-----|------|---|----------------|----------------|---------|
| Perfluorobutanesulfonic acid (PFBS) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:38 | 1 |
| Perfluoroheptanoic acid (PFHpA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:38 | 1 |
| Perfluorononanoic acid (PFNA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:38 | 1 |
| Perfluorotetradecanoic acid (PFTA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:38 | 1 |
| Perfluorotridecanoic acid (PFTrDA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:38 | 1 |
| 9-Chlorohexadecafluoro-3-oxanonan e-1-sulfonic acid(9Cl-PF3ONS) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:38 | 1 |
| 11-Chloroeicosafuoro-3-oxaundecan e-1-sulfonic acid (11Cl-PF3OUdS) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:38 | 1 |
| 4,8-Dioxa-3H-perfluorononanoic acid (ADONA) | <2.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 16:38 | 1 |

| Surrogate | %Recovery | Qualifier | Limits | Prepared | Analyzed | Dil Fac |
|-------------|-----------|-----------|----------|----------------|----------------|---------|
| d5-NEtFOSAA | 100 | | 70 - 130 | 10/02/25 16:08 | 10/03/25 16:38 | 1 |
| 13C2 PFHxA | 104 | | 70 - 130 | 10/02/25 16:08 | 10/03/25 16:38 | 1 |
| 13C2 PFDA | 102 | | 70 - 130 | 10/02/25 16:08 | 10/03/25 16:38 | 1 |
| 13C3-GenX | 105 | | 70 - 130 | 10/02/25 16:08 | 10/03/25 16:38 | 1 |

Action Limit Summary

Client: City & County of Honolulu
Project/Site: RED-HILL

Job ID: 380-174244-1
SDG: PFAS: Ka'amilo Wells P1/P2

Client Sample ID: Ka'amilo Wells P1

Lab Sample ID: 380-174244-1

Compliance Check

The results obtained from the analytical testing of this data set were checked against compliance limits received from the client. Any results at or above the compliance limits have been highlighted for your convenience.

| Analyte | Result | Qualifier | Unit | EPAMCL | | RL | Method | Prep Type |
|---|------------|-----------|------|----------|--|-----|--------|-----------|
| | | | | Limit | | | | |
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX) | <2.0 | | ng/L | 10 | | 2.0 | 533 | Total/NA |
| Perfluorohexanesulfonic acid (PFHxS) | 3.3 | | ng/L | 10 | | 2.0 | 533 | Total/NA |
| Perfluorononanoic acid (PFNA) | <2.0 | | ng/L | 10 | | 2.0 | 533 | Total/NA |
| Perfluorooctanesulfonic acid (PFOS) | 4.4 | | ng/L | 4 | | 2.0 | 533 | Total/NA |
| Perfluorooctanoic acid (PFOA) | 3.8 | | ng/L | 4 | | 2.0 | 533 | Total/NA |
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX) | <2.0 | | ng/L | 10 | | 2.0 | 537.1 | Total/NA |
| Perfluorooctanesulfonic acid (PFOS) | 4.5 | | ng/L | 4 | | 2.0 | 537.1 | Total/NA |
| Perfluorooctanoic acid (PFOA) | 3.8 | | ng/L | 4 | | 2.0 | 537.1 | Total/NA |
| Perfluorohexanesulfonic acid (PFHxS) | 3.5 | | ng/L | 10 | | 2.0 | 537.1 | Total/NA |
| Perfluorononanoic acid (PFNA) | <2.0 | | ng/L | 10 | | 2.0 | 537.1 | Total/NA |

Client Sample ID: Ka'amilo Wells P2

Lab Sample ID: 380-174244-2

Compliance Check

The results obtained from the analytical testing of this data set were checked against compliance limits received from the client. Any results at or above the compliance limits have been highlighted for your convenience.

| Analyte | Result | Qualifier | Unit | EPAMCL | | RL | Method | Prep Type |
|---|------------|-----------|------|----------|--|-----|--------|-----------|
| | | | | Limit | | | | |
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX) | <2.0 | | ng/L | 10 | | 2.0 | 533 | Total/NA |
| Perfluorohexanesulfonic acid (PFHxS) | 3.2 | | ng/L | 10 | | 2.0 | 533 | Total/NA |
| Perfluorononanoic acid (PFNA) | <2.0 | | ng/L | 10 | | 2.0 | 533 | Total/NA |
| Perfluorooctanesulfonic acid (PFOS) | 4.1 | | ng/L | 4 | | 2.0 | 533 | Total/NA |
| Perfluorooctanoic acid (PFOA) | 3.5 | | ng/L | 4 | | 2.0 | 533 | Total/NA |
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX) | <2.0 | | ng/L | 10 | | 2.0 | 537.1 | Total/NA |
| Perfluorooctanesulfonic acid (PFOS) | 3.6 | | ng/L | 4 | | 2.0 | 537.1 | Total/NA |
| Perfluorooctanoic acid (PFOA) | 3.4 | | ng/L | 4 | | 2.0 | 537.1 | Total/NA |
| Perfluorohexanesulfonic acid (PFHxS) | 3.1 | | ng/L | 10 | | 2.0 | 537.1 | Total/NA |
| Perfluorononanoic acid (PFNA) | <2.0 | | ng/L | 10 | | 2.0 | 537.1 | Total/NA |

Client Sample ID: FB: Ka'amilo Wells P1

Lab Sample ID: 380-174244-3

Compliance Check

The results obtained from the analytical testing of this data set were checked against compliance limits received from the client. Any results at or above the compliance limits have been highlighted for your convenience.

| Analyte | Result | Qualifier | Unit | EPAMCL | | RL | Method | Prep Type |
|---|--------|-----------|------|--------|--|-----|--------|-----------|
| | | | | Limit | | | | |
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX) | <2.0 | | ng/L | 10 | | 2.0 | 533 | Total/NA |
| Perfluorohexanesulfonic acid (PFHxS) | <2.0 | | ng/L | 10 | | 2.0 | 533 | Total/NA |
| Perfluorononanoic acid (PFNA) | <2.0 | | ng/L | 10 | | 2.0 | 533 | Total/NA |
| Perfluorooctanesulfonic acid (PFOS) | <2.0 | | ng/L | 4 | | 2.0 | 533 | Total/NA |
| Perfluorooctanoic acid (PFOA) | <2.0 | | ng/L | 4 | | 2.0 | 533 | Total/NA |
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX) | <2.0 | | ng/L | 10 | | 2.0 | 537.1 | Total/NA |

Eurofins Eaton Analytical Pomona

Action Limit Summary

Client: City & County of Honolulu
Project/Site: RED-HILL

Job ID: 380-174244-1
SDG: PFAS: Ka'amilo Wells P1/P2

Client Sample ID: FB: Ka'amilo Wells P1 (Continued)

Lab Sample ID: 380-174244-3

Compliance Check

The results obtained from the analytical testing of this data set were checked against compliance limits received from the client. Any results at or above the compliance limits have been highlighted for your convenience.

| Analyte | Result | Qualifier | Unit | EPAMCL | RL | Method | Prep Type |
|--------------------------------------|--------|-----------|------|--------|-----|--------|-----------|
| | | | | Limit | | | |
| Perfluorooctanesulfonic acid (PFOS) | <2.0 | | ng/L | 4 | 2.0 | 537.1 | Total/NA |
| Perfluorooctanoic acid (PFOA) | <2.0 | | ng/L | 4 | 2.0 | 537.1 | Total/NA |
| Perfluorohexanesulfonic acid (PFHxS) | <2.0 | | ng/L | 10 | 2.0 | 537.1 | Total/NA |
| Perfluorononanoic acid (PFNA) | <2.0 | | ng/L | 10 | 2.0 | 537.1 | Total/NA |

Client Sample ID: FB: Ka'amilo Wells P2

Lab Sample ID: 380-174244-4

Compliance Check

The results obtained from the analytical testing of this data set were checked against compliance limits received from the client. Any results at or above the compliance limits have been highlighted for your convenience.

| Analyte | Result | Qualifier | Unit | EPAMCL | RL | Method | Prep Type |
|---|--------|-----------|------|--------|-----|--------|-----------|
| | | | | Limit | | | |
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX) | <2.0 | | ng/L | 10 | 2.0 | 533 | Total/NA |
| Perfluorohexanesulfonic acid (PFHxS) | <2.0 | | ng/L | 10 | 2.0 | 533 | Total/NA |
| Perfluorononanoic acid (PFNA) | <2.0 | | ng/L | 10 | 2.0 | 533 | Total/NA |
| Perfluorooctanesulfonic acid (PFOS) | <2.0 | | ng/L | 4 | 2.0 | 533 | Total/NA |
| Perfluorooctanoic acid (PFOA) | <2.0 | | ng/L | 4 | 2.0 | 533 | Total/NA |
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX) | <2.0 | | ng/L | 10 | 2.0 | 537.1 | Total/NA |
| Perfluorooctanesulfonic acid (PFOS) | <2.0 | | ng/L | 4 | 2.0 | 537.1 | Total/NA |
| Perfluorooctanoic acid (PFOA) | <2.0 | | ng/L | 4 | 2.0 | 537.1 | Total/NA |
| Perfluorohexanesulfonic acid (PFHxS) | <2.0 | | ng/L | 10 | 2.0 | 537.1 | Total/NA |
| Perfluorononanoic acid (PFNA) | <2.0 | | ng/L | 10 | 2.0 | 537.1 | Total/NA |

Surrogate Summary

Client: City & County of Honolulu
 Project/Site: RED-HILL

Job ID: 380-174244-1
 SDG: PFAS: Ka'amilo Wells P1/P2

Method: 537.1 - Perfluorinated Alkyl Acids (LC/MS)

Matrix: Water

Prep Type: Total/NA

| Lab Sample ID | Client Sample ID | Percent Surrogate Recovery (Acceptance Limits) | | | |
|----------------------|------------------------|--|-------------------|------------------|------------------|
| | | d5NEFOS (70-130) | PFHxA (70-130) | PFDA (70-130) | GenX (70-130) |
| 380-174242-A-1-B MS | Matrix Spike | 87 | 113 | 99 | 115 |
| 380-174242-A-1-C MSD | Matrix Spike Duplicate | 95 | 106 | 100 | 103 |
| 380-174244-1 | Ka'amilo Wells P1 | 101 | 103 | 110 | 110 |
| 380-174244-2 | Ka'amilo Wells P2 | 96 | 102 | 107 | 108 |
| 380-174244-3 | FB: Ka'amilo Wells P1 | 97 | 106 | 100 | 102 |
| 380-174244-4 | FB: Ka'amilo Wells P2 | 100 | 104 | 102 | 105 |
| LCS 380-177612/22-A | Lab Control Sample | 98 | 99 | 99 | 110 |
| MBL 380-177612/20-A | Method Blank | 102 | 114 | 114 | 116 |
| MRL 380-177612/21-A | Lab Control Sample | 102 | 105 | 98 | 102 |

Surrogate Legend

d5NEFOS = d5-NEtFOSAA
 PFHxA = 13C2 PFHxA
 PFDA = 13C2 PFDA
 GenX = 13C3-GenX

Isotope Dilution Summary

Client: City & County of Honolulu
Project/Site: RED-HILL

Job ID: 380-174244-1
SDG: PFAS: Ka'amilo Wells P1/P2

Method: 533 - Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water

Matrix: Water

Prep Type: Total/NA

| | | Percent Isotope Dilution Recovery (Acceptance Limits) | | | | | | | |
|---------------------|-----------------------|---|--------------------|---------------------|--------------------|--------------------|--------------------|---------------------|--------------------------------|
| Lab Sample ID | Client Sample ID | HFPODA (50-200) | C6PFDA (50-200) | 13C5PHA (50-200) | C4PFHA (50-200) | C8PFOA (50-200) | C9PFNA (50-200) | 13C7PUA (50-200) | PFD _o A (50-200) |
| 380-174244-1 | Ka'amilo Wells P1 | 87 | 102 | 97 | 103 | 107 | 103 | 104 | 103 |
| 380-174244-1 MS | Ka'amilo Wells P1 | 107 | 113 | 105 | 113 | 115 | 113 | 112 | 114 |
| 380-174244-1 MSD | Ka'amilo Wells P1 | 103 | 109 | 100 | 115 | 110 | 107 | 108 | 110 |
| 380-174244-2 | Ka'amilo Wells P2 | 93 | 104 | 98 | 100 | 106 | 100 | 107 | 103 |
| 380-174244-3 | FB: Ka'amilo Wells P1 | 89 | 101 | 93 | 99 | 104 | 102 | 101 | 102 |
| 380-174244-4 | FB: Ka'amilo Wells P2 | 100 | 108 | 107 | 110 | 115 | 115 | 112 | 110 |
| LCS 380-177489/30-A | Lab Control Sample | 104 | 108 | 106 | 107 | 116 | 111 | 114 | 110 |
| MBL 380-177489/28-A | Method Blank | 98 | 113 | 107 | 114 | 115 | 112 | 112 | 115 |
| MRL 380-177489/29-A | Lab Control Sample | 90 | 102 | 102 | 103 | 106 | 103 | 105 | 107 |

| | | Percent Isotope Dilution Recovery (Acceptance Limits) | | | | | | | |
|---------------------|-----------------------|---|-------------------|--------------------|--------------------|--------------------|-------------------|-------------------|-------------------|
| Lab Sample ID | Client Sample ID | PFBA (50-200) | PFPeA (50-200) | C3PFBS (50-200) | C3PFHS (50-200) | C8PFOS (50-200) | 42FTS (50-200) | 62FTS (50-200) | 82FTS (50-200) |
| 380-174244-1 | Ka'amilo Wells P1 | 104 | 106 | 105 | 109 | 106 | 104 | 110 | 107 |
| 380-174244-1 MS | Ka'amilo Wells P1 | 114 | 116 | 110 | 113 | 110 | 112 | 116 | 116 |
| 380-174244-1 MSD | Ka'amilo Wells P1 | 112 | 113 | 108 | 107 | 106 | 110 | 109 | 113 |
| 380-174244-2 | Ka'amilo Wells P2 | 109 | 109 | 102 | 108 | 103 | 111 | 114 | 115 |
| 380-174244-3 | FB: Ka'amilo Wells P1 | 106 | 104 | 103 | 108 | 104 | 111 | 114 | 109 |
| 380-174244-4 | FB: Ka'amilo Wells P2 | 106 | 112 | 107 | 111 | 109 | 111 | 111 | 117 |
| LCS 380-177489/30-A | Lab Control Sample | 109 | 111 | 105 | 110 | 106 | 105 | 113 | 108 |
| MBL 380-177489/28-A | Method Blank | 120 | 114 | 111 | 121 | 115 | 118 | 119 | 118 |
| MRL 380-177489/29-A | Lab Control Sample | 114 | 106 | 102 | 113 | 106 | 112 | 111 | 110 |

Surrogate Legend

- HFPODA = 13C3 HFPO-DA
- C6PFDA = 13C6 PFDA
- 13C5PHA = 13C5 PFHxA
- C4PFHA = 13C4 PFHpA
- C8PFOA = 13C8 PFOA
- C9PFNA = 13C9 PFNA
- 13C7PUA = 13C7 PFUnA
- PFD_oA = 13C2 PFD_oA
- PFBA = 13C4 PFBA
- PFPeA = 13C5 PFPeA
- C3PFBS = 13C3 PFBS
- C3PFHS = 13C3 PFHxS
- C8PFOS = 13C8 PFOS
- 42FTS = 13C2-4:2-FTS
- 62FTS = 13C2-6:2-FTS
- 82FTS = 13C2-8:2-FTS

QC Sample Results

Client: City & County of Honolulu
Project/Site: RED-HILL

Job ID: 380-174244-1
SDG: PFAS: Ka'amilo Wells P1/P2

Method: 533 - Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water

Lab Sample ID: MBL 380-177489/28-A
Matrix: Water
Analysis Batch: 177605

Client Sample ID: Method Blank
Prep Type: Total/NA
Prep Batch: 177489

| Analyte | MBL Result | MBL Qualifier | RL | Unit | D | Prepared | Analyzed | Dil Fac |
|--|------------|---------------|-----|------|---|----------------|----------------|---------|
| 11-Chloroeicosafluoro-3-oxaundecane-1-sulfonic acid (11Cl-PF3OUdS) | <0.30 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| 9-Chlorohexadecafluoro-3-oxanonane-1-sulfonic acid(9Cl-PF3ONS) | <0.30 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| 4,8-Dioxa-3H-perfluorononanoic acid (ADONA) | <0.60 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX) | <1.0 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| Perfluorobutanesulfonic acid (PFBS) | <0.37 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| Perfluorodecanoic acid (PFDA) | <0.31 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| Perfluorododecanoic acid (PFDoA) | <0.54 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| Perfluoroheptanoic acid (PFHpA) | <0.39 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| Perfluorohexanesulfonic acid (PFHxS) | <0.32 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| Perfluorohexanoic acid (PFHxA) | <0.46 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| Perfluorononanoic acid (PFNA) | <0.40 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| Perfluorooctanesulfonic acid (PFOS) | <0.43 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| Perfluorooctanoic acid (PFOA) | <0.38 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| Perfluoroundecanoic acid (PFUnA) | <0.42 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| Perfluorobutanoic acid (PFBA) | <0.69 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| 1H,1H,2H,2H-Perfluorodecane sulfonic acid (8:2 FTS) | <0.38 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| 1H,1H,2H,2H-Perfluorohexane sulfonic acid (4:2 FTS) | <0.37 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| 1H,1H,2H,2H-Perfluorooctane sulfonic acid (6:2 FTS) | <0.48 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| Nonafluoro-3,6-dioxaheptanoic acid (NFDHA) | <0.47 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| Perfluoro (2-ethoxyethane) sulfonic acid (PFEESA) | <0.25 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| Perfluoro-3-methoxypropanoic acid (PFMPA) | <0.46 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| Perfluoro-4-methoxybutanoic acid (PFMBA) | <0.15 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| Perfluoropentanoic acid (PFPeA) | <0.38 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| Perfluoroheptanesulfonic acid (PFHpS) | <0.36 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| Perfluoropentanesulfonic acid (PFPeS) | <0.39 | | 2.0 | ng/L | | 10/02/25 03:37 | 10/02/25 16:50 | 1 |

| Isotope Dilution | MBL %Recovery | MBL Qualifier | Limits | Prepared | Analyzed | Dil Fac |
|------------------|---------------|---------------|----------|----------------|----------------|---------|
| 13C3 HFPO-DA | 98 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| 13C6 PFDA | 113 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| 13C5 PFHxA | 107 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| 13C4 PFHpA | 114 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| 13C8 PFOA | 115 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| 13C9 PFNA | 112 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| 13C7 PFUnA | 112 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| 13C2 PFDoA | 115 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| 13C4 PFBA | 120 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| 13C5 PFPeA | 114 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| 13C3 PFBS | 111 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| 13C3 PFHxS | 121 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 16:50 | 1 |

Eurofins Eaton Analytical Pomona

QC Sample Results

Client: City & County of Honolulu
Project/Site: RED-HILL

Job ID: 380-174244-1
SDG: PFAS: Ka'amilo Wells P1/P2

Method: 533 - Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water (Continued)

Lab Sample ID: MBL 380-177489/28-A
Matrix: Water
Analysis Batch: 177605

Client Sample ID: Method Blank
Prep Type: Total/NA
Prep Batch: 177489

| <i>Isotope Dilution</i> | <i>MBL</i> | <i>MBL</i> | <i>Limits</i> | <i>Prepared</i> | <i>Analyzed</i> | <i>Dil Fac</i> |
|-------------------------|------------------|------------------|---------------|-----------------|-----------------|----------------|
| | <i>%Recovery</i> | <i>Qualifier</i> | | | | |
| 13C8 PFOS | 115 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| 13C2-4:2-FTS | 118 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| 13C2-6:2-FTS | 119 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 16:50 | 1 |
| 13C2-8:2-FTS | 118 | | 50 - 200 | 10/02/25 03:37 | 10/02/25 16:50 | 1 |

Lab Sample ID: LCS 380-177489/30-A
Matrix: Water
Analysis Batch: 177605

Client Sample ID: Lab Control Sample
Prep Type: Total/NA
Prep Batch: 177489

| <i>Analyte</i> | <i>Spike</i> | <i>LCS</i> | <i>LCS</i> | <i>Unit</i> | <i>D</i> | <i>%Rec</i> | <i>%Rec</i> |
|--|--------------|---------------|------------------|-------------|----------|-------------|---------------|
| | <i>Added</i> | <i>Result</i> | <i>Qualifier</i> | | | | <i>Limits</i> |
| 11-Chloroeicosafluoro-3-oxaundecane-1-sulfonic acid (11Cl-PF3OUdS) | 60.1 | 62.6 | | ng/L | | 104 | 70 - 130 |
| 9-Chlorohexadecafluoro-3-oxanonane-1-sulfonic acid(9Cl-PF3ONS) | 60.1 | 61.9 | | ng/L | | 103 | 70 - 130 |
| 4,8-Dioxo-3H-perfluorononanoic acid (ADONA) | 60.1 | 59.3 | | ng/L | | 99 | 70 - 130 |
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX) | 60.1 | 58.3 | | ng/L | | 97 | 70 - 130 |
| Perfluorobutanesulfonic acid (PFBS) | 60.1 | 62.6 | | ng/L | | 104 | 70 - 130 |
| Perfluorodecanoic acid (PFDA) | 60.1 | 61.7 | | ng/L | | 103 | 70 - 130 |
| Perfluorododecanoic acid (PFDoA) | 60.1 | 59.1 | | ng/L | | 98 | 70 - 130 |
| Perfluoroheptanoic acid (PFHpA) | 60.1 | 61.9 | | ng/L | | 103 | 70 - 130 |
| Perfluorohexanesulfonic acid (PFHxS) | 60.1 | 59.2 | | ng/L | | 98 | 70 - 130 |
| Perfluorohexanoic acid (PFHxA) | 60.1 | 60.9 | | ng/L | | 101 | 70 - 130 |
| Perfluorononanoic acid (PFNA) | 60.1 | 59.2 | | ng/L | | 98 | 70 - 130 |
| Perfluorooctanesulfonic acid (PFOS) | 60.1 | 62.7 | | ng/L | | 104 | 70 - 130 |
| Perfluorooctanoic acid (PFOA) | 60.1 | 56.1 | | ng/L | | 93 | 70 - 130 |
| Perfluoroundecanoic acid (PFUnA) | 60.1 | 59.4 | | ng/L | | 99 | 70 - 130 |
| Perfluorobutanoic acid (PFBA) | 60.1 | 61.6 | | ng/L | | 102 | 70 - 130 |
| 1H,1H,2H,2H-Perfluorodecane sulfonic acid (8:2 FTS) | 60.1 | 62.0 | | ng/L | | 103 | 70 - 130 |
| 1H,1H,2H,2H-Perfluorohexane sulfonic acid (4:2 FTS) | 60.1 | 65.1 | | ng/L | | 108 | 70 - 130 |
| 1H,1H,2H,2H-Perfluorooctane sulfonic acid (6:2 FTS) | 60.1 | 58.9 | | ng/L | | 98 | 70 - 130 |
| Nonafluoro-3,6-dioxaheptanoic acid (NFDHA) | 60.1 | 60.4 | | ng/L | | 101 | 70 - 130 |
| Perfluoro (2-ethoxyethane) sulfonic acid (PFEEESA) | 60.1 | 58.5 | | ng/L | | 97 | 70 - 130 |
| Perfluoro-3-methoxypropanoic acid (PFMPA) | 60.1 | 62.3 | | ng/L | | 104 | 70 - 130 |
| Perfluoro-4-methoxybutanoic acid (PFMBA) | 60.1 | 54.4 | | ng/L | | 90 | 70 - 130 |
| Perfluoropentanoic acid (PFPeA) | 60.1 | 61.2 | | ng/L | | 102 | 70 - 130 |
| Perfluoroheptanesulfonic acid (PFHpS) | 60.1 | 63.0 | | ng/L | | 105 | 70 - 130 |

QC Sample Results

Client: City & County of Honolulu
Project/Site: RED-HILL

Job ID: 380-174244-1
SDG: PFAS: Ka'amilo Wells P1/P2

Method: 533 - Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water (Continued)

Lab Sample ID: LCS 380-177489/30-A
Matrix: Water
Analysis Batch: 177605

Client Sample ID: Lab Control Sample
Prep Type: Total/NA
Prep Batch: 177489

| Analyte | Spike Added | LCS Result | LCS Qualifier | Unit | D | %Rec | %Rec Limits |
|---------------------------------------|------------------|------------------|---------------|------|---|------|-------------|
| | | | | | | | |
| Perfluoropentanesulfonic acid (PFPeS) | 60.1 | 58.7 | | ng/L | | 98 | 70 - 130 |
| LCS LCS | | | | | | | |
| Isotope Dilution | %Recovery | Qualifier | Limits | | | | |
| 13C3 HFPO-DA | 104 | | 50 - 200 | | | | |
| 13C6 PFDA | 108 | | 50 - 200 | | | | |
| 13C5 PFHxA | 106 | | 50 - 200 | | | | |
| 13C4 PFHpA | 107 | | 50 - 200 | | | | |
| 13C8 PFOA | 116 | | 50 - 200 | | | | |
| 13C9 PFNA | 111 | | 50 - 200 | | | | |
| 13C7 PFUnA | 114 | | 50 - 200 | | | | |
| 13C2 PFDoA | 110 | | 50 - 200 | | | | |
| 13C4 PFBA | 109 | | 50 - 200 | | | | |
| 13C5 PFPeA | 111 | | 50 - 200 | | | | |
| 13C3 PFBS | 105 | | 50 - 200 | | | | |
| 13C3 PFHxS | 110 | | 50 - 200 | | | | |
| 13C8 PFOS | 106 | | 50 - 200 | | | | |
| 13C2-4:2-FTS | 105 | | 50 - 200 | | | | |
| 13C2-6:2-FTS | 113 | | 50 - 200 | | | | |
| 13C2-8:2-FTS | 108 | | 50 - 200 | | | | |

Lab Sample ID: MRL 380-177489/29-A
Matrix: Water
Analysis Batch: 177605

Client Sample ID: Lab Control Sample
Prep Type: Total/NA
Prep Batch: 177489

| Analyte | Spike Added | MRL Result | MRL Qualifier | Unit | D | %Rec | %Rec Limits |
|--|-------------|------------|---------------|------|---|------|-------------|
| | | | | | | | |
| 11-Chloroeicosafluoro-3-oxaundecane-1-sulfonic acid (11Cl-PF3OUdS) | 2.01 | 2.02 | J | ng/L | | 100 | 50 - 150 |
| 9-Chlorohexadecafluoro-3-oxanonane-1-sulfonic acid(9Cl-PF3ONS) | 2.01 | 2.08 | J | ng/L | | 104 | 50 - 150 |
| 4,8-Dioxa-3H-perfluorononanoic acid (ADONA) | 2.01 | 2.02 | J | ng/L | | 100 | 50 - 150 |
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX) | 2.01 | 2.06 | J | ng/L | | 103 | 50 - 150 |
| Perfluorobutanesulfonic acid (PFBS) | 2.01 | 2.14 | J | ng/L | | 107 | 50 - 150 |
| Perfluorodecanoic acid (PFDA) | 2.01 | 2.07 | J | ng/L | | 103 | 50 - 150 |
| Perfluorododecanoic acid (PFDoA) | 2.01 | 2.02 | J | ng/L | | 101 | 50 - 150 |
| Perfluoroheptanoic acid (PFHpA) | 2.01 | 2.03 | J | ng/L | | 101 | 50 - 150 |
| Perfluorohexanesulfonic acid (PFHxS) | 2.01 | 1.89 | J | ng/L | | 94 | 50 - 150 |
| Perfluorohexanoic acid (PFHxA) | 2.01 | 2.08 | J | ng/L | | 103 | 50 - 150 |
| Perfluorononanoic acid (PFNA) | 2.01 | 2.01 | J | ng/L | | 100 | 50 - 150 |
| Perfluorooctanesulfonic acid (PFOS) | 2.01 | 2.16 | J | ng/L | | 107 | 50 - 150 |
| Perfluorooctanoic acid (PFOA) | 2.01 | 1.97 | J | ng/L | | 98 | 50 - 150 |
| Perfluoroundecanoic acid (PFUnA) | 2.01 | 2.10 | J | ng/L | | 104 | 50 - 150 |
| Perfluorobutanoic acid (PFBA) | 2.01 | 1.90 | J | ng/L | | 95 | 50 - 150 |

Eurofins Eaton Analytical Pomona

QC Sample Results

Client: City & County of Honolulu
Project/Site: RED-HILL

Job ID: 380-174244-1
SDG: PFAS: Ka'amilo Wells P1/P2

Method: 533 - Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water (Continued)

Lab Sample ID: MRL 380-177489/29-A
Matrix: Water
Analysis Batch: 177605

Client Sample ID: Lab Control Sample
Prep Type: Total/NA
Prep Batch: 177489

| Analyte | Spike Added | MRL Result | MRL Qualifier | Unit | D | %Rec | %Rec Limits |
|---|-------------|------------|---------------|------|---|------|-------------|
| 1H,1H,2H,2H-Perfluorodecane sulfonic acid (8:2 FTS) | 2.01 | 2.17 | J | ng/L | | 108 | 50 - 150 |
| 1H,1H,2H,2H-Perfluorohexane sulfonic acid (4:2 FTS) | 2.01 | 2.00 | J | ng/L | | 100 | 50 - 150 |
| 1H,1H,2H,2H-Perfluorooctane sulfonic acid (6:2 FTS) | 2.01 | 2.03 | J | ng/L | | 101 | 50 - 150 |
| Nonafluoro-3,6-dioxaheptanoic acid (NFDHA) | 2.01 | 1.93 | J | ng/L | | 96 | 50 - 150 |
| Perfluoro (2-ethoxyethane) sulfonic acid (PFEEESA) | 2.01 | 1.90 | J | ng/L | | 94 | 50 - 150 |
| Perfluoro-3-methoxypropanoic acid (PFMPA) | 2.01 | 1.96 | J | ng/L | | 97 | 50 - 150 |
| Perfluoro-4-methoxybutanoic acid (PFMBA) | 2.01 | 1.95 | J | ng/L | | 97 | 50 - 150 |
| Perfluoropentanoic acid (PFPeA) | 2.01 | 2.03 | J | ng/L | | 101 | 50 - 150 |
| Perfluoroheptanesulfonic acid (PFHpS) | 2.01 | 2.14 | J | ng/L | | 106 | 50 - 150 |
| Perfluoropentanesulfonic acid (PFPeS) | 2.01 | 1.91 | J | ng/L | | 95 | 50 - 150 |

| Isotope Dilution | MRL %Recovery | MRL Qualifier | MRL Limits |
|------------------|---------------|---------------|------------|
| 13C3 HFPO-DA | 90 | | 50 - 200 |
| 13C6 PFDA | 102 | | 50 - 200 |
| 13C5 PFHxA | 102 | | 50 - 200 |
| 13C4 PFHpA | 103 | | 50 - 200 |
| 13C8 PFOA | 106 | | 50 - 200 |
| 13C9 PFNA | 103 | | 50 - 200 |
| 13C7 PFUnA | 105 | | 50 - 200 |
| 13C2 PFDoA | 107 | | 50 - 200 |
| 13C4 PFBA | 114 | | 50 - 200 |
| 13C5 PFPeA | 106 | | 50 - 200 |
| 13C3 PFBS | 102 | | 50 - 200 |
| 13C3 PFHxS | 113 | | 50 - 200 |
| 13C8 PFOS | 106 | | 50 - 200 |
| 13C2-4:2-FTS | 112 | | 50 - 200 |
| 13C2-6:2-FTS | 111 | | 50 - 200 |
| 13C2-8:2-FTS | 110 | | 50 - 200 |

Lab Sample ID: 380-174244-1 MS
Matrix: Water
Analysis Batch: 177605

Client Sample ID: Ka'amilo Wells P1
Prep Type: Total/NA
Prep Batch: 177489

| Analyte | Sample Result | Sample Qualifier | Spike Added | MS Result | MS Qualifier | Unit | D | %Rec | %Rec Limits |
|--|---------------|------------------|-------------|-----------|--------------|------|---|------|-------------|
| 11-Chloroeicosafluoro-3-oxaundecane-1-sulfonic acid (11Cl-PF3OUdS) | <2.0 | | 60.5 | 60.3 | | ng/L | | 100 | 70 - 130 |
| 9-Chlorohexadecafluoro-3-oxanonane-1-sulfonic acid(9Cl-PF3ONS) | <2.0 | | 60.5 | 62.4 | | ng/L | | 103 | 70 - 130 |
| 4,8-Dioxa-3H-perfluorononanoic acid (ADONA) | <2.0 | | 60.5 | 55.3 | | ng/L | | 91 | 70 - 130 |

QC Sample Results

Client: City & County of Honolulu
Project/Site: RED-HILL

Job ID: 380-174244-1
SDG: PFAS: Ka'amilo Wells P1/P2

Method: 533 - Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water (Continued)

Lab Sample ID: 380-174244-1 MS

Matrix: Water

Analysis Batch: 177605

Client Sample ID: Ka'amilo Wells P1

Prep Type: Total/NA

Prep Batch: 177489

| Analyte | Sample | Sample | Spike | MS | MS | Unit | D | %Rec | %Rec Limits |
|---|--------|-----------|-------|--------|-----------|------|---|------|----------------|
| | Result | Qualifier | Added | Result | Qualifier | | | | |
| Hexafluoropropylene Oxide | <2.0 | | 60.5 | 57.3 | | ng/L | | 95 | 70 - 130 |
| Dimer Acid (HFPO-DA/GenX) | | | | | | | | | |
| Perfluorobutanesulfonic acid (PFBS) | 3.2 | | 60.5 | 65.5 | | ng/L | | 103 | 70 - 130 |
| Perfluorodecanoic acid (PFDA) | <2.0 | | 60.5 | 59.5 | | ng/L | | 98 | 70 - 130 |
| Perfluorododecanoic acid (PFDoA) | <2.0 | | 60.5 | 57.4 | | ng/L | | 95 | 70 - 130 |
| Perfluoroheptanoic acid (PFHpA) | <2.0 | | 60.5 | 59.2 | | ng/L | | 95 | 70 - 130 |
| Perfluorohexanesulfonic acid (PFHxS) | 3.3 | | 60.5 | 64.5 | | ng/L | | 101 | 70 - 130 |
| Perfluorohexanoic acid (PFHxA) | 3.6 | | 60.5 | 64.8 | | ng/L | | 101 | 70 - 130 |
| Perfluorononanoic acid (PFNA) | <2.0 | | 60.5 | 62.0 | | ng/L | | 103 | 70 - 130 |
| Perfluorooctanesulfonic acid (PFOS) | 4.4 | | 60.5 | 63.5 | | ng/L | | 98 | 70 - 130 |
| Perfluorooctanoic acid (PFOA) | 3.8 | | 60.5 | 62.7 | | ng/L | | 97 | 70 - 130 |
| Perfluoroundecanoic acid (PFUnA) | <2.0 | | 60.5 | 60.1 | | ng/L | | 99 | 70 - 130 |
| Perfluorobutanoic acid (PFBA) | <2.0 | | 60.5 | 60.9 | | ng/L | | 98 | 70 - 130 |
| 1H,1H,2H,2H-Perfluorodecane sulfonic acid (8:2 FTS) | <2.0 | | 60.5 | 60.6 | | ng/L | | 100 | 70 - 130 |
| 1H,1H,2H,2H-Perfluorohexane sulfonic acid (4:2 FTS) | <2.0 | | 60.5 | 62.4 | | ng/L | | 103 | 70 - 130 |
| 1H,1H,2H,2H-Perfluorooctane sulfonic acid (6:2 FTS) | <2.0 | | 60.5 | 61.4 | | ng/L | | 102 | 70 - 130 |
| Nonafluoro-3,6-dioxaheptanoic acid (NFDHA) | <2.0 | | 60.5 | 61.6 | | ng/L | | 102 | 70 - 130 |
| Perfluoro (2-ethoxyethane) sulfonic acid (PFEEESA) | <2.0 | | 60.5 | 57.1 | | ng/L | | 94 | 70 - 130 |
| Perfluoro-3-methoxypropanoic acid (PFMPA) | <2.0 | | 60.5 | 59.0 | | ng/L | | 98 | 70 - 130 |
| Perfluoro-4-methoxybutanoic acid (PFMBA) | <2.0 | | 60.5 | 55.7 | | ng/L | | 92 | 70 - 130 |
| Perfluoropentanoic acid (PFPeA) | 3.8 | | 60.5 | 60.5 | | ng/L | | 94 | 70 - 130 |
| Perfluoroheptanesulfonic acid (PFHpS) | <2.0 | | 60.5 | 61.7 | | ng/L | | 102 | 70 - 130 |
| Perfluoropentanesulfonic acid (PFPeS) | <2.0 | | 60.5 | 61.6 | | ng/L | | 101 | 70 - 130 |

| Isotope Dilution | MS MS | | Limits |
|------------------|-----------|-----------|----------|
| | %Recovery | Qualifier | |
| 13C3 HFPO-DA | 107 | | 50 - 200 |
| 13C6 PFDA | 113 | | 50 - 200 |
| 13C5 PFHxA | 105 | | 50 - 200 |
| 13C4 PFHpA | 113 | | 50 - 200 |
| 13C8 PFOA | 115 | | 50 - 200 |
| 13C9 PFNA | 113 | | 50 - 200 |
| 13C7 PFUnA | 112 | | 50 - 200 |
| 13C2 PFDoA | 114 | | 50 - 200 |
| 13C4 PFBA | 114 | | 50 - 200 |
| 13C5 PFPeA | 116 | | 50 - 200 |
| 13C3 PFBS | 110 | | 50 - 200 |
| 13C3 PFHxS | 113 | | 50 - 200 |
| 13C8 PFOS | 110 | | 50 - 200 |

QC Sample Results

Client: City & County of Honolulu
Project/Site: RED-HILL

Job ID: 380-174244-1
SDG: PFAS: Ka'amilo Wells P1/P2

Method: 533 - Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water (Continued)

Lab Sample ID: 380-174244-1 MS
Matrix: Water
Analysis Batch: 177605

Client Sample ID: Ka'amilo Wells P1
Prep Type: Total/NA
Prep Batch: 177489

| <i>Isotope Dilution</i> | <i>%Recovery</i> | <i>MS MS Qualifier</i> | <i>Limits</i> |
|-------------------------|------------------|------------------------|---------------|
| 13C2-4:2-FTS | 112 | | 50 - 200 |
| 13C2-6:2-FTS | 116 | | 50 - 200 |
| 13C2-8:2-FTS | 116 | | 50 - 200 |

Lab Sample ID: 380-174244-1 MSD
Matrix: Water
Analysis Batch: 177605

Client Sample ID: Ka'amilo Wells P1
Prep Type: Total/NA
Prep Batch: 177489

| Analyte | Sample Result | Sample Qualifier | Spike Added | MSD Result | MSD Qualifier | Unit | D | %Rec | %Rec Limits | RPD | RPD Limit |
|--|----------------------|-------------------------|--------------------|-------------------|----------------------|-------------|----------|-------------|--------------------|------------|------------------|
| 11-Chloroeicosafluoro-3-oxaundecane-1-sulfonic acid (11Cl-PF3OUdS) | <2.0 | | 60.5 | 61.6 | | ng/L | | 102 | 70 - 130 | 2 | 30 |
| 9-Chlorohexadecafluoro-3-oxanonane-1-sulfonic acid(9Cl-PF3ONS) | <2.0 | | 60.5 | 61.5 | | ng/L | | 102 | 70 - 130 | 1 | 30 |
| 4,8-Dioxa-3H-perfluorononanoic acid (ADONA) | <2.0 | | 60.5 | 53.5 | | ng/L | | 88 | 70 - 130 | 3 | 30 |
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX) | <2.0 | | 60.5 | 59.4 | | ng/L | | 98 | 70 - 130 | 4 | 30 |
| Perfluorobutanesulfonic acid (PFBS) | 3.2 | | 60.5 | 65.2 | | ng/L | | 103 | 70 - 130 | 0 | 30 |
| Perfluorodecanoic acid (PFDA) | <2.0 | | 60.5 | 58.2 | | ng/L | | 96 | 70 - 130 | 2 | 30 |
| Perfluorododecanoic acid (PFDoA) | <2.0 | | 60.5 | 58.1 | | ng/L | | 96 | 70 - 130 | 1 | 30 |
| Perfluoroheptanoic acid (PFHpA) | <2.0 | | 60.5 | 58.3 | | ng/L | | 94 | 70 - 130 | 2 | 30 |
| Perfluorohexanesulfonic acid (PFHxS) | 3.3 | | 60.5 | 63.3 | | ng/L | | 99 | 70 - 130 | 2 | 30 |
| Perfluorohexanoic acid (PFHxA) | 3.6 | | 60.5 | 67.0 | | ng/L | | 105 | 70 - 130 | 3 | 30 |
| Perfluorononanoic acid (PFNA) | <2.0 | | 60.5 | 61.7 | | ng/L | | 102 | 70 - 130 | 1 | 30 |
| Perfluorooctanesulfonic acid (PFOS) | 4.4 | | 60.5 | 65.6 | | ng/L | | 101 | 70 - 130 | 3 | 30 |
| Perfluorooctanoic acid (PFOA) | 3.8 | | 60.5 | 65.2 | | ng/L | | 102 | 70 - 130 | 4 | 30 |
| Perfluoroundecanoic acid (PFUnA) | <2.0 | | 60.5 | 62.1 | | ng/L | | 103 | 70 - 130 | 3 | 30 |
| Perfluorobutanoic acid (PFBA) | <2.0 | | 60.5 | 63.4 | | ng/L | | 102 | 70 - 130 | 4 | 30 |
| 1H,1H,2H,2H-Perfluorodecane sulfonic acid (8:2 FTS) | <2.0 | | 60.5 | 61.1 | | ng/L | | 101 | 70 - 130 | 1 | 30 |
| 1H,1H,2H,2H-Perfluorohexane sulfonic acid (4:2 FTS) | <2.0 | | 60.5 | 60.2 | | ng/L | | 99 | 70 - 130 | 4 | 30 |
| 1H,1H,2H,2H-Perfluorooctane sulfonic acid (6:2 FTS) | <2.0 | | 60.5 | 62.1 | | ng/L | | 103 | 70 - 130 | 1 | 30 |
| Nonafluoro-3,6-dioxaheptanoic acid (NFDHA) | <2.0 | | 60.5 | 64.0 | | ng/L | | 106 | 70 - 130 | 4 | 30 |
| Perfluoro (2-ethoxyethane) sulfonic acid (PFEEESA) | <2.0 | | 60.5 | 59.0 | | ng/L | | 97 | 70 - 130 | 3 | 30 |
| Perfluoro-3-methoxypropanoic acid (PFMPA) | <2.0 | | 60.5 | 59.0 | | ng/L | | 98 | 70 - 130 | 0 | 30 |
| Perfluoro-4-methoxybutanoic acid (PFMBA) | <2.0 | | 60.5 | 58.4 | | ng/L | | 97 | 70 - 130 | 5 | 30 |
| Perfluoropentanoic acid (PFPeA) | 3.8 | | 60.5 | 61.6 | | ng/L | | 96 | 70 - 130 | 2 | 30 |
| Perfluoroheptanesulfonic acid (PFHpS) | <2.0 | | 60.5 | 64.1 | | ng/L | | 106 | 70 - 130 | 4 | 30 |
| Perfluoropentanesulfonic acid (PFPeS) | <2.0 | | 60.5 | 61.0 | | ng/L | | 100 | 70 - 130 | 1 | 30 |

QC Sample Results

Client: City & County of Honolulu
Project/Site: RED-HILL

Job ID: 380-174244-1
SDG: PFAS: Ka'amilo Wells P1/P2

Method: 533 - Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water (Continued)

| Isotope Dilution | MSD MSD | | Limits |
|------------------|-----------|-----------|----------|
| | %Recovery | Qualifier | |
| 13C3 HFPO-DA | 103 | | 50 - 200 |
| 13C6 PFDA | 109 | | 50 - 200 |
| 13C5 PFHxA | 100 | | 50 - 200 |
| 13C4 PFHpA | 115 | | 50 - 200 |
| 13C8 PFOA | 110 | | 50 - 200 |
| 13C9 PFNA | 107 | | 50 - 200 |
| 13C7 PFUnA | 108 | | 50 - 200 |
| 13C2 PFDoA | 110 | | 50 - 200 |
| 13C4 PFBA | 112 | | 50 - 200 |
| 13C5 PFPeA | 113 | | 50 - 200 |
| 13C3 PFBS | 108 | | 50 - 200 |
| 13C3 PFHxS | 107 | | 50 - 200 |
| 13C8 PFOS | 106 | | 50 - 200 |
| 13C2-4:2-FTS | 110 | | 50 - 200 |
| 13C2-6:2-FTS | 109 | | 50 - 200 |
| 13C2-8:2-FTS | 113 | | 50 - 200 |

Method: 537.1 - Perfluorinated Alkyl Acids (LC/MS)

Lab Sample ID: MBL 380-177612/20-A
Matrix: Water
Analysis Batch: 177803

Client Sample ID: Method Blank
Prep Type: Total/NA
Prep Batch: 177612

| Analyte | MBL MBL | | RL | Unit | D | Prepared | Analyzed | Dil Fac |
|--|---------|-----------|-----|------|---|----------------|----------------|---------|
| | Result | Qualifier | | | | | | |
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX) | <1.0 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 15:44 | 1 |
| Perfluorooctanesulfonic acid (PFOS) | <0.43 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 15:44 | 1 |
| Perfluoroundecanoic acid (PFUnA) | <0.42 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 15:44 | 1 |
| N-methylperfluorooctanesulfonamidoacetic acid (NMeFOSAA) | <0.58 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 15:44 | 1 |
| N-ethylperfluorooctanesulfonamidoacetic acid (NEtFOSAA) | <0.42 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 15:44 | 1 |
| Perfluorohexanoic acid (PFHxA) | <0.46 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 15:44 | 1 |
| Perfluorododecanoic acid (PFDoA) | <0.54 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 15:44 | 1 |
| Perfluorooctanoic acid (PFOA) | <0.38 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 15:44 | 1 |
| Perfluorodecanoic acid (PFDA) | <0.31 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 15:44 | 1 |
| Perfluorohexanesulfonic acid (PFHxS) | <0.32 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 15:44 | 1 |
| Perfluorobutanesulfonic acid (PFBS) | <0.37 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 15:44 | 1 |
| Perfluoroheptanoic acid (PFHpA) | <0.39 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 15:44 | 1 |
| Perfluorononanoic acid (PFNA) | <0.40 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 15:44 | 1 |
| Perfluorotetradecanoic acid (PFTA) | <0.54 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 15:44 | 1 |
| Perfluorotridecanoic acid (PFTTrDA) | <0.36 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 15:44 | 1 |
| 9-Chlorohexadecafluoro-3-oxanonane-1-sulfonic acid(9Cl-PF3ONS) | <0.30 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 15:44 | 1 |
| 11-Chloroeicosafluoro-3-oxaundecane-1-sulfonic acid (11Cl-PF3OUdS) | <0.30 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 15:44 | 1 |
| 4,8-Dioxa-3H-perfluorononanoic acid (ADONA) | <0.60 | | 2.0 | ng/L | | 10/02/25 16:08 | 10/03/25 15:44 | 1 |

| Surrogate | MBL MBL | | Limits | Prepared | Analyzed | Dil Fac |
|-------------|-----------|-----------|----------|----------------|----------------|---------|
| | %Recovery | Qualifier | | | | |
| d5-NEtFOSAA | 102 | | 70 - 130 | 10/02/25 16:08 | 10/03/25 15:44 | 1 |
| 13C2 PFHxA | 114 | | 70 - 130 | 10/02/25 16:08 | 10/03/25 15:44 | 1 |
| 13C2 PFDA | 114 | | 70 - 130 | 10/02/25 16:08 | 10/03/25 15:44 | 1 |

Eurofins Eaton Analytical Pomona

QC Sample Results

Client: City & County of Honolulu
Project/Site: RED-HILL

Job ID: 380-174244-1
SDG: PFAS: Ka'amilo Wells P1/P2

Method: 537.1 - Perfluorinated Alkyl Acids (LC/MS) (Continued)

Lab Sample ID: MBL 380-177612/20-A
Matrix: Water
Analysis Batch: 177803

Client Sample ID: Method Blank
Prep Type: Total/NA
Prep Batch: 177612

| <i>Surrogate</i> | <i>MBL</i> | <i>MBL</i> | <i>Limits</i> | <i>Prepared</i> | <i>Analyzed</i> | <i>Dil Fac</i> |
|------------------|------------|------------|---------------|-----------------|-----------------|----------------|
| 13C3-GenX | 116 | Qualifier | 70 - 130 | 10/02/25 16:08 | 10/03/25 15:44 | 1 |

Lab Sample ID: LCS 380-177612/22-A
Matrix: Water
Analysis Batch: 177803

Client Sample ID: Lab Control Sample
Prep Type: Total/NA
Prep Batch: 177612

| <i>Analyte</i> | <i>Spike</i> | <i>LCS</i> | <i>LCS</i> | <i>Unit</i> | <i>D</i> | <i>%Rec</i> | <i>%Rec</i> |
|--|--------------|---------------|------------------|-------------|----------|-------------|---------------|
| <i>Analyte</i> | <i>Added</i> | <i>Result</i> | <i>Qualifier</i> | <i>Unit</i> | <i>D</i> | <i>%Rec</i> | <i>Limits</i> |
| Hexafluoropropylene Oxide | 25.1 | 25.3 | | ng/L | | 101 | 70 - 130 |
| Dimer Acid (HFPO-DA/GenX) | | | | | | | |
| Perfluorooctanesulfonic acid (PFOS) | 25.1 | 24.8 | | ng/L | | 99 | 70 - 130 |
| Perfluoroundecanoic acid (PFUnA) | 25.1 | 24.9 | | ng/L | | 99 | 70 - 130 |
| N-methylperfluorooctanesulfonamidoacetic acid (NMeFOSAA) | 25.1 | 24.5 | | ng/L | | 98 | 70 - 130 |
| N-ethylperfluorooctanesulfonamidoacetic acid (NEtFOSAA) | 25.1 | 23.5 | | ng/L | | 94 | 70 - 130 |
| Perfluorohexanoic acid (PFHxA) | 25.1 | 24.6 | | ng/L | | 98 | 70 - 130 |
| Perfluorododecanoic acid (PFDoA) | 25.1 | 23.7 | | ng/L | | 95 | 70 - 130 |
| Perfluorooctanoic acid (PFOA) | 25.1 | 25.0 | | ng/L | | 100 | 70 - 130 |
| Perfluorodecanoic acid (PFDA) | 25.1 | 24.5 | | ng/L | | 98 | 70 - 130 |
| Perfluorohexanesulfonic acid (PFHxS) | 25.1 | 24.6 | | ng/L | | 98 | 70 - 130 |
| Perfluorobutanesulfonic acid (PFBS) | 25.1 | 22.1 | | ng/L | | 88 | 70 - 130 |
| Perfluoroheptanoic acid (PFHpA) | 25.1 | 25.0 | | ng/L | | 100 | 70 - 130 |
| Perfluorononanoic acid (PFNA) | 25.1 | 24.9 | | ng/L | | 99 | 70 - 130 |
| Perfluorotetradecanoic acid (PFTA) | 25.1 | 25.9 | | ng/L | | 104 | 70 - 130 |
| Perfluorotridecanoic acid (PFTrDA) | 25.1 | 25.6 | | ng/L | | 102 | 70 - 130 |
| 9-Chlorohexadecafluoro-3-oxanonane-1-sulfonic acid(9Cl-PF3ONS) | 25.1 | 25.4 | | ng/L | | 101 | 70 - 130 |
| 11-Chloroeicosafluoro-3-oxaundecane-1-sulfonic acid (11Cl-PF3OUdS) | 25.1 | 24.7 | | ng/L | | 99 | 70 - 130 |
| 4,8-Dioxa-3H-perfluorononanoic acid (ADONA) | 25.1 | 25.0 | | ng/L | | 100 | 70 - 130 |

| <i>Surrogate</i> | <i>LCS</i> | <i>LCS</i> | <i>Limits</i> |
|------------------|------------------|------------------|---------------|
| <i>Surrogate</i> | <i>%Recovery</i> | <i>Qualifier</i> | <i>Limits</i> |
| d5-NEtFOSAA | 98 | | 70 - 130 |
| 13C2 PFHxA | 99 | | 70 - 130 |
| 13C2 PFDA | 99 | | 70 - 130 |
| 13C3-GenX | 110 | | 70 - 130 |

QC Sample Results

Client: City & County of Honolulu
Project/Site: RED-HILL

Job ID: 380-174244-1
SDG: PFAS: Ka'amilo Wells P1/P2

Method: 537.1 - Perfluorinated Alkyl Acids (LC/MS) (Continued)

Lab Sample ID: MRL 380-177612/21-A
Matrix: Water
Analysis Batch: 177803

Client Sample ID: Lab Control Sample
Prep Type: Total/NA
Prep Batch: 177612

| Analyte | Spike Added | MRL Result | MRL Qualifier | Unit | D | %Rec | %Rec Limits |
|--|-------------|------------|---------------|------|---|------|-------------|
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX) | 2.01 | 2.09 | J | ng/L | | 104 | 50 - 150 |
| Perfluorooctanesulfonic acid (PFOS) | 2.01 | 2.14 | J | ng/L | | 106 | 50 - 150 |
| Perfluoroundecanoic acid (PFUnA) | 2.01 | 2.08 | J | ng/L | | 103 | 50 - 150 |
| N-methylperfluorooctanesulfonamidoacetic acid (NMeFOSAA) | 2.01 | 2.20 | J | ng/L | | 109 | 50 - 150 |
| N-ethylperfluorooctanesulfonamidoacetic acid (NEtFOSAA) | 2.01 | 2.08 | J | ng/L | | 103 | 50 - 150 |
| Perfluorohexanoic acid (PFHxA) | 2.01 | 2.37 | J | ng/L | | 118 | 50 - 150 |
| Perfluorododecanoic acid (PFDoA) | 2.01 | 2.04 | J | ng/L | | 102 | 50 - 150 |
| Perfluorooctanoic acid (PFOA) | 2.01 | 2.09 | J | ng/L | | 104 | 50 - 150 |
| Perfluorodecanoic acid (PFDA) | 2.01 | 2.08 | J | ng/L | | 103 | 50 - 150 |
| Perfluorohexanesulfonic acid (PFHxS) | 2.01 | 2.29 | J | ng/L | | 114 | 50 - 150 |
| Perfluorobutanesulfonic acid (PFBS) | 2.01 | 2.27 | J | ng/L | | 113 | 50 - 150 |
| Perfluoroheptanoic acid (PFHpA) | 2.01 | 2.14 | J | ng/L | | 106 | 50 - 150 |
| Perfluorononanoic acid (PFNA) | 2.01 | 2.08 | J | ng/L | | 104 | 50 - 150 |
| Perfluorotetradecanoic acid (PFTA) | 2.01 | 2.06 | J | ng/L | | 102 | 50 - 150 |
| Perfluorotridecanoic acid (PFTrDA) | 2.01 | 2.20 | J | ng/L | | 109 | 50 - 150 |
| 9-Chlorohexadecafluoro-3-oxanonane-1-sulfonic acid(9Cl-PF3ONS) | 2.01 | 2.16 | J | ng/L | | 107 | 50 - 150 |
| 11-Chloroeicosafluoro-3-oxaundecane-1-sulfonic acid (11Cl-PF3OUdS) | 2.01 | 2.20 | J | ng/L | | 109 | 50 - 150 |
| 4,8-Dioxa-3H-perfluorononanoic acid (ADONA) | 2.01 | 2.01 | J | ng/L | | 100 | 50 - 150 |

| Surrogate | MRL %Recovery | MRL Qualifier | Limits |
|-------------|---------------|---------------|----------|
| d5-NEtFOSAA | 102 | | 70 - 130 |
| 13C2 PFHxA | 105 | | 70 - 130 |
| 13C2 PFDA | 98 | | 70 - 130 |
| 13C3-GenX | 102 | | 70 - 130 |

Lab Sample ID: 380-174242-A-1-B MS
Matrix: Water
Analysis Batch: 177803

Client Sample ID: Matrix Spike
Prep Type: Total/NA
Prep Batch: 177612

| Analyte | Sample Result | Sample Qualifier | Spike Added | MS Result | MS Qualifier | Unit | D | %Rec | %Rec Limits |
|--|---------------|------------------|-------------|-----------|--------------|------|---|------|-------------|
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX) | <2.0 | | 50.3 | 52.5 | | ng/L | | 104 | 70 - 130 |
| Perfluorooctanesulfonic acid (PFOS) | <2.0 | | 50.3 | 51.7 | | ng/L | | 103 | 70 - 130 |
| Perfluoroundecanoic acid (PFUnA) | <2.0 | | 50.3 | 47.0 | | ng/L | | 93 | 70 - 130 |
| N-methylperfluorooctanesulfonamidoacetic acid (NMeFOSAA) | <2.0 | | 50.3 | 45.5 | | ng/L | | 90 | 70 - 130 |

Eurofins Eaton Analytical Pomona

QC Association Summary

Client: City & County of Honolulu
 Project/Site: RED-HILL

Job ID: 380-174244-1
 SDG: PFAS: Ka'amilo Wells P1/P2

LCMS

Prep Batch: 177489

| Lab Sample ID | Client Sample ID | Prep Type | Matrix | Method | Prep Batch |
|---------------------|-----------------------|-----------|--------|--------|------------|
| 380-174244-1 | Ka'amilo Wells P1 | Total/NA | Water | 533 | |
| 380-174244-2 | Ka'amilo Wells P2 | Total/NA | Water | 533 | |
| 380-174244-3 | FB: Ka'amilo Wells P1 | Total/NA | Water | 533 | |
| 380-174244-4 | FB: Ka'amilo Wells P2 | Total/NA | Water | 533 | |
| MBL 380-177489/28-A | Method Blank | Total/NA | Water | 533 | |
| LCS 380-177489/30-A | Lab Control Sample | Total/NA | Water | 533 | |
| MRL 380-177489/29-A | Lab Control Sample | Total/NA | Water | 533 | |
| 380-174244-1 MS | Ka'amilo Wells P1 | Total/NA | Water | 533 | |
| 380-174244-1 MSD | Ka'amilo Wells P1 | Total/NA | Water | 533 | |

Analysis Batch: 177605

| Lab Sample ID | Client Sample ID | Prep Type | Matrix | Method | Prep Batch |
|---------------------|-----------------------|-----------|--------|--------|------------|
| 380-174244-1 | Ka'amilo Wells P1 | Total/NA | Water | 533 | 177489 |
| 380-174244-2 | Ka'amilo Wells P2 | Total/NA | Water | 533 | 177489 |
| 380-174244-3 | FB: Ka'amilo Wells P1 | Total/NA | Water | 533 | 177489 |
| 380-174244-4 | FB: Ka'amilo Wells P2 | Total/NA | Water | 533 | 177489 |
| MBL 380-177489/28-A | Method Blank | Total/NA | Water | 533 | 177489 |
| LCS 380-177489/30-A | Lab Control Sample | Total/NA | Water | 533 | 177489 |
| MRL 380-177489/29-A | Lab Control Sample | Total/NA | Water | 533 | 177489 |
| 380-174244-1 MS | Ka'amilo Wells P1 | Total/NA | Water | 533 | 177489 |
| 380-174244-1 MSD | Ka'amilo Wells P1 | Total/NA | Water | 533 | 177489 |

Prep Batch: 177612

| Lab Sample ID | Client Sample ID | Prep Type | Matrix | Method | Prep Batch |
|----------------------|------------------------|-----------|--------|----------|------------|
| 380-174244-1 | Ka'amilo Wells P1 | Total/NA | Water | 537.1 DW | |
| 380-174244-2 | Ka'amilo Wells P2 | Total/NA | Water | 537.1 DW | |
| 380-174244-3 | FB: Ka'amilo Wells P1 | Total/NA | Water | 537.1 DW | |
| 380-174244-4 | FB: Ka'amilo Wells P2 | Total/NA | Water | 537.1 DW | |
| MBL 380-177612/20-A | Method Blank | Total/NA | Water | 537.1 DW | |
| LCS 380-177612/22-A | Lab Control Sample | Total/NA | Water | 537.1 DW | |
| MRL 380-177612/21-A | Lab Control Sample | Total/NA | Water | 537.1 DW | |
| 380-174242-A-1-B MS | Matrix Spike | Total/NA | Water | 537.1 DW | |
| 380-174242-A-1-C MSD | Matrix Spike Duplicate | Total/NA | Water | 537.1 DW | |

Analysis Batch: 177803

| Lab Sample ID | Client Sample ID | Prep Type | Matrix | Method | Prep Batch |
|----------------------|------------------------|-----------|--------|--------|------------|
| 380-174244-1 | Ka'amilo Wells P1 | Total/NA | Water | 537.1 | 177612 |
| 380-174244-2 | Ka'amilo Wells P2 | Total/NA | Water | 537.1 | 177612 |
| 380-174244-3 | FB: Ka'amilo Wells P1 | Total/NA | Water | 537.1 | 177612 |
| 380-174244-4 | FB: Ka'amilo Wells P2 | Total/NA | Water | 537.1 | 177612 |
| MBL 380-177612/20-A | Method Blank | Total/NA | Water | 537.1 | 177612 |
| LCS 380-177612/22-A | Lab Control Sample | Total/NA | Water | 537.1 | 177612 |
| MRL 380-177612/21-A | Lab Control Sample | Total/NA | Water | 537.1 | 177612 |
| 380-174242-A-1-B MS | Matrix Spike | Total/NA | Water | 537.1 | 177612 |
| 380-174242-A-1-C MSD | Matrix Spike Duplicate | Total/NA | Water | 537.1 | 177612 |

Lab Chronicle

Client: City & County of Honolulu
 Project/Site: RED-HILL

Job ID: 380-174244-1
 SDG: PFAS: Ka'amilo Wells P1/P2

Client Sample ID: Ka'amilo Wells P1

Lab Sample ID: 380-174244-1

Date Collected: 09/29/25 11:47

Matrix: Water

Date Received: 10/01/25 10:00

| Prep Type | Batch Type | Batch Method | Run | Dilution Factor | Batch Number | Batch Analyst | Lab | Prepared or Analyzed |
|-----------|------------|--------------|-----|-----------------|--------------|---------------|--------|----------------------|
| Total/NA | Prep | 533 | | | 177489 | G9MN | EA POM | 10/02/25 03:37 |
| Total/NA | Analysis | 533 | | 1 | 177605 | Y5FM | EA POM | 10/02/25 17:22 |
| Total/NA | Prep | 537.1 DW | | | 177612 | N8NE | EA POM | 10/02/25 16:08 |
| Total/NA | Analysis | 537.1 | | 1 | 177803 | Y5FM | EA POM | 10/03/25 16:06 |

Client Sample ID: Ka'amilo Wells P2

Lab Sample ID: 380-174244-2

Date Collected: 09/29/25 12:32

Matrix: Water

Date Received: 10/01/25 10:00

| Prep Type | Batch Type | Batch Method | Run | Dilution Factor | Batch Number | Batch Analyst | Lab | Prepared or Analyzed |
|-----------|------------|--------------|-----|-----------------|--------------|---------------|--------|----------------------|
| Total/NA | Prep | 533 | | | 177489 | G9MN | EA POM | 10/02/25 03:37 |
| Total/NA | Analysis | 533 | | 1 | 177605 | Y5FM | EA POM | 10/02/25 22:13 |
| Total/NA | Prep | 537.1 DW | | | 177612 | N8NE | EA POM | 10/02/25 16:08 |
| Total/NA | Analysis | 537.1 | | 1 | 177803 | Y5FM | EA POM | 10/03/25 16:17 |

Client Sample ID: FB: Ka'amilo Wells P1

Lab Sample ID: 380-174244-3

Date Collected: 09/29/25 11:47

Matrix: Water

Date Received: 10/01/25 10:00

| Prep Type | Batch Type | Batch Method | Run | Dilution Factor | Batch Number | Batch Analyst | Lab | Prepared or Analyzed |
|-----------|------------|--------------|-----|-----------------|--------------|---------------|--------|----------------------|
| Total/NA | Prep | 533 | | | 177489 | G9MN | EA POM | 10/02/25 03:37 |
| Total/NA | Analysis | 533 | | 1 | 177605 | Y5FM | EA POM | 10/02/25 22:23 |
| Total/NA | Prep | 537.1 DW | | | 177612 | N8NE | EA POM | 10/02/25 16:08 |
| Total/NA | Analysis | 537.1 | | 1 | 177803 | Y5FM | EA POM | 10/03/25 16:27 |

Client Sample ID: FB: Ka'amilo Wells P2

Lab Sample ID: 380-174244-4

Date Collected: 09/29/25 12:32

Matrix: Water

Date Received: 10/01/25 10:00

| Prep Type | Batch Type | Batch Method | Run | Dilution Factor | Batch Number | Batch Analyst | Lab | Prepared or Analyzed |
|-----------|------------|--------------|-----|-----------------|--------------|---------------|--------|----------------------|
| Total/NA | Prep | 533 | | | 177489 | G9MN | EA POM | 10/02/25 03:37 |
| Total/NA | Analysis | 533 | | 1 | 177605 | Y5FM | EA POM | 10/02/25 22:34 |
| Total/NA | Prep | 537.1 DW | | | 177612 | N8NE | EA POM | 10/02/25 16:08 |
| Total/NA | Analysis | 537.1 | | 1 | 177803 | Y5FM | EA POM | 10/03/25 16:38 |

Laboratory References:

EA POM = Eurofins Eaton Analytical Pomona, 941 Corporate Center Drive, Pomona, CA 91768-2642, TEL (626)386-1100

Accreditation/Certification Summary

Client: City & County of Honolulu
Project/Site: RED-HILL

Job ID: 380-174244-1
SDG: PFAS: Ka'amilo Wells P1/P2

Laboratory: Eurofins Eaton Analytical Pomona

The accreditations/certifications listed below are applicable to this report.

| Authority | Program | Identification Number | Expiration Date |
|-----------|---------|-----------------------|-----------------|
| Hawaii | State | CA00006 | 01-31-26 |

- 1
- 2
- 3
- 4
- 5
- 6
- 7
- 8
- 9
- 10
- 11
- 12
- 13
- 14
- 15
- 16
- 17

Method Summary

Client: City & County of Honolulu
Project/Site: RED-HILL

Job ID: 380-174244-1
SDG: PFAS: Ka'amilo Wells P1/P2

| Method | Method Description | Protocol | Laboratory |
|----------|---|----------|------------|
| 533 | Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water | EPA | EA POM |
| 537.1 | Perfluorinated Alkyl Acids (LC/MS) | EPA | EA POM |
| 533 | Extraction of Perfluorinated and Polyfluorinated Alkyl Acids | EPA | EA POM |
| 537.1 DW | Extraction of Perfluorinated Alkyl Acids | EPA | EA POM |

Protocol References:

EPA = US Environmental Protection Agency

Laboratory References:

EA POM = Eurofins Eaton Analytical Pomona, 941 Corporate Center Drive, Pomona, CA 91768-2642, TEL (626)386-1100



Sample Summary

Client: City & County of Honolulu
Project/Site: RED-HILL

Job ID: 380-174244-1
SDG: PFAS: Ka'amilo Wells P1/P2

| Lab Sample ID | Client Sample ID | Matrix | Collected | Received | Sample Origin |
|---------------|-----------------------|--------|----------------|----------------|---------------|
| 380-174244-1 | Ka'amilo Wells P1 | Water | 09/29/25 11:47 | 10/01/25 10:00 | Hawaii |
| 380-174244-2 | Ka'amilo Wells P2 | Water | 09/29/25 12:32 | 10/01/25 10:00 | Hawaii |
| 380-174244-3 | FB: Ka'amilo Wells P1 | Water | 09/29/25 11:47 | 10/01/25 10:00 | Hawaii |
| 380-174244-4 | FB: Ka'amilo Wells P2 | Water | 09/29/25 12:32 | 10/01/25 10:00 | Hawaii |

- 1
- 2
- 3
- 4
- 5
- 6
- 7
- 8
- 9
- 10
- 11
- 12
- 13
- 14
- 15
- 16
- 17

Login Sample Receipt Checklist

Client: City & County of Honolulu

Job Number: 380-174244-1
SDG Number: PFAS: Ka'amilo Wells P1/P2

Login Number: 174244

List Number: 1

Creator: Segura, Ryan

List Source: Eurofins Eaton Analytical Pomona

| Question | Answer | Comment |
|--|--------|---------|
| The coolers custody seal, if present, is intact. | N/A | |
| Sample custody seals, if present, are intact. | N/A | |
| Samples were received on ice. | True | |
| Cooler(s) Temperature is acceptable. | True | |
| Cooler(s) Temperature is recorded. | True | |
| COC is present. | True | |
| COC is filled out in ink and is legible. | True | |
| COC is filled out with all pertinent information. | True | |
| There are no discrepancies between the containers received and the COC. | True | |
| Samples are received within Holding Time (excluding tests with immediate HTs) | True | |
| Sample containers have legible labels. | True | |
| Containers are not broken or leaking. | True | |
| Sample collection date/times are provided. | True | |
| There is sufficient vol. for all requested analyses, incl. any requested MS/MSDs | True | |
| Containers requiring zero headspace have no headspace or bubble is <6mm (1/4"). | True | |
| CIO4 headspace requirement met (>50% for CA, >30% for other states). | True | |
| Samples do not require splitting or compositing. | True | |
| Container provided by EEA | True | |

