

# ANALYTICAL REPORT

## PREPARED FOR

Attn: Mr. Erwin Kawata  
City & County of Honolulu  
630 South Beretania Street  
Public Service Bldg. Room 310  
Honolulu, Hawaii 96843

Generated 3/12/2025 5:42:54 PM

## JOB DESCRIPTION

RED-HILL  
Weekly PFAS

## JOB NUMBER

380-139320-1

# Eurofins Eaton Analytical Pomona

## Job Notes

This report may not be reproduced except in full, and with written approval from the laboratory. The results relate only to the samples tested. For questions please contact the Project Manager at the e-mail address or telephone number listed on this page.

The test results in this report relate only to the samples as received by the laboratory and meet all requirements of the methodology, with any exceptions noted. This report shall not be reproduced except in full, without the express written approval of the laboratory. All questions should be directed to the Eurofins Eaton Analytical, LLC Project Manager.

## Compliance Statement

1. Laboratory is accredited in accordance with TNI 2016 Standards and ISO/IEC 17025:2017.
2. Laboratory certifies that the test results meet all TNI 2016 and ISO/IEC 17025:2017 requirements unless noted under the individual analysis
3. Test results relate only to the sample(s) tested.
4. This report shall not be reproduced except in full, without the written approval of the laboratory.
5. Unless otherwise noted, all analytes for this laboratory were covered under each accreditation/certification below.  
(DW, Water matrices)

## Authorization



Generated  
3/12/2025 5:42:54 PM

Authorized for release by  
Rachelle Arada, Project Manager  
[Rachelle.Arada@et.eurofinsus.com](mailto:Rachelle.Arada@et.eurofinsus.com)  
(626)386-1106

# Table of Contents

Cover Page . . . . . 1

Table of Contents . . . . . 3

Definitions/Glossary . . . . . 4

Case Narrative . . . . . 5

Detection Summary . . . . . 6

Client Sample Results . . . . . 7

Action Limit Summary . . . . . 11

Surrogate Summary . . . . . 12

Isotope Dilution Summary . . . . . 13

QC Sample Results . . . . . 14

QC Association Summary . . . . . 25

Lab Chronicle . . . . . 26

Certification Summary . . . . . 27

Method Summary . . . . . 28

Sample Summary . . . . . 29

Chain of Custody . . . . . 30

Receipt Checklists . . . . . 31



# Definitions/Glossary

Client: City & County of Honolulu  
Project/Site: RED-HILL

Job ID: 380-139320-1  
SDG: Weekly PFAS

## Qualifiers

### LCMS

| Qualifier | Qualifier Description                                                                                          |
|-----------|----------------------------------------------------------------------------------------------------------------|
| J         | Result is less than the RL but greater than or equal to the MDL and the concentration is an approximate value. |

## Glossary

| Abbreviation   | These commonly used abbreviations may or may not be present in this report.                                 |
|----------------|-------------------------------------------------------------------------------------------------------------|
| ☼              | Listed under the "D" column to designate that the result is reported on a dry weight basis                  |
| %R             | Percent Recovery                                                                                            |
| CFL            | Contains Free Liquid                                                                                        |
| CFU            | Colony Forming Unit                                                                                         |
| CNF            | Contains No Free Liquid                                                                                     |
| DER            | Duplicate Error Ratio (normalized absolute difference)                                                      |
| Dil Fac        | Dilution Factor                                                                                             |
| DL             | Detection Limit (DoD/DOE)                                                                                   |
| DL, RA, RE, IN | Indicates a Dilution, Re-analysis, Re-extraction, or additional Initial metals/anion analysis of the sample |
| DLC            | Decision Level Concentration (Radiochemistry)                                                               |
| EDL            | Estimated Detection Limit (Dioxin)                                                                          |
| LOD            | Limit of Detection (DoD/DOE)                                                                                |
| LOQ            | Limit of Quantitation (DoD/DOE)                                                                             |
| MCL            | EPA recommended "Maximum Contaminant Level"                                                                 |
| MDA            | Minimum Detectable Activity (Radiochemistry)                                                                |
| MDC            | Minimum Detectable Concentration (Radiochemistry)                                                           |
| MDL            | Method Detection Limit                                                                                      |
| ML             | Minimum Level (Dioxin)                                                                                      |
| MPN            | Most Probable Number                                                                                        |
| MQL            | Method Quantitation Limit                                                                                   |
| NC             | Not Calculated                                                                                              |
| ND             | Not Detected at the reporting limit (or MDL or EDL if shown)                                                |
| NEG            | Negative / Absent                                                                                           |
| POS            | Positive / Present                                                                                          |
| PQL            | Practical Quantitation Limit                                                                                |
| PRES           | Presumptive                                                                                                 |
| QC             | Quality Control                                                                                             |
| RER            | Relative Error Ratio (Radiochemistry)                                                                       |
| RL             | Reporting Limit or Requested Limit (Radiochemistry)                                                         |
| RPD            | Relative Percent Difference, a measure of the relative difference between two points                        |
| TEF            | Toxicity Equivalent Factor (Dioxin)                                                                         |
| TEQ            | Toxicity Equivalent Quotient (Dioxin)                                                                       |
| TNTC           | Too Numerous To Count                                                                                       |

## Case Narrative

Client: City & County of Honolulu  
Project: RED-HILL

Job ID: 380-139320-1

**Job ID: 380-139320-1**

**Eurofins Eaton Analytical Pomona**

### **Job Narrative 380-139320-1**

Analytical test results meet all requirements of the associated regulatory program listed on the Accreditation/Certification Summary Page unless otherwise noted under the individual analysis. Data qualifiers and/or narrative comments are included to explain any exceptions, if applicable.

- Matrix QC may not be reported if insufficient sample is provided or site-specific QC samples were not submitted. In these situations, to demonstrate precision and accuracy at a batch level, a LCS/LCSD may be performed, unless otherwise specified in the method.
- Surrogate and/or isotope dilution analyte recoveries (if applicable) which are outside of the QC window are confirmed unless attributed to a dilution or otherwise noted in the narrative.

Regulated compliance samples (e.g. SDWA, NPDES) must comply with the associated agency requirements/permits.

#### **Receipt**

The samples were received on 3/6/2025 10:12 AM. Unless otherwise noted below, the samples arrived in good condition, and, where required, properly preserved and on ice. The temperatures of the 2 coolers at receipt time were 0.3°C and 0.4°C.

#### **PFAS**

No additional analytical or quality issues were noted, other than those described above or in the Definitions/ Glossary page.

Eurofins Eaton Analytical Pomona

## Detection Summary

Client: City & County of Honolulu  
Project/Site: RED-HILL

Job ID: 380-139320-1  
SDG: Weekly PFAS

### Client Sample ID: HALAWA SHAFT VIEWING POOL

Lab Sample ID: 380-139320-1

| Analyte                              | Result | Qualifier | RL  | Unit | Dil Fac | D | Method | Prep Type |
|--------------------------------------|--------|-----------|-----|------|---------|---|--------|-----------|
| Perfluorohexanesulfonic acid (PFHxS) | 3.6    |           | 2.0 | ng/L | 1       |   | 533    | Total/NA  |
| Perfluorooctanesulfonic acid (PFOS)  | 3.2    |           | 2.0 | ng/L | 1       |   | 533    | Total/NA  |
| Perfluorooctanesulfonic acid (PFOS)  | 3.6    |           | 2.0 | ng/L | 1       |   | 537.1  | Total/NA  |
| Perfluorohexanesulfonic acid (PFHxS) | 3.8    |           | 2.0 | ng/L | 1       |   | 537.1  | Total/NA  |

### Client Sample ID: FB: HALAWA SHAFT VIEWING POOL

Lab Sample ID: 380-139320-2

No Detections.

This Detection Summary does not include radiochemical test results.

Eurofins Eaton Analytical Pomona

# Client Sample Results

Client: City & County of Honolulu  
Project/Site: RED-HILL

Job ID: 380-139320-1  
SDG: Weekly PFAS

Client Sample ID: HALAWA SHAFT VIEWING POOL

Lab Sample ID: 380-139320-1

Date Collected: 03/04/25 10:00

Matrix: Water

Date Received: 03/06/25 10:12

## Method: EPA 533 - Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water

| Analyte                                                                | Result     | Qualifier | RL  | Unit | D | Prepared       | Analyzed       | Dil Fac |
|------------------------------------------------------------------------|------------|-----------|-----|------|---|----------------|----------------|---------|
| 11-Chloroeicosafluoro-3-oxaundecan<br>e-1-sulfonic acid (11Cl-PF3OUdS) | <2.0       |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| 9-Chlorohexadecafluoro-3-oxanonan<br>e-1-sulfonic acid(9Cl-PF3ONS)     | <2.0       |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| 4,8-Dioxa-3H-perfluorononanoic acid<br>(ADONA)                         | <2.0       |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| Hexafluoropropylene Oxide Dimer<br>Acid (HFPO-DA/GenX)                 | <2.0       |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| Perfluorobutanesulfonic acid (PFBS)                                    | <2.0       |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| Perfluorodecanoic acid (PFDA)                                          | <2.0       |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| Perfluorododecanoic acid (PFDoA)                                       | <2.0       |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| Perfluoroheptanoic acid (PFHpA)                                        | <2.0       |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| <b>Perfluorohexanesulfonic acid<br/>(PFHxS)</b>                        | <b>3.6</b> |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| Perfluorohexanoic acid (PFHxA)                                         | <2.0       |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| Perfluorononanoic acid (PFNA)                                          | <2.0       |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| <b>Perfluorooctanesulfonic acid<br/>(PFOS)</b>                         | <b>3.2</b> |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| Perfluorooctanoic acid (PFOA)                                          | <2.0       |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| Perfluoroundecanoic acid (PFUnA)                                       | <2.0       |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| Perfluorobutanoic acid (PFBA)                                          | <2.0       |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| 1H,1H,2H,2H-Perfluorodecane<br>sulfonic acid (8:2 FTS)                 | <2.0       |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| 1H,1H,2H,2H-Perfluorohexane<br>sulfonic acid (4:2 FTS)                 | <2.0       |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| 1H,1H,2H,2H-Perfluorooctane sulfonic<br>acid (6:2 FTS)                 | <2.0       |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| Nonafluoro-3,6-dioxaheptanoic acid<br>(NFDHA)                          | <2.0       |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| Perfluoro (2-ethoxyethane) sulfonic<br>acid (PFEEESA)                  | <2.0       |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| Perfluoro-3-methoxypropanoic acid<br>(PFMPA)                           | <2.0       |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| Perfluoro-4-methoxybutanoic acid<br>(PFMBA)                            | <2.0       |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| Perfluoropentanoic acid (PFPeA)                                        | <2.0       |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| Perfluoroheptanesulfonic acid<br>(PFHpS)                               | <2.0       |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| Perfluoropentanesulfonic acid<br>(PFPeS)                               | <2.0       |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:40 | 1       |

| Isotope Dilution | %Recovery | Qualifier | Limits   | Prepared       | Analyzed       | Dil Fac |
|------------------|-----------|-----------|----------|----------------|----------------|---------|
| 13C3 HFPO-DA     | 101       |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| 13C6 PFDA        | 102       |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| 13C5 PFHxA       | 96        |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| 13C4 PFHpA       | 105       |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| 13C8 PFOA        | 105       |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| 13C9 PFNA        | 105       |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| 13C7 PFUnA       | 103       |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| 13C2 PFDoA       | 98        |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| 13C4 PFBA        | 108       |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| 13C5 PFPeA       | 111       |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| 13C3 PFBS        | 104       |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| 13C3 PFHxS       | 102       |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:40 | 1       |

Eurofins Eaton Analytical Pomona

# Client Sample Results

Client: City & County of Honolulu  
Project/Site: RED-HILL

Job ID: 380-139320-1  
SDG: Weekly PFAS

Client Sample ID: HALAWA SHAFT VIEWING POOL

Lab Sample ID: 380-139320-1

Date Collected: 03/04/25 10:00

Matrix: Water

Date Received: 03/06/25 10:12

## Method: EPA 533 - Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water (Continued)

| Isotope Dilution | %Recovery | Qualifier | Limits   | Prepared       | Analyzed       | Dil Fac |
|------------------|-----------|-----------|----------|----------------|----------------|---------|
| 13C8 PFOS        | 113       |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| 13C2-4:2-FTS     | 147       |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| 13C2-6:2-FTS     | 140       |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:40 | 1       |
| 13C2-8:2-FTS     | 119       |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:40 | 1       |

## Method: EPA 537.1 - Perfluorinated Alkyl Acids (LC/MS)

| Analyte                                                            | Result     | Qualifier | RL  | Unit | D | Prepared       | Analyzed       | Dil Fac |
|--------------------------------------------------------------------|------------|-----------|-----|------|---|----------------|----------------|---------|
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX)                | <2.0       |           | 2.0 | ng/L |   | 03/08/25 13:49 | 03/10/25 06:56 | 1       |
| <b>Perfluorooctanesulfonic acid (PFOS)</b>                         | <b>3.6</b> |           | 2.0 | ng/L |   | 03/08/25 13:49 | 03/10/25 06:56 | 1       |
| Perfluoroundecanoic acid (PFUnA)                                   | <2.0       |           | 2.0 | ng/L |   | 03/08/25 13:49 | 03/10/25 06:56 | 1       |
| N-methylperfluorooctanesulfonamidoacetic acid (NMeFOSAA)           | <2.0       |           | 2.0 | ng/L |   | 03/08/25 13:49 | 03/10/25 06:56 | 1       |
| N-ethylperfluorooctanesulfonamidoacetic acid (NEtFOSAA)            | <2.0       |           | 2.0 | ng/L |   | 03/08/25 13:49 | 03/10/25 06:56 | 1       |
| Perfluorohexanoic acid (PFHxA)                                     | <2.0       |           | 2.0 | ng/L |   | 03/08/25 13:49 | 03/10/25 06:56 | 1       |
| Perfluorododecanoic acid (PFDoA)                                   | <2.0       |           | 2.0 | ng/L |   | 03/08/25 13:49 | 03/10/25 06:56 | 1       |
| Perfluorooctanoic acid (PFOA)                                      | <2.0       |           | 2.0 | ng/L |   | 03/08/25 13:49 | 03/10/25 06:56 | 1       |
| Perfluorodecanoic acid (PFDA)                                      | <2.0       |           | 2.0 | ng/L |   | 03/08/25 13:49 | 03/10/25 06:56 | 1       |
| <b>Perfluorohexanesulfonic acid (PFHxS)</b>                        | <b>3.8</b> |           | 2.0 | ng/L |   | 03/08/25 13:49 | 03/10/25 06:56 | 1       |
| Perfluorobutanesulfonic acid (PFBS)                                | <2.0       |           | 2.0 | ng/L |   | 03/08/25 13:49 | 03/10/25 06:56 | 1       |
| Perfluoroheptanoic acid (PFHpA)                                    | <2.0       |           | 2.0 | ng/L |   | 03/08/25 13:49 | 03/10/25 06:56 | 1       |
| Perfluorononanoic acid (PFNA)                                      | <2.0       |           | 2.0 | ng/L |   | 03/08/25 13:49 | 03/10/25 06:56 | 1       |
| Perfluorotetradecanoic acid (PFTA)                                 | <2.0       |           | 2.0 | ng/L |   | 03/08/25 13:49 | 03/10/25 06:56 | 1       |
| Perfluorotridecanoic acid (PFTrDA)                                 | <2.0       |           | 2.0 | ng/L |   | 03/08/25 13:49 | 03/10/25 06:56 | 1       |
| 9-Chlorohexadecafluoro-3-oxanonane-1-sulfonic acid (9Cl-PF3ONS)    | <2.0       |           | 2.0 | ng/L |   | 03/08/25 13:49 | 03/10/25 06:56 | 1       |
| 11-Chloroeicosafluoro-3-oxaundecane-1-sulfonic acid (11Cl-PF3OUdS) | <2.0       |           | 2.0 | ng/L |   | 03/08/25 13:49 | 03/10/25 06:56 | 1       |
| 4,8-Dioxa-3H-perfluorononanoic acid (ADONA)                        | <2.0       |           | 2.0 | ng/L |   | 03/08/25 13:49 | 03/10/25 06:56 | 1       |

| Surrogate   | %Recovery | Qualifier | Limits   | Prepared       | Analyzed       | Dil Fac |
|-------------|-----------|-----------|----------|----------------|----------------|---------|
| d5-NEtFOSAA | 115       |           | 70 - 130 | 03/08/25 13:49 | 03/10/25 06:56 | 1       |
| 13C2 PFHxA  | 117       |           | 70 - 130 | 03/08/25 13:49 | 03/10/25 06:56 | 1       |
| 13C2 PFDA   | 116       |           | 70 - 130 | 03/08/25 13:49 | 03/10/25 06:56 | 1       |
| 13C3-GenX   | 114       |           | 70 - 130 | 03/08/25 13:49 | 03/10/25 06:56 | 1       |

Client Sample ID: FB: HALAWA SHAFT VIEWING POOL

Lab Sample ID: 380-139320-2

Date Collected: 03/04/25 10:00

Matrix: Water

Date Received: 03/06/25 10:12

## Method: EPA 533 - Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water

| Analyte                                                            | Result | Qualifier | RL  | Unit | D | Prepared       | Analyzed       | Dil Fac |
|--------------------------------------------------------------------|--------|-----------|-----|------|---|----------------|----------------|---------|
| 11-Chloroeicosafluoro-3-oxaundecane-1-sulfonic acid (11Cl-PF3OUdS) | <2.0   |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| 9-Chlorohexadecafluoro-3-oxanonane-1-sulfonic acid (9Cl-PF3ONS)    | <2.0   |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| 4,8-Dioxa-3H-perfluorononanoic acid (ADONA)                        | <2.0   |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:49 | 1       |

Eurofins Eaton Analytical Pomona

# Client Sample Results

Client: City & County of Honolulu  
Project/Site: RED-HILL

Job ID: 380-139320-1  
SDG: Weekly PFAS

Client Sample ID: FB: HALAWA SHAFT VIEWING POOL

Lab Sample ID: 380-139320-2

Date Collected: 03/04/25 10:00

Matrix: Water

Date Received: 03/06/25 10:12

## Method: EPA 533 - Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water (Continued)

| Analyte                                             | Result | Qualifier | RL  | Unit | D | Prepared       | Analyzed       | Dil Fac |
|-----------------------------------------------------|--------|-----------|-----|------|---|----------------|----------------|---------|
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX) | <2.0   |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| Perfluorobutanesulfonic acid (PFBS)                 | <2.0   |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| Perfluorodecanoic acid (PFDA)                       | <2.0   |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| Perfluorododecanoic acid (PFDoA)                    | <2.0   |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| Perfluoroheptanoic acid (PFHpA)                     | <2.0   |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| Perfluorohexanesulfonic acid (PFHxS)                | <2.0   |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| Perfluorohexanoic acid (PFHxA)                      | <2.0   |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| Perfluorononanoic acid (PFNA)                       | <2.0   |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| Perfluorooctanesulfonic acid (PFOS)                 | <2.0   |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| Perfluorooctanoic acid (PFOA)                       | <2.0   |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| Perfluoroundecanoic acid (PFUnA)                    | <2.0   |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| Perfluorobutanoic acid (PFBA)                       | <2.0   |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| 1H,1H,2H,2H-Perfluorodecane sulfonic acid (8:2 FTS) | <2.0   |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| 1H,1H,2H,2H-Perfluorohexane sulfonic acid (4:2 FTS) | <2.0   |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| 1H,1H,2H,2H-Perfluorooctane sulfonic acid (6:2 FTS) | <2.0   |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| Nonafluoro-3,6-dioxaheptanoic acid (NFDHA)          | <2.0   |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| Perfluoro (2-ethoxyethane) sulfonic acid (PFEEESA)  | <2.0   |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| Perfluoro-3-methoxypropanoic acid (PFMPA)           | <2.0   |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| Perfluoro-4-methoxybutanoic acid (PFMBA)            | <2.0   |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| Perfluoropentanoic acid (PFPeA)                     | <2.0   |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| Perfluoroheptanesulfonic acid (PFHpS)               | <2.0   |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| Perfluoropentanesulfonic acid (PFPeS)               | <2.0   |           | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 19:49 | 1       |

| Isotope Dilution | %Recovery | Qualifier | Limits   | Prepared       | Analyzed       | Dil Fac |
|------------------|-----------|-----------|----------|----------------|----------------|---------|
| 13C3 HFPO-DA     | 97        |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| 13C6 PFDA        | 102       |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| 13C5 PFHxA       | 107       |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| 13C4 PFHpA       | 108       |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| 13C8 PFOA        | 104       |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| 13C9 PFNA        | 105       |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| 13C7 PFUnA       | 103       |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| 13C2 PFDoA       | 99        |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| 13C4 PFBA        | 105       |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| 13C5 PFPeA       | 105       |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| 13C3 PFBS        | 105       |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| 13C3 PFHxS       | 103       |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| 13C8 PFOS        | 111       |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| 13C2-4:2-FTS     | 135       |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| 13C2-6:2-FTS     | 131       |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:49 | 1       |
| 13C2-8:2-FTS     | 110       |           | 50 - 200 | 03/10/25 19:02 | 03/11/25 19:49 | 1       |

Eurofins Eaton Analytical Pomona

# Client Sample Results

Client: City & County of Honolulu  
Project/Site: RED-HILL

Job ID: 380-139320-1  
SDG: Weekly PFAS

Client Sample ID: FB: HALAWA SHAFT VIEWING POOL

Lab Sample ID: 380-139320-2

Date Collected: 03/04/25 10:00

Matrix: Water

Date Received: 03/06/25 10:12

## Method: EPA 537.1 - Perfluorinated Alkyl Acids (LC/MS)

| Analyte                                                            | Result    | Qualifier | RL       | Unit | D | Prepared       | Analyzed       | Dil Fac |
|--------------------------------------------------------------------|-----------|-----------|----------|------|---|----------------|----------------|---------|
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX)                | <2.0      |           | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 07:06 | 1       |
| Perfluorooctanesulfonic acid (PFOS)                                | <2.0      |           | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 07:06 | 1       |
| Perfluoroundecanoic acid (PFUnA)                                   | <2.0      |           | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 07:06 | 1       |
| N-methylperfluorooctanesulfonamidoacetic acid (NMeFOSAA)           | <2.0      |           | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 07:06 | 1       |
| N-ethylperfluorooctanesulfonamidoacetic acid (NEtFOSAA)            | <2.0      |           | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 07:06 | 1       |
| Perfluorohexanoic acid (PFHxA)                                     | <2.0      |           | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 07:06 | 1       |
| Perfluorododecanoic acid (PFDoA)                                   | <2.0      |           | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 07:06 | 1       |
| Perfluorooctanoic acid (PFOA)                                      | <2.0      |           | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 07:06 | 1       |
| Perfluorodecanoic acid (PFDA)                                      | <2.0      |           | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 07:06 | 1       |
| Perfluorohexanesulfonic acid (PFHxS)                               | <2.0      |           | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 07:06 | 1       |
| Perfluorobutanesulfonic acid (PFBS)                                | <2.0      |           | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 07:06 | 1       |
| Perfluoroheptanoic acid (PFHpA)                                    | <2.0      |           | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 07:06 | 1       |
| Perfluorononanoic acid (PFNA)                                      | <2.0      |           | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 07:06 | 1       |
| Perfluorotetradecanoic acid (PFTA)                                 | <2.0      |           | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 07:06 | 1       |
| Perfluorotridecanoic acid (PFTrDA)                                 | <2.0      |           | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 07:06 | 1       |
| 9-Chlorohexadecafluoro-3-oxanonane-1-sulfonic acid(9Cl-PF3ONS)     | <2.0      |           | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 07:06 | 1       |
| 11-Chloroeicosafluoro-3-oxaundecane-1-sulfonic acid (11Cl-PF3OUdS) | <2.0      |           | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 07:06 | 1       |
| 4,8-Dioxa-3H-perfluorononanoic acid (ADONA)                        | <2.0      |           | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 07:06 | 1       |
| Surrogate                                                          | %Recovery | Qualifier | Limits   |      |   | Prepared       | Analyzed       | Dil Fac |
| d5-NEtFOSAA                                                        | 112       |           | 70 - 130 |      |   | 03/08/25 13:49 | 03/10/25 07:06 | 1       |
| 13C2 PFHxA                                                         | 113       |           | 70 - 130 |      |   | 03/08/25 13:49 | 03/10/25 07:06 | 1       |
| 13C2 PFDA                                                          | 111       |           | 70 - 130 |      |   | 03/08/25 13:49 | 03/10/25 07:06 | 1       |
| 13C3-GenX                                                          | 108       |           | 70 - 130 |      |   | 03/08/25 13:49 | 03/10/25 07:06 | 1       |

# Action Limit Summary

Client: City & County of Honolulu  
Project/Site: RED-HILL

Job ID: 380-139320-1  
SDG: Weekly PFAS

Client Sample ID: HALAWA SHAFT VIEWING POOL

Lab Sample ID: 380-139320-1

## Compliance Check

The results obtained from the analytical testing of this data set were checked against compliance limits received from the client. Any results at or above the compliance limits have been highlighted for your convenience.

| Analyte                                             | Result | Qualifier | Unit | EPAMCL<br>Limit | RL  | Method | Prep Type |
|-----------------------------------------------------|--------|-----------|------|-----------------|-----|--------|-----------|
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX) | <2.0   |           | ng/L | 10              | 2.0 | 533    | Total/NA  |
| Perfluorohexanesulfonic acid (PFHxS)                | 3.6    |           | ng/L | 10              | 2.0 | 533    | Total/NA  |
| Perfluorononanoic acid (PFNA)                       | <2.0   |           | ng/L | 10              | 2.0 | 533    | Total/NA  |
| Perfluorooctanesulfonic acid (PFOS)                 | 3.2    |           | ng/L | 4               | 2.0 | 533    | Total/NA  |
| Perfluorooctanoic acid (PFOA)                       | <2.0   |           | ng/L | 4               | 2.0 | 533    | Total/NA  |
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX) | <2.0   |           | ng/L | 10              | 2.0 | 537.1  | Total/NA  |
| Perfluorooctanesulfonic acid (PFOS)                 | 3.6    |           | ng/L | 4               | 2.0 | 537.1  | Total/NA  |
| Perfluorooctanoic acid (PFOA)                       | <2.0   |           | ng/L | 4               | 2.0 | 537.1  | Total/NA  |
| Perfluorohexanesulfonic acid (PFHxS)                | 3.8    |           | ng/L | 10              | 2.0 | 537.1  | Total/NA  |
| Perfluorononanoic acid (PFNA)                       | <2.0   |           | ng/L | 10              | 2.0 | 537.1  | Total/NA  |

Client Sample ID: FB: HALAWA SHAFT VIEWING POOL

Lab Sample ID: 380-139320-2

## Compliance Check

The results obtained from the analytical testing of this data set were checked against compliance limits received from the client. Any results at or above the compliance limits have been highlighted for your convenience.

| Analyte                                             | Result | Qualifier | Unit | EPAMCL<br>Limit | RL  | Method | Prep Type |
|-----------------------------------------------------|--------|-----------|------|-----------------|-----|--------|-----------|
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX) | <2.0   |           | ng/L | 10              | 2.0 | 533    | Total/NA  |
| Perfluorohexanesulfonic acid (PFHxS)                | <2.0   |           | ng/L | 10              | 2.0 | 533    | Total/NA  |
| Perfluorononanoic acid (PFNA)                       | <2.0   |           | ng/L | 10              | 2.0 | 533    | Total/NA  |
| Perfluorooctanesulfonic acid (PFOS)                 | <2.0   |           | ng/L | 4               | 2.0 | 533    | Total/NA  |
| Perfluorooctanoic acid (PFOA)                       | <2.0   |           | ng/L | 4               | 2.0 | 533    | Total/NA  |
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX) | <2.0   |           | ng/L | 10              | 2.0 | 537.1  | Total/NA  |
| Perfluorooctanesulfonic acid (PFOS)                 | <2.0   |           | ng/L | 4               | 2.0 | 537.1  | Total/NA  |
| Perfluorooctanoic acid (PFOA)                       | <2.0   |           | ng/L | 4               | 2.0 | 537.1  | Total/NA  |
| Perfluorohexanesulfonic acid (PFHxS)                | <2.0   |           | ng/L | 10              | 2.0 | 537.1  | Total/NA  |
| Perfluorononanoic acid (PFNA)                       | <2.0   |           | ng/L | 10              | 2.0 | 537.1  | Total/NA  |

# Surrogate Summary

Client: City & County of Honolulu  
Project/Site: RED-HILL

Job ID: 380-139320-1  
SDG: Weekly PFAS

**Method: 537.1 - Perfluorinated Alkyl Acids (LC/MS)**

**Matrix: Water**

**Prep Type: Total/NA**

|                      |                                  | Percent Surrogate Recovery (Acceptance Limits) |                   |                  |                  |
|----------------------|----------------------------------|------------------------------------------------|-------------------|------------------|------------------|
| Lab Sample ID        | Client Sample ID                 | d5NEFOS<br>(70-130)                            | PFHxA<br>(70-130) | PFDA<br>(70-130) | GenX<br>(70-130) |
| 380-139166-A-1-B MS  | Matrix Spike                     | 114                                            | 111               | 110              | 106              |
| 380-139166-A-1-C MSD | Matrix Spike Duplicate           | 112                                            | 112               | 110              | 107              |
| 380-139320-1         | HALAWA SHAFT VIEWING<br>POOL     | 115                                            | 117               | 116              | 114              |
| 380-139320-2         | FB: HALAWA SHAFT VIEWING<br>POOL | 112                                            | 113               | 111              | 108              |
| LCS 380-140692/22-A  | Lab Control Sample               | 117                                            | 118               | 115              | 111              |
| MBL 380-140692/20-A  | Method Blank                     | 122                                            | 117               | 119              | 113              |
| MRL 380-140692/21-A  | Lab Control Sample               | 111                                            | 114               | 113              | 106              |

## Surrogate Legend

d5NEFOS = d5-NEtFOSAA

PFHxA = 13C2 PFHxA

PFDA = 13C2 PFDA

GenX = 13C3-GenX

# Isotope Dilution Summary

Client: City & County of Honolulu  
Project/Site: RED-HILL

Job ID: 380-139320-1  
SDG: Weekly PFAS

## Method: 533 - Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water

Matrix: Water

Prep Type: Total/NA

### Percent Isotope Dilution Recovery (Acceptance Limits)

| Lab Sample ID        | Client Sample ID                 | HFPODA<br>(50-200) | C6PFDA<br>(50-200) | 13C5PHA<br>(50-200) | C4PFHA<br>(50-200) | C8PFOA<br>(50-200) | C9PFNA<br>(50-200) | 13C7PUA<br>(50-200) | PFDaA<br>(50-200) |
|----------------------|----------------------------------|--------------------|--------------------|---------------------|--------------------|--------------------|--------------------|---------------------|-------------------|
| 380-139230-E-1-A MS  | Matrix Spike                     | 91                 | 102                | 96                  | 101                | 100                | 103                | 105                 | 100               |
| 380-139230-F-1-A MSD | Matrix Spike Duplicate           | 103                | 104                | 105                 | 107                | 108                | 107                | 106                 | 101               |
| 380-139320-1         | HALAWA SHAFT VIEWING<br>POOL     | 101                | 102                | 96                  | 105                | 105                | 105                | 103                 | 98                |
| 380-139320-2         | FB: HALAWA SHAFT VIEWING<br>POOL | 97                 | 102                | 107                 | 108                | 104                | 105                | 103                 | 99                |
| LCS 380-141021/22-A  | Lab Control Sample               | 88                 | 104                | 107                 | 104                | 107                | 104                | 103                 | 102               |
| MBL 380-141021/20-A  | Method Blank                     | 91                 | 104                | 109                 | 113                | 106                | 106                | 105                 | 102               |
| MRL 380-141021/21-A  | Lab Control Sample               | 102                | 104                | 111                 | 113                | 110                | 110                | 108                 | 104               |

### Percent Isotope Dilution Recovery (Acceptance Limits)

| Lab Sample ID        | Client Sample ID                 | PFBA<br>(50-200) | PFPeA<br>(50-200) | C3PFBS<br>(50-200) | C3PFHS<br>(50-200) | C8PFOS<br>(50-200) | 42FTS<br>(50-200) | 62FTS<br>(50-200) | 82FTS<br>(50-200) |
|----------------------|----------------------------------|------------------|-------------------|--------------------|--------------------|--------------------|-------------------|-------------------|-------------------|
| 380-139230-E-1-A MS  | Matrix Spike                     | 97               | 100               | 106                | 102                | 109                | 117               | 121               | 109               |
| 380-139230-F-1-A MSD | Matrix Spike Duplicate           | 109              | 108               | 106                | 105                | 111                | 119               | 120               | 110               |
| 380-139320-1         | HALAWA SHAFT VIEWING<br>POOL     | 108              | 111               | 104                | 102                | 113                | 147               | 140               | 119               |
| 380-139320-2         | FB: HALAWA SHAFT VIEWING<br>POOL | 105              | 105               | 105                | 103                | 111                | 135               | 131               | 110               |
| LCS 380-141021/22-A  | Lab Control Sample               | 108              | 109               | 104                | 102                | 109                | 124               | 123               | 106               |
| MBL 380-141021/20-A  | Method Blank                     | 108              | 109               | 107                | 103                | 112                | 128               | 129               | 113               |
| MRL 380-141021/21-A  | Lab Control Sample               | 110              | 111               | 109                | 108                | 114                | 127               | 133               | 115               |

### Surrogate Legend

HFPODA = 13C3 HFPO-DA  
C6PFDA = 13C6 PFDA  
13C5PHA = 13C5 PFHxA  
C4PFHA = 13C4 PFHpA  
C8PFOA = 13C8 PFOA  
C9PFNA = 13C9 PFNA  
13C7PUA = 13C7 PFUnA  
PFDaA = 13C2 PFDaA  
PFBA = 13C4 PFBA  
PFPeA = 13C5 PFPeA  
C3PFBS = 13C3 PFBS  
C3PFHS = 13C3 PFHxS  
C8PFOS = 13C8 PFOS  
42FTS = 13C2-4:2-FTS  
62FTS = 13C2-6:2-FTS  
82FTS = 13C2-8:2-FTS

# QC Sample Results

Client: City & County of Honolulu  
Project/Site: RED-HILL

Job ID: 380-139320-1  
SDG: Weekly PFAS

## Method: 533 - Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water

Lab Sample ID: MBL 380-141021/20-A

Matrix: Water

Analysis Batch: 141076

Client Sample ID: Method Blank

Prep Type: Total/NA

Prep Batch: 141021

| Analyte                                                                | MBL Result | MBL Qualifier | RL  | Unit | D | Prepared       | Analyzed       | Dil Fac |
|------------------------------------------------------------------------|------------|---------------|-----|------|---|----------------|----------------|---------|
| 11-Chloroeicosafluoro-3-oxaundecan<br>e-1-sulfonic acid (11Cl-PF3OUdS) | <0.30      |               | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| 9-Chlorohexadecafluoro-3-oxanonan<br>e-1-sulfonic acid(9Cl-PF3ONS)     | <0.30      |               | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| 4,8-Dioxa-3H-perfluorononanoic acid<br>(ADONA)                         | <0.60      |               | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| Hexafluoropropylene Oxide Dimer<br>Acid (HFPO-DA/GenX)                 | <1.0       |               | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| Perfluorobutanesulfonic acid (PFBS)                                    | <0.37      |               | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| Perfluorodecanoic acid (PFDA)                                          | <0.31      |               | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| Perfluorododecanoic acid (PFDoA)                                       | <0.54      |               | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| Perfluoroheptanoic acid (PFHpA)                                        | <0.39      |               | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| Perfluorohexanesulfonic acid (PFHxS)                                   | <0.32      |               | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| Perfluorohexanoic acid (PFHxA)                                         | <0.46      |               | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| Perfluorononanoic acid (PFNA)                                          | <0.40      |               | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| Perfluorooctanesulfonic acid (PFOS)                                    | <0.43      |               | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| Perfluorooctanoic acid (PFOA)                                          | <0.38      |               | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| Perfluoroundecanoic acid (PFUnA)                                       | <0.42      |               | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| Perfluorobutanoic acid (PFBA)                                          | <0.69      |               | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| 1H,1H,2H,2H-Perfluorodecane<br>sulfonic acid (8:2 FTS)                 | <0.38      |               | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| 1H,1H,2H,2H-Perfluorohexane<br>sulfonic acid (4:2 FTS)                 | <0.37      |               | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| 1H,1H,2H,2H-Perfluorooctane sulfonic<br>acid (6:2 FTS)                 | <0.48      |               | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| Nonafluoro-3,6-dioxaheptanoic acid<br>(NFDHA)                          | <0.47      |               | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| Perfluoro (2-ethoxyethane) sulfonic<br>acid (PFEEESA)                  | <0.25      |               | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| Perfluoro-3-methoxypropanoic acid<br>(PFMPA)                           | <0.46      |               | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| Perfluoro-4-methoxybutanoic acid<br>(PFMBA)                            | <0.15      |               | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| Perfluoropentanoic acid (PFPeA)                                        | <0.38      |               | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| Perfluoroheptanesulfonic acid<br>(PFHpS)                               | <0.36      |               | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| Perfluoropentanesulfonic acid<br>(PFPeS)                               | <0.39      |               | 2.0 | ng/L |   | 03/10/25 19:02 | 03/11/25 16:10 | 1       |

| Isotope Dilution | MBL %Recovery | MBL Qualifier | Limits   | Prepared       | Analyzed       | Dil Fac |
|------------------|---------------|---------------|----------|----------------|----------------|---------|
| 13C3 HFPO-DA     | 91            |               | 50 - 200 | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| 13C6 PFDA        | 104           |               | 50 - 200 | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| 13C5 PFHxA       | 109           |               | 50 - 200 | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| 13C4 PFHpA       | 113           |               | 50 - 200 | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| 13C8 PFOA        | 106           |               | 50 - 200 | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| 13C9 PFNA        | 106           |               | 50 - 200 | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| 13C7 PFUnA       | 105           |               | 50 - 200 | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| 13C2 PFDoA       | 102           |               | 50 - 200 | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| 13C4 PFBA        | 108           |               | 50 - 200 | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| 13C5 PFPeA       | 109           |               | 50 - 200 | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| 13C3 PFBS        | 107           |               | 50 - 200 | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| 13C3 PFHxS       | 103           |               | 50 - 200 | 03/10/25 19:02 | 03/11/25 16:10 | 1       |

Eurofins Eaton Analytical Pomona

# QC Sample Results

Client: City & County of Honolulu  
Project/Site: RED-HILL

Job ID: 380-139320-1  
SDG: Weekly PFAS

## Method: 533 - Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water (Continued)

Lab Sample ID: MBL 380-141021/20-A

Matrix: Water

Analysis Batch: 141076

Client Sample ID: Method Blank

Prep Type: Total/NA

Prep Batch: 141021

| Isotope Dilution | MBL %Recovery | MBL Qualifier | Limits   | Prepared       | Analyzed       | Dil Fac |
|------------------|---------------|---------------|----------|----------------|----------------|---------|
| 13C8 PFOS        | 112           |               | 50 - 200 | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| 13C2-4:2-FTS     | 128           |               | 50 - 200 | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| 13C2-6:2-FTS     | 129           |               | 50 - 200 | 03/10/25 19:02 | 03/11/25 16:10 | 1       |
| 13C2-8:2-FTS     | 113           |               | 50 - 200 | 03/10/25 19:02 | 03/11/25 16:10 | 1       |

Lab Sample ID: LCS 380-141021/22-A

Matrix: Water

Analysis Batch: 141076

Client Sample ID: Lab Control Sample

Prep Type: Total/NA

Prep Batch: 141021

| Analyte                                                           | Spike Added | LCS Result | LCS Qualifier | Unit | D | %Rec | %Rec Limits |
|-------------------------------------------------------------------|-------------|------------|---------------|------|---|------|-------------|
| 11-Chloroeicosfluoro-3-oxaundecane-1-sulfonic acid (11Cl-PF3OUdS) | 60.1        | 57.5       |               | ng/L |   | 96   | 70 - 130    |
| 9-Chlorohexadecafluoro-3-oxanonane-1-sulfonic acid (9Cl-PF3ONS)   | 60.1        | 54.9       |               | ng/L |   | 91   | 70 - 130    |
| 4,8-Dioxa-3H-perfluorononanoic acid (ADONA)                       | 60.1        | 64.7       |               | ng/L |   | 108  | 70 - 130    |
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX)               | 60.1        | 56.9       |               | ng/L |   | 95   | 70 - 130    |
| Perfluorobutanesulfonic acid (PFBS)                               | 60.1        | 60.6       |               | ng/L |   | 101  | 70 - 130    |
| Perfluorodecanoic acid (PFDA)                                     | 60.1        | 61.4       |               | ng/L |   | 102  | 70 - 130    |
| Perfluorododecanoic acid (PFDaA)                                  | 60.1        | 60.5       |               | ng/L |   | 101  | 70 - 130    |
| Perfluoroheptanoic acid (PFHpA)                                   | 60.1        | 62.3       |               | ng/L |   | 104  | 70 - 130    |
| Perfluorohexanesulfonic acid (PFHxS)                              | 60.1        | 60.2       |               | ng/L |   | 100  | 70 - 130    |
| Perfluorohexanoic acid (PFHxA)                                    | 60.1        | 59.7       |               | ng/L |   | 99   | 70 - 130    |
| Perfluorononanoic acid (PFNA)                                     | 60.1        | 63.8       |               | ng/L |   | 106  | 70 - 130    |
| Perfluorooctanesulfonic acid (PFOS)                               | 60.1        | 58.1       |               | ng/L |   | 97   | 70 - 130    |
| Perfluorooctanoic acid (PFOA)                                     | 60.1        | 61.5       |               | ng/L |   | 102  | 70 - 130    |
| Perfluoroundecanoic acid (PFUnA)                                  | 60.1        | 62.9       |               | ng/L |   | 105  | 70 - 130    |
| Perfluorobutanoic acid (PFBA)                                     | 60.1        | 62.0       |               | ng/L |   | 103  | 70 - 130    |
| 1H,1H,2H,2H-Perfluorodecane sulfonic acid (8:2 FTS)               | 60.1        | 64.6       |               | ng/L |   | 107  | 70 - 130    |
| 1H,1H,2H,2H-Perfluorohexane sulfonic acid (4:2 FTS)               | 60.1        | 64.8       |               | ng/L |   | 108  | 70 - 130    |
| 1H,1H,2H,2H-Perfluorooctane sulfonic acid (6:2 FTS)               | 60.1        | 63.0       |               | ng/L |   | 105  | 70 - 130    |
| Nonafluoro-3,6-dioxaheptanoic acid (NFDHA)                        | 60.1        | 53.8       |               | ng/L |   | 89   | 70 - 130    |
| Perfluoro (2-ethoxyethane) sulfonic acid (PFEESA)                 | 60.1        | 60.6       |               | ng/L |   | 101  | 70 - 130    |
| Perfluoro-3-methoxypropanoic acid (PFMPA)                         | 60.1        | 59.5       |               | ng/L |   | 99   | 70 - 130    |
| Perfluoro-4-methoxybutanoic acid (PFMBA)                          | 60.1        | 58.0       |               | ng/L |   | 96   | 70 - 130    |
| Perfluoropentanoic acid (PFPeA)                                   | 60.1        | 58.2       |               | ng/L |   | 97   | 70 - 130    |
| Perfluoroheptanesulfonic acid (PFHpS)                             | 60.1        | 56.7       |               | ng/L |   | 94   | 70 - 130    |

Eurofins Eaton Analytical Pomona

# QC Sample Results

Client: City & County of Honolulu  
Project/Site: RED-HILL

Job ID: 380-139320-1  
SDG: Weekly PFAS

## Method: 533 - Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water (Continued)

Lab Sample ID: LCS 380-141021/22-A

Matrix: Water

Analysis Batch: 141076

Client Sample ID: Lab Control Sample

Prep Type: Total/NA

Prep Batch: 141021

| Analyte                               | Spike Added | LCS Result | LCS Qualifier | Unit | D | %Rec | %Rec Limits |
|---------------------------------------|-------------|------------|---------------|------|---|------|-------------|
| Perfluoropentanesulfonic acid (PFPeS) | 60.1        | 61.8       |               | ng/L |   | 103  | 70 - 130    |
|                                       |             |            |               |      |   |      |             |
|                                       | LCS         | LCS        |               |      |   |      |             |
| Isotope Dilution                      | %Recovery   | Qualifier  | Limits        |      |   |      |             |
| 13C3 HFPO-DA                          | 88          |            | 50 - 200      |      |   |      |             |
| 13C6 PFDA                             | 104         |            | 50 - 200      |      |   |      |             |
| 13C5 PFHxA                            | 107         |            | 50 - 200      |      |   |      |             |
| 13C4 PFHpA                            | 104         |            | 50 - 200      |      |   |      |             |
| 13C8 PFOA                             | 107         |            | 50 - 200      |      |   |      |             |
| 13C9 PFNA                             | 104         |            | 50 - 200      |      |   |      |             |
| 13C7 PFUnA                            | 103         |            | 50 - 200      |      |   |      |             |
| 13C2 PFDoA                            | 102         |            | 50 - 200      |      |   |      |             |
| 13C4 PFBA                             | 108         |            | 50 - 200      |      |   |      |             |
| 13C5 PFPeA                            | 109         |            | 50 - 200      |      |   |      |             |
| 13C3 PFBS                             | 104         |            | 50 - 200      |      |   |      |             |
| 13C3 PFHxS                            | 102         |            | 50 - 200      |      |   |      |             |
| 13C8 PFOS                             | 109         |            | 50 - 200      |      |   |      |             |
| 13C2-4:2-FTS                          | 124         |            | 50 - 200      |      |   |      |             |
| 13C2-6:2-FTS                          | 123         |            | 50 - 200      |      |   |      |             |
| 13C2-8:2-FTS                          | 106         |            | 50 - 200      |      |   |      |             |

Lab Sample ID: MRL 380-141021/21-A

Matrix: Water

Analysis Batch: 141076

Client Sample ID: Lab Control Sample

Prep Type: Total/NA

Prep Batch: 141021

| Analyte                                                            | Spike Added | MRL Result | MRL Qualifier | Unit | D | %Rec | %Rec Limits |
|--------------------------------------------------------------------|-------------|------------|---------------|------|---|------|-------------|
| 11-Chloroeicosafluoro-3-oxaundecane-1-sulfonic acid (11Cl-PF3OUdS) | 2.00        | 1.98       | J             | ng/L |   | 99   | 50 - 150    |
| 9-Chlorohexadecafluoro-3-oxanonane-1-sulfonic acid (9Cl-PF3ONS)    | 2.00        | 1.78       | J             | ng/L |   | 89   | 50 - 150    |
| 4,8-Dioxa-3H-perfluorononanoic acid (ADONA)                        | 2.00        | 2.08       | J             | ng/L |   | 104  | 50 - 150    |
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX)                | 2.00        | 2.15       | J             | ng/L |   | 107  | 50 - 150    |
| Perfluorobutanesulfonic acid (PFBS)                                | 2.00        | 2.11       | J             | ng/L |   | 105  | 50 - 150    |
| Perfluorodecanoic acid (PFDA)                                      | 2.00        | 2.08       | J             | ng/L |   | 104  | 50 - 150    |
| Perfluorododecanoic acid (PFDoA)                                   | 2.00        | 2.10       | J             | ng/L |   | 105  | 50 - 150    |
| Perfluoroheptanoic acid (PFHpA)                                    | 2.00        | 2.09       | J             | ng/L |   | 104  | 50 - 150    |
| Perfluorohexanesulfonic acid (PFHxS)                               | 2.00        | 2.04       | J             | ng/L |   | 102  | 50 - 150    |
| Perfluorohexanoic acid (PFHxA)                                     | 2.00        | 2.06       | J             | ng/L |   | 103  | 50 - 150    |
| Perfluorononanoic acid (PFNA)                                      | 2.00        | 2.12       | J             | ng/L |   | 106  | 50 - 150    |
| Perfluorooctanesulfonic acid (PFOS)                                | 2.00        | 2.01       | J             | ng/L |   | 100  | 50 - 150    |
| Perfluorooctanoic acid (PFOA)                                      | 2.00        | 2.11       | J             | ng/L |   | 105  | 50 - 150    |
| Perfluoroundecanoic acid (PFUnA)                                   | 2.00        | 2.13       | J             | ng/L |   | 106  | 50 - 150    |
| Perfluorobutanoic acid (PFBA)                                      | 2.00        | 2.05       | J             | ng/L |   | 102  | 50 - 150    |

Eurofins Eaton Analytical Pomona

# QC Sample Results

Client: City & County of Honolulu  
Project/Site: RED-HILL

Job ID: 380-139320-1  
SDG: Weekly PFAS

## Method: 533 - Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water (Continued)

Lab Sample ID: MRL 380-141021/21-A

Matrix: Water

Analysis Batch: 141076

Client Sample ID: Lab Control Sample

Prep Type: Total/NA

Prep Batch: 141021

| Analyte                                             | Spike Added | MRL Result | MRL Qualifier | Unit | D | %Rec | %Rec Limits |
|-----------------------------------------------------|-------------|------------|---------------|------|---|------|-------------|
| 1H,1H,2H,2H-Perfluorodecane sulfonic acid (8:2 FTS) | 2.00        | 2.25       | J             | ng/L |   | 112  | 50 - 150    |
| 1H,1H,2H,2H-Perfluorohexane sulfonic acid (4:2 FTS) | 2.00        | 2.37       | J             | ng/L |   | 118  | 50 - 150    |
| 1H,1H,2H,2H-Perfluorooctane sulfonic acid (6:2 FTS) | 2.00        | 2.25       | J             | ng/L |   | 112  | 50 - 150    |
| Nonafluoro-3,6-dioxaheptanoic acid (NFDHA)          | 2.00        | 2.07       | J             | ng/L |   | 104  | 50 - 150    |
| Perfluoro (2-ethoxyethane) sulfonic acid (PFEESA)   | 2.00        | 1.80       | J             | ng/L |   | 90   | 50 - 150    |
| Perfluoro-3-methoxypropanoic acid (PFMPA)           | 2.00        | 2.06       | J             | ng/L |   | 103  | 50 - 150    |
| Perfluoro-4-methoxybutanoic acid (PFMBA)            | 2.00        | 1.96       | J             | ng/L |   | 98   | 50 - 150    |
| Perfluoropentanoic acid (PFPeA)                     | 2.00        | 2.08       | J             | ng/L |   | 104  | 50 - 150    |
| Perfluoroheptanesulfonic acid (PFHpS)               | 2.00        | 1.85       | J             | ng/L |   | 92   | 50 - 150    |
| Perfluoropentanesulfonic acid (PFPeS)               | 2.00        | 2.06       | J             | ng/L |   | 103  | 50 - 150    |

| Isotope Dilution | %Recovery | MRL Qualifier | MRL Limits |
|------------------|-----------|---------------|------------|
| 13C3 HFPO-DA     | 102       |               | 50 - 200   |
| 13C6 PFDA        | 104       |               | 50 - 200   |
| 13C5 PFHxA       | 111       |               | 50 - 200   |
| 13C4 PFHpA       | 113       |               | 50 - 200   |
| 13C8 PFOA        | 110       |               | 50 - 200   |
| 13C9 PFNA        | 110       |               | 50 - 200   |
| 13C7 PFUnA       | 108       |               | 50 - 200   |
| 13C2 PFDoA       | 104       |               | 50 - 200   |
| 13C4 PFBA        | 110       |               | 50 - 200   |
| 13C5 PFPeA       | 111       |               | 50 - 200   |
| 13C3 PFBS        | 109       |               | 50 - 200   |
| 13C3 PFHxS       | 108       |               | 50 - 200   |
| 13C8 PFOS        | 114       |               | 50 - 200   |
| 13C2-4:2-FTS     | 127       |               | 50 - 200   |
| 13C2-6:2-FTS     | 133       |               | 50 - 200   |
| 13C2-8:2-FTS     | 115       |               | 50 - 200   |

Lab Sample ID: 380-139230-E-1-A MS

Matrix: Water

Analysis Batch: 141076

Client Sample ID: Matrix Spike

Prep Type: Total/NA

Prep Batch: 141021

| Analyte                                                            | Sample Result | Sample Qualifier | Spike Added | MS Result | MS Qualifier | Unit | D | %Rec | %Rec Limits |
|--------------------------------------------------------------------|---------------|------------------|-------------|-----------|--------------|------|---|------|-------------|
| 11-Chloroeicosafluoro-3-oxaundecane-1-sulfonic acid (11Cl-PF3OUdS) | <2.0          |                  | 121         | 115       |              | ng/L |   | 95   | 70 - 130    |
| 9-Chlorohexadecafluoro-3-oxanonane-1-sulfonic acid(9Cl-PF3ONS)     | <2.0          |                  | 121         | 114       |              | ng/L |   | 94   | 70 - 130    |
| 4,8-Dioxa-3H-perfluorononanoic acid (ADONA)                        | <2.0          |                  | 121         | 115       |              | ng/L |   | 95   | 70 - 130    |

Eurofins Eaton Analytical Pomona

# QC Sample Results

Client: City & County of Honolulu  
Project/Site: RED-HILL

Job ID: 380-139320-1  
SDG: Weekly PFAS

## Method: 533 - Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water (Continued)

Lab Sample ID: 380-139230-E-1-A MS

Matrix: Water

Analysis Batch: 141076

Client Sample ID: Matrix Spike

Prep Type: Total/NA

Prep Batch: 141021

| Analyte                                             | Sample Result | Sample Qualifier | Spike Added | MS Result | MS Qualifier | Unit | D | %Rec | %Rec Limits |
|-----------------------------------------------------|---------------|------------------|-------------|-----------|--------------|------|---|------|-------------|
| Hexafluoropropylene Oxide                           | <2.0          |                  | 121         | 116       |              | ng/L |   | 96   | 70 - 130    |
| Dimer Acid (HFPO-DA/GenX)                           |               |                  |             |           |              |      |   |      |             |
| Perfluorobutanesulfonic acid (PFBS)                 | <2.0          |                  | 121         | 118       |              | ng/L |   | 97   | 70 - 130    |
| Perfluorodecanoic acid (PFDA)                       | <2.0          |                  | 121         | 123       |              | ng/L |   | 102  | 70 - 130    |
| Perfluorododecanoic acid (PFDoA)                    | <2.0          |                  | 121         | 120       |              | ng/L |   | 99   | 70 - 130    |
| Perfluoroheptanoic acid (PFHpA)                     | <2.0          |                  | 121         | 119       |              | ng/L |   | 99   | 70 - 130    |
| Perfluorohexanesulfonic acid (PFHxS)                | <2.0          |                  | 121         | 120       |              | ng/L |   | 100  | 70 - 130    |
| Perfluorohexanoic acid (PFHxA)                      | <2.0          |                  | 121         | 125       |              | ng/L |   | 104  | 70 - 130    |
| Perfluorononanoic acid (PFNA)                       | <2.0          |                  | 121         | 122       |              | ng/L |   | 101  | 70 - 130    |
| Perfluorooctanesulfonic acid (PFOS)                 | <2.0          |                  | 121         | 115       |              | ng/L |   | 95   | 70 - 130    |
| Perfluorooctanoic acid (PFOA)                       | <2.0          |                  | 121         | 123       |              | ng/L |   | 102  | 70 - 130    |
| Perfluoroundecanoic acid (PFUnA)                    | <2.0          |                  | 121         | 122       |              | ng/L |   | 101  | 70 - 130    |
| Perfluorobutanoic acid (PFBA)                       | <2.0          |                  | 121         | 120       |              | ng/L |   | 100  | 70 - 130    |
| 1H,1H,2H,2H-Perfluorodecane sulfonic acid (8:2 FTS) | <2.0          |                  | 121         | 122       |              | ng/L |   | 101  | 70 - 130    |
| 1H,1H,2H,2H-Perfluorohexane sulfonic acid (4:2 FTS) | <2.0          |                  | 121         | 128       |              | ng/L |   | 106  | 70 - 130    |
| 1H,1H,2H,2H-Perfluorooctane sulfonic acid (6:2 FTS) | <2.0          |                  | 121         | 116       |              | ng/L |   | 96   | 70 - 130    |
| Nonafluoro-3,6-dioxahexanoic acid (NFDHA)           | <2.0          |                  | 121         | 124       |              | ng/L |   | 103  | 70 - 130    |
| Perfluoro (2-ethoxyethane) sulfonic acid (PFEEESA)  | <2.0          |                  | 121         | 121       |              | ng/L |   | 100  | 70 - 130    |
| Perfluoro-3-methoxypropanoic acid (PFMPA)           | <2.0          |                  | 121         | 117       |              | ng/L |   | 97   | 70 - 130    |
| Perfluoro-4-methoxybutanoic acid (PFMBA)            | <2.0          |                  | 121         | 113       |              | ng/L |   | 94   | 70 - 130    |
| Perfluoropentanoic acid (PFPeA)                     | <2.0          |                  | 121         | 116       |              | ng/L |   | 96   | 70 - 130    |
| Perfluoroheptanesulfonic acid (PFHpS)               | <2.0          |                  | 121         | 112       |              | ng/L |   | 93   | 70 - 130    |
| Perfluoropentanesulfonic acid (PFPeS)               | <2.0          |                  | 121         | 120       |              | ng/L |   | 99   | 70 - 130    |

| Isotope Dilution | MS %Recovery | MS Qualifier | Limits   |
|------------------|--------------|--------------|----------|
| 13C3 HFPO-DA     | 91           |              | 50 - 200 |
| 13C6 PFDA        | 102          |              | 50 - 200 |
| 13C5 PFHxA       | 96           |              | 50 - 200 |
| 13C4 PFHpA       | 101          |              | 50 - 200 |
| 13C8 PFOA        | 100          |              | 50 - 200 |
| 13C9 PFNA        | 103          |              | 50 - 200 |
| 13C7 PFUnA       | 105          |              | 50 - 200 |
| 13C2 PFDoA       | 100          |              | 50 - 200 |
| 13C4 PFBA        | 97           |              | 50 - 200 |
| 13C5 PFPeA       | 100          |              | 50 - 200 |
| 13C3 PFBS        | 106          |              | 50 - 200 |
| 13C3 PFHxS       | 102          |              | 50 - 200 |
| 13C8 PFOS        | 109          |              | 50 - 200 |

Eurofins Eaton Analytical Pomona

# QC Sample Results

Client: City & County of Honolulu  
Project/Site: RED-HILL

Job ID: 380-139320-1  
SDG: Weekly PFAS

## Method: 533 - Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water (Continued)

Lab Sample ID: 380-139230-E-1-A MS

Matrix: Water

Analysis Batch: 141076

Client Sample ID: Matrix Spike

Prep Type: Total/NA

Prep Batch: 141021

| Isotope Dilution | MS<br>%Recovery | MS<br>Qualifier | Limits   |
|------------------|-----------------|-----------------|----------|
| 13C2-4:2-FTS     | 117             |                 | 50 - 200 |
| 13C2-6:2-FTS     | 121             |                 | 50 - 200 |
| 13C2-8:2-FTS     | 109             |                 | 50 - 200 |

Lab Sample ID: 380-139230-F-1-A MSD

Matrix: Water

Analysis Batch: 141076

Client Sample ID: Matrix Spike Duplicate

Prep Type: Total/NA

Prep Batch: 141021

| Analyte                                                           | Sample<br>Result | Sample<br>Qualifier | Spike<br>Added | MSD<br>Result | MSD<br>Qualifier | Unit | D | %Rec | %Rec<br>Limits | RPD | RPD<br>Limit |
|-------------------------------------------------------------------|------------------|---------------------|----------------|---------------|------------------|------|---|------|----------------|-----|--------------|
| 11-Chloroeicosfluoro-3-oxaundecane-1-sulfonic acid (11Cl-PF3OUdS) | <2.0             |                     | 121            | 111           |                  | ng/L |   | 92   | 70 - 130       | 3   | 30           |
| 9-Chlorohexadecafluoro-3-oxanonane-1-sulfonic acid (9Cl-PF3ONS)   | <2.0             |                     | 121            | 111           |                  | ng/L |   | 92   | 70 - 130       | 2   | 30           |
| 4,8-Dioxa-3H-perfluorononanoic acid (ADONA)                       | <2.0             |                     | 121            | 122           |                  | ng/L |   | 101  | 70 - 130       | 6   | 30           |
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX)               | <2.0             |                     | 121            | 114           |                  | ng/L |   | 95   | 70 - 130       | 2   | 30           |
| Perfluorobutanesulfonic acid (PFBS)                               | <2.0             |                     | 121            | 121           |                  | ng/L |   | 100  | 70 - 130       | 3   | 30           |
| Perfluorodecanoic acid (PFDA)                                     | <2.0             |                     | 121            | 122           |                  | ng/L |   | 101  | 70 - 130       | 1   | 30           |
| Perfluorododecanoic acid (PFDaA)                                  | <2.0             |                     | 121            | 117           |                  | ng/L |   | 97   | 70 - 130       | 2   | 30           |
| Perfluoroheptanoic acid (PFHpA)                                   | <2.0             |                     | 121            | 121           |                  | ng/L |   | 100  | 70 - 130       | 1   | 30           |
| Perfluorohexanesulfonic acid (PFHxS)                              | <2.0             |                     | 121            | 117           |                  | ng/L |   | 97   | 70 - 130       | 3   | 30           |
| Perfluorohexanoic acid (PFHxA)                                    | <2.0             |                     | 121            | 121           |                  | ng/L |   | 100  | 70 - 130       | 3   | 30           |
| Perfluorononanoic acid (PFNA)                                     | <2.0             |                     | 121            | 121           |                  | ng/L |   | 100  | 70 - 130       | 1   | 30           |
| Perfluorooctanesulfonic acid (PFOS)                               | <2.0             |                     | 121            | 115           |                  | ng/L |   | 95   | 70 - 130       | 0   | 30           |
| Perfluorooctanoic acid (PFOA)                                     | <2.0             |                     | 121            | 120           |                  | ng/L |   | 99   | 70 - 130       | 3   | 30           |
| Perfluoroundecanoic acid (PFUnA)                                  | <2.0             |                     | 121            | 124           |                  | ng/L |   | 103  | 70 - 130       | 2   | 30           |
| Perfluorobutanoic acid (PFBA)                                     | <2.0             |                     | 121            | 120           |                  | ng/L |   | 99   | 70 - 130       | 1   | 30           |
| 1H,1H,2H,2H-Perfluorodecane sulfonic acid (8:2 FTS)               | <2.0             |                     | 121            | 123           |                  | ng/L |   | 102  | 70 - 130       | 1   | 30           |
| 1H,1H,2H,2H-Perfluorohexane sulfonic acid (4:2 FTS)               | <2.0             |                     | 121            | 118           |                  | ng/L |   | 98   | 70 - 130       | 8   | 30           |
| 1H,1H,2H,2H-Perfluorooctane sulfonic acid (6:2 FTS)               | <2.0             |                     | 121            | 121           |                  | ng/L |   | 100  | 70 - 130       | 4   | 30           |
| Nonafluoro-3,6-dioxaheptanoic acid (NFDHA)                        | <2.0             |                     | 121            | 126           |                  | ng/L |   | 104  | 70 - 130       | 1   | 30           |
| Perfluoro (2-ethoxyethane) sulfonic acid (PFEEA)                  | <2.0             |                     | 121            | 120           |                  | ng/L |   | 100  | 70 - 130       | 0   | 30           |
| Perfluoro-3-methoxypropanoic acid (PFMPA)                         | <2.0             |                     | 121            | 116           |                  | ng/L |   | 96   | 70 - 130       | 0   | 30           |
| Perfluoro-4-methoxybutanoic acid (PFMBA)                          | <2.0             |                     | 121            | 115           |                  | ng/L |   | 95   | 70 - 130       | 1   | 30           |
| Perfluoropentanoic acid (PFPeA)                                   | <2.0             |                     | 121            | 119           |                  | ng/L |   | 99   | 70 - 130       | 3   | 30           |
| Perfluoroheptanesulfonic acid (PFHpS)                             | <2.0             |                     | 121            | 113           |                  | ng/L |   | 94   | 70 - 130       | 1   | 30           |
| Perfluoropentanesulfonic acid (PFPeS)                             | <2.0             |                     | 121            | 118           |                  | ng/L |   | 98   | 70 - 130       | 2   | 30           |

Eurofins Eaton Analytical Pomona

# QC Sample Results

Client: City & County of Honolulu  
Project/Site: RED-HILL

Job ID: 380-139320-1  
SDG: Weekly PFAS

## Method: 533 - Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water (Continued)

| Isotope Dilution | MSD<br>%Recovery | MSD<br>Qualifier | Limits   |
|------------------|------------------|------------------|----------|
| 13C3 HFPO-DA     | 103              |                  | 50 - 200 |
| 13C6 PFDA        | 104              |                  | 50 - 200 |
| 13C5 PFHxA       | 105              |                  | 50 - 200 |
| 13C4 PFHpA       | 107              |                  | 50 - 200 |
| 13C8 PFOA        | 108              |                  | 50 - 200 |
| 13C9 PFNA        | 107              |                  | 50 - 200 |
| 13C7 PFUnA       | 106              |                  | 50 - 200 |
| 13C2 PFDoA       | 101              |                  | 50 - 200 |
| 13C4 PFBA        | 109              |                  | 50 - 200 |
| 13C5 PFPeA       | 108              |                  | 50 - 200 |
| 13C3 PFBS        | 106              |                  | 50 - 200 |
| 13C3 PFHxS       | 105              |                  | 50 - 200 |
| 13C8 PFOS        | 111              |                  | 50 - 200 |
| 13C2-4:2-FTS     | 119              |                  | 50 - 200 |
| 13C2-6:2-FTS     | 120              |                  | 50 - 200 |
| 13C2-8:2-FTS     | 110              |                  | 50 - 200 |

## Method: 537.1 - Perfluorinated Alkyl Acids (LC/MS)

Lab Sample ID: MBL 380-140692/20-A  
Matrix: Water  
Analysis Batch: 140731

Client Sample ID: Method Blank  
Prep Type: Total/NA  
Prep Batch: 140692

| Analyte                                                            | MBL<br>Result    | MBL<br>Qualifier | RL       | Unit | D | Prepared       | Analyzed       | Dil Fac |
|--------------------------------------------------------------------|------------------|------------------|----------|------|---|----------------|----------------|---------|
| Hexafluoropropylene Oxide Dimer<br>Acid (HFPO-DA/GenX)             | <1.0             |                  | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 03:10 | 1       |
| Perfluorooctanesulfonic acid (PFOS)                                | <0.43            |                  | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 03:10 | 1       |
| Perfluoroundecanoic acid (PFUnA)                                   | <0.42            |                  | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 03:10 | 1       |
| N-methylperfluorooctanesulfonamidoacetic acid (NMeFOSAA)           | <0.58            |                  | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 03:10 | 1       |
| N-ethylperfluorooctanesulfonamidoacetic acid (NEtFOSAA)            | <0.42            |                  | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 03:10 | 1       |
| Perfluorohexanoic acid (PFHxA)                                     | <0.46            |                  | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 03:10 | 1       |
| Perfluorododecanoic acid (PFDoA)                                   | <0.54            |                  | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 03:10 | 1       |
| Perfluorooctanoic acid (PFOA)                                      | <0.38            |                  | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 03:10 | 1       |
| Perfluorodecanoic acid (PFDA)                                      | <0.31            |                  | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 03:10 | 1       |
| Perfluorohexanesulfonic acid (PFHxS)                               | <0.32            |                  | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 03:10 | 1       |
| Perfluorobutanesulfonic acid (PFBS)                                | <0.37            |                  | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 03:10 | 1       |
| Perfluoroheptanoic acid (PFHpA)                                    | <0.39            |                  | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 03:10 | 1       |
| Perfluorononanoic acid (PFNA)                                      | <0.40            |                  | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 03:10 | 1       |
| Perfluorotetradecanoic acid (PFTA)                                 | <0.54            |                  | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 03:10 | 1       |
| Perfluorotridecanoic acid (PFTrDA)                                 | <0.36            |                  | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 03:10 | 1       |
| 9-Chlorohexadecafluoro-3-oxanonane-1-sulfonic acid(9Cl-PF3ONS)     | <0.30            |                  | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 03:10 | 1       |
| 11-Chloroeicosafluoro-3-oxaundecane-1-sulfonic acid (11Cl-PF3OUdS) | <0.30            |                  | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 03:10 | 1       |
| 4,8-Dioxa-3H-perfluorononanoic acid (ADONA)                        | <0.60            |                  | 2.0      | ng/L |   | 03/08/25 13:49 | 03/10/25 03:10 | 1       |
| Surrogate                                                          | MBL<br>%Recovery | MBL<br>Qualifier | Limits   |      |   | Prepared       | Analyzed       | Dil Fac |
| d5-NEtFOSAA                                                        | 122              |                  | 70 - 130 |      |   | 03/08/25 13:49 | 03/10/25 03:10 | 1       |
| 13C2 PFHxA                                                         | 117              |                  | 70 - 130 |      |   | 03/08/25 13:49 | 03/10/25 03:10 | 1       |
| 13C2 PFDA                                                          | 119              |                  | 70 - 130 |      |   | 03/08/25 13:49 | 03/10/25 03:10 | 1       |

Eurofins Eaton Analytical Pomona

# QC Sample Results

Client: City & County of Honolulu  
Project/Site: RED-HILL

Job ID: 380-139320-1  
SDG: Weekly PFAS

## Method: 537.1 - Perfluorinated Alkyl Acids (LC/MS) (Continued)

Lab Sample ID: MBL 380-140692/20-A

Matrix: Water

Analysis Batch: 140731

Client Sample ID: Method Blank

Prep Type: Total/NA

Prep Batch: 140692

| Surrogate | MBL %Recovery | MBL Qualifier | Limits   | Prepared       | Analyzed       | Dil Fac |
|-----------|---------------|---------------|----------|----------------|----------------|---------|
| 13C3-GenX | 113           |               | 70 - 130 | 03/08/25 13:49 | 03/10/25 03:10 | 1       |

Lab Sample ID: LCS 380-140692/22-A

Matrix: Water

Analysis Batch: 140731

Client Sample ID: Lab Control Sample

Prep Type: Total/NA

Prep Batch: 140692

| Analyte                                                            | Spike Added | LCS Result | LCS Qualifier | Unit | D | %Rec | %Rec Limits |
|--------------------------------------------------------------------|-------------|------------|---------------|------|---|------|-------------|
| Hexafluoropropylene Oxide                                          | 50.0        | 51.8       |               | ng/L |   | 104  | 70 - 130    |
| Dimer Acid (HFPO-DA/GenX)                                          |             |            |               |      |   |      |             |
| Perfluorooctanesulfonic acid (PFOS)                                | 50.0        | 56.0       |               | ng/L |   | 112  | 70 - 130    |
| Perfluoroundecanoic acid (PFUnA)                                   | 50.0        | 55.8       |               | ng/L |   | 112  | 70 - 130    |
| N-methylperfluorooctanesulfonamidoacetic acid (NMeFOSAA)           | 50.0        | 53.6       |               | ng/L |   | 107  | 70 - 130    |
| N-ethylperfluorooctanesulfonamidoacetic acid (NEtFOSAA)            | 50.0        | 55.9       |               | ng/L |   | 112  | 70 - 130    |
| Perfluorohexanoic acid (PFHxA)                                     | 50.0        | 54.6       |               | ng/L |   | 109  | 70 - 130    |
| Perfluorododecanoic acid (PFDoA)                                   | 50.0        | 54.2       |               | ng/L |   | 108  | 70 - 130    |
| Perfluorooctanoic acid (PFOA)                                      | 50.0        | 56.0       |               | ng/L |   | 112  | 70 - 130    |
| Perfluorodecanoic acid (PFDA)                                      | 50.0        | 55.3       |               | ng/L |   | 111  | 70 - 130    |
| Perfluorohexanesulfonic acid (PFHxS)                               | 50.0        | 54.8       |               | ng/L |   | 110  | 70 - 130    |
| Perfluorobutanesulfonic acid (PFBS)                                | 50.0        | 53.6       |               | ng/L |   | 107  | 70 - 130    |
| Perfluoroheptanoic acid (PFHpA)                                    | 50.0        | 56.1       |               | ng/L |   | 112  | 70 - 130    |
| Perfluorononanoic acid (PFNA)                                      | 50.0        | 57.2       |               | ng/L |   | 114  | 70 - 130    |
| Perfluorotetradecanoic acid (PFTA)                                 | 50.0        | 57.0       |               | ng/L |   | 114  | 70 - 130    |
| Perfluorotridecanoic acid (PFTrDA)                                 | 50.0        | 55.4       |               | ng/L |   | 111  | 70 - 130    |
| 9-Chlorohexadecafluoro-3-oxanonane-1-sulfonic acid(9Cl-PF3ONS)     | 50.0        | 53.1       |               | ng/L |   | 106  | 70 - 130    |
| 11-Chloroeicosafluoro-3-oxaundecane-1-sulfonic acid (11Cl-PF3OUdS) | 50.0        | 57.9       |               | ng/L |   | 116  | 70 - 130    |
| 4,8-Dioxa-3H-perfluorononanoic acid (ADONA)                        | 50.0        | 54.5       |               | ng/L |   | 109  | 70 - 130    |

| Surrogate   | LCS %Recovery | LCS Qualifier | Limits   |
|-------------|---------------|---------------|----------|
| d5-NEtFOSAA | 117           |               | 70 - 130 |
| 13C2 PFHxA  | 118           |               | 70 - 130 |
| 13C2 PFDA   | 115           |               | 70 - 130 |
| 13C3-GenX   | 111           |               | 70 - 130 |

# QC Sample Results

Client: City & County of Honolulu  
Project/Site: RED-HILL

Job ID: 380-139320-1  
SDG: Weekly PFAS

## Method: 537.1 - Perfluorinated Alkyl Acids (LC/MS) (Continued)

Lab Sample ID: MRL 380-140692/21-A

Matrix: Water

Analysis Batch: 140731

Client Sample ID: Lab Control Sample

Prep Type: Total/NA

Prep Batch: 140692

| Analyte                                                            | Spike Added | MRL Result | MRL Qualifier | Unit | D | %Rec | %Rec Limits |
|--------------------------------------------------------------------|-------------|------------|---------------|------|---|------|-------------|
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX)                | 2.00        | 2.03       | J             | ng/L |   | 101  | 50 - 150    |
| Perfluorooctanesulfonic acid (PFOS)                                | 2.00        | 2.27       | J             | ng/L |   | 113  | 50 - 150    |
| Perfluoroundecanoic acid (PFUnA)                                   | 2.00        | 2.16       | J             | ng/L |   | 108  | 50 - 150    |
| N-methylperfluorooctanesulfonamidoacetic acid (NMeFOSAA)           | 2.00        | 2.17       | J             | ng/L |   | 108  | 50 - 150    |
| N-ethylperfluorooctanesulfonamidoacetic acid (NEtFOSAA)            | 2.00        | 2.16       | J             | ng/L |   | 108  | 50 - 150    |
| Perfluorohexanoic acid (PFHxA)                                     | 2.00        | 2.23       | J             | ng/L |   | 111  | 50 - 150    |
| Perfluorododecanoic acid (PFDoA)                                   | 2.00        | 2.17       | J             | ng/L |   | 108  | 50 - 150    |
| Perfluorooctanoic acid (PFOA)                                      | 2.00        | 2.24       | J             | ng/L |   | 112  | 50 - 150    |
| Perfluorodecanoic acid (PFDA)                                      | 2.00        | 2.22       | J             | ng/L |   | 111  | 50 - 150    |
| Perfluorohexanesulfonic acid (PFHxS)                               | 2.00        | 2.11       | J             | ng/L |   | 105  | 50 - 150    |
| Perfluorobutanesulfonic acid (PFBS)                                | 2.00        | 2.02       | J             | ng/L |   | 101  | 50 - 150    |
| Perfluoroheptanoic acid (PFHpA)                                    | 2.00        | 2.20       | J             | ng/L |   | 110  | 50 - 150    |
| Perfluorononanoic acid (PFNA)                                      | 2.00        | 2.15       | J             | ng/L |   | 107  | 50 - 150    |
| Perfluorotetradecanoic acid (PFTA)                                 | 2.00        | 2.47       | J             | ng/L |   | 123  | 50 - 150    |
| Perfluorotridecanoic acid (PFTrDA)                                 | 2.00        | 2.20       | J             | ng/L |   | 110  | 50 - 150    |
| 9-Chlorohexadecafluoro-3-oxanonane-1-sulfonic acid(9Cl-PF3ONS)     | 2.00        | 2.13       | J             | ng/L |   | 106  | 50 - 150    |
| 11-Chloroeicosafluoro-3-oxaundecane-1-sulfonic acid (11Cl-PF3OUdS) | 2.00        | 2.23       | J             | ng/L |   | 111  | 50 - 150    |
| 4,8-Dioxa-3H-perfluorononanoic acid (ADONA)                        | 2.00        | 2.15       | J             | ng/L |   | 107  | 50 - 150    |

| Surrogate   | MRL %Recovery | MRL Qualifier | Limits   |
|-------------|---------------|---------------|----------|
| d5-NEtFOSAA | 111           |               | 70 - 130 |
| 13C2 PFHxA  | 114           |               | 70 - 130 |
| 13C2 PFDA   | 113           |               | 70 - 130 |
| 13C3-GenX   | 106           |               | 70 - 130 |

Lab Sample ID: 380-139166-A-1-B MS

Matrix: Water

Analysis Batch: 140731

Client Sample ID: Matrix Spike

Prep Type: Total/NA

Prep Batch: 140692

| Analyte                                                  | Sample Result | Sample Qualifier | Spike Added | MS Result | MS Qualifier | Unit | D | %Rec | %Rec Limits |
|----------------------------------------------------------|---------------|------------------|-------------|-----------|--------------|------|---|------|-------------|
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX)      | <2.0          |                  | 25.1        | 26.6      |              | ng/L |   | 106  | 70 - 130    |
| Perfluorooctanesulfonic acid (PFOS)                      | <2.0          |                  | 25.1        | 28.7      |              | ng/L |   | 114  | 70 - 130    |
| Perfluoroundecanoic acid (PFUnA)                         | <2.0          |                  | 25.1        | 28.4      |              | ng/L |   | 113  | 70 - 130    |
| N-methylperfluorooctanesulfonamidoacetic acid (NMeFOSAA) | <2.0          |                  | 25.1        | 28.3      |              | ng/L |   | 113  | 70 - 130    |

Eurofins Eaton Analytical Pomona

# QC Sample Results

Client: City & County of Honolulu  
Project/Site: RED-HILL

Job ID: 380-139320-1  
SDG: Weekly PFAS

## Method: 537.1 - Perfluorinated Alkyl Acids (LC/MS) (Continued)

Lab Sample ID: 380-139166-A-1-B MS

Matrix: Water

Analysis Batch: 140731

Client Sample ID: Matrix Spike

Prep Type: Total/NA

Prep Batch: 140692

| MS/MS Data - PFOS                                                         |           |           |          |        |           |      |   |        |          |
|---------------------------------------------------------------------------|-----------|-----------|----------|--------|-----------|------|---|--------|----------|
| Analyte                                                                   | Sample    | Sample    | Spike    | MS     | MS        | Unit | D | %Rec   | %Rec     |
|                                                                           | Result    | Qualifier | Added    | Result | Qualifier |      |   | Limits | Limits   |
| N-ethylperfluorooctanesulfonami<br>doacetic acid (NEtFOSAA)               | <2.0      |           | 25.1     | 28.9   |           | ng/L |   | 115    | 70 - 130 |
| Perfluorohexanoic acid (PFHxA)                                            | <2.0      |           | 25.1     | 29.0   |           | ng/L |   | 115    | 70 - 130 |
| Perfluorododecanoic acid<br>(PFDoA)                                       | <2.0      |           | 25.1     | 27.3   |           | ng/L |   | 109    | 70 - 130 |
| Perfluorooctanoic acid (PFOA)                                             | <2.0      |           | 25.1     | 28.7   |           | ng/L |   | 114    | 70 - 130 |
| Perfluorodecanoic acid (PFDA)                                             | <2.0      |           | 25.1     | 28.1   |           | ng/L |   | 112    | 70 - 130 |
| Perfluorohexanesulfonic acid<br>(PFHxS)                                   | <2.0      |           | 25.1     | 27.7   |           | ng/L |   | 110    | 70 - 130 |
| Perfluorobutanesulfonic acid<br>(PFBS)                                    | <2.0      |           | 25.1     | 27.8   |           | ng/L |   | 111    | 70 - 130 |
| Perfluoroheptanoic acid (PFHpA)                                           | <2.0      |           | 25.1     | 28.8   |           | ng/L |   | 115    | 70 - 130 |
| Perfluorononanoic acid (PFNA)                                             | <2.0      |           | 25.1     | 28.5   |           | ng/L |   | 113    | 70 - 130 |
| Perfluorotetradecanoic acid<br>(PFTA)                                     | <2.0      |           | 25.1     | 29.8   |           | ng/L |   | 119    | 70 - 130 |
| Perfluorotridecanoic acid<br>(PFTrDA)                                     | <2.0      |           | 25.1     | 28.7   |           | ng/L |   | 114    | 70 - 130 |
| 9-Chlorohexadecafluoro-3-oxan<br>onane-1-sulfonic<br>acid(9Cl-PF3ONS)     | <2.0      |           | 25.1     | 27.1   |           | ng/L |   | 108    | 70 - 130 |
| 11-Chloroeicosafluoro-3-oxaund<br>ecane-1-sulfonic acid<br>(11Cl-PF3OUdS) | <2.0      |           | 25.1     | 28.5   |           | ng/L |   | 114    | 70 - 130 |
| 4,8-Dioxa-3H-perfluorononanoic<br>acid (ADONA)                            | <2.0      |           | 25.1     | 28.0   |           | ng/L |   | 112    | 70 - 130 |
|                                                                           |           |           |          |        |           |      |   |        |          |
|                                                                           | MS        | MS        |          |        |           |      |   |        |          |
| Surrogate                                                                 | %Recovery | Qualifier | Limits   |        |           |      |   |        |          |
| d5-NEtFOSAA                                                               | 114       |           | 70 - 130 |        |           |      |   |        |          |
| 13C2 PFHxA                                                                | 111       |           | 70 - 130 |        |           |      |   |        |          |
| 13C2 PFDA                                                                 | 110       |           | 70 - 130 |        |           |      |   |        |          |
| 13C3-GenX                                                                 | 106       |           | 70 - 130 |        |           |      |   |        |          |

Lab Sample ID: 380-139166-A-1-C MSD

Matrix: Water

Analysis Batch: 140731

Client Sample ID: Matrix Spike Duplicate

Prep Type: Total/NA

Prep Batch: 140692

| Analyte                                                  | Sample Result | Sample Qualifier | Spike Added | MSD Result | MSD Qualifier | Unit | D | %Rec | %Rec Limits | RPD | Limit |
|----------------------------------------------------------|---------------|------------------|-------------|------------|---------------|------|---|------|-------------|-----|-------|
| Hexafluoropropylene Oxide Dimer Acid (HFPO-DA/GenX)      | <2.0          |                  | 25.1        | 26.6       |               | ng/L |   | 106  | 70 - 130    | 0   | 30    |
| Perfluorooctanesulfonic acid (PFOS)                      | <2.0          |                  | 25.1        | 28.4       |               | ng/L |   | 113  | 70 - 130    | 1   | 30    |
| Perfluoroundecanoic acid (PFUnA)                         | <2.0          |                  | 25.1        | 28.5       |               | ng/L |   | 114  | 70 - 130    | 0   | 30    |
| N-methylperfluorooctanesulfonamidoacetic acid (NMeFOSAA) | <2.0          |                  | 25.1        | 27.8       |               | ng/L |   | 111  | 70 - 130    | 2   | 30    |
| N-ethylperfluorooctanesulfonamidoacetic acid (NEtFOSAA)  | <2.0          |                  | 25.1        | 28.1       |               | ng/L |   | 112  | 70 - 130    | 3   | 30    |
| Perfluorohexanoic acid (PFHxA)                           | <2.0          |                  | 25.1        | 27.9       |               | ng/L |   | 111  | 70 - 130    | 4   | 30    |
| Perfluorododecanoic acid (PFDoA)                         | <2.0          |                  | 25.1        | 26.8       |               | ng/L |   | 107  | 70 - 130    | 2   | 30    |
| Perfluorooctanoic acid (PFOA)                            | <2.0          |                  | 25.1        | 28.1       |               | ng/L |   | 112  | 70 - 130    | 2   | 30    |
| Perfluorodecanoic acid (PFDA)                            | <2.0          |                  | 25.1        | 28.0       |               | ng/L |   | 112  | 70 - 130    | 0   | 30    |

Eurofins Eaton Analytical Pomona

# QC Sample Results

Client: City & County of Honolulu  
Project/Site: RED-HILL

Job ID: 380-139320-1  
SDG: Weekly PFAS

## Method: 537.1 - Perfluorinated Alkyl Acids (LC/MS) (Continued)

Lab Sample ID: 380-139166-A-1-C MSD

Matrix: Water

Analysis Batch: 140731

Client Sample ID: Matrix Spike Duplicate

Prep Type: Total/NA

Prep Batch: 140692

| Analyte                                                            | Sample Result | Sample Qualifier | Spike Added | MSD Result | MSD Qualifier | Unit | D | %Rec | %Rec Limits | RPD | RPD Limit |
|--------------------------------------------------------------------|---------------|------------------|-------------|------------|---------------|------|---|------|-------------|-----|-----------|
| Perfluorohexanesulfonic acid (PFHxS)                               | <2.0          |                  | 25.1        | 28.2       |               | ng/L |   | 113  | 70 - 130    | 2   | 30        |
| Perfluorobutanesulfonic acid (PFBS)                                | <2.0          |                  | 25.1        | 27.5       |               | ng/L |   | 110  | 70 - 130    | 1   | 30        |
| Perfluoroheptanoic acid (PFHpA)                                    | <2.0          |                  | 25.1        | 28.2       |               | ng/L |   | 113  | 70 - 130    | 2   | 30        |
| Perfluorononanoic acid (PFNA)                                      | <2.0          |                  | 25.1        | 28.4       |               | ng/L |   | 113  | 70 - 130    | 0   | 30        |
| Perfluorotetradecanoic acid (PFTA)                                 | <2.0          |                  | 25.1        | 30.1       |               | ng/L |   | 120  | 70 - 130    | 1   | 30        |
| Perfluorotridecanoic acid (PFTTrDA)                                | <2.0          |                  | 25.1        | 28.3       |               | ng/L |   | 113  | 70 - 130    | 1   | 30        |
| 9-Chlorohexadecafluoro-3-oxanonane-1-sulfonic acid(9Cl-PF3ONS)     | <2.0          |                  | 25.1        | 26.5       |               | ng/L |   | 106  | 70 - 130    | 2   | 30        |
| 11-Chloroeicosafluoro-3-oxaundecane-1-sulfonic acid (11Cl-PF3OUdS) | <2.0          |                  | 25.1        | 29.8       |               | ng/L |   | 119  | 70 - 130    | 4   | 30        |
| 4,8-Dioxa-3H-perfluorononanoic acid (ADONA)                        | <2.0          |                  | 25.1        | 27.7       |               | ng/L |   | 111  | 70 - 130    | 1   | 30        |
| Surrogate                                                          | MSD %Recovery | MSD Qualifier    | Limits      |            |               |      |   |      |             |     |           |
| d5-NEtFOSAA                                                        | 112           |                  | 70 - 130    |            |               |      |   |      |             |     |           |
| 13C2 PFHxA                                                         | 112           |                  | 70 - 130    |            |               |      |   |      |             |     |           |
| 13C2 PFDA                                                          | 110           |                  | 70 - 130    |            |               |      |   |      |             |     |           |
| 13C3-GenX                                                          | 107           |                  | 70 - 130    |            |               |      |   |      |             |     |           |

# QC Association Summary

Client: City & County of Honolulu  
Project/Site: RED-HILL

Job ID: 380-139320-1  
SDG: Weekly PFAS

## LCMS

### Prep Batch: 140692

| Lab Sample ID        | Client Sample ID              | Prep Type | Matrix | Method   | Prep Batch |
|----------------------|-------------------------------|-----------|--------|----------|------------|
| 380-139320-1         | HALAWA SHAFT VIEWING POOL     | Total/NA  | Water  | 537.1 DW |            |
| 380-139320-2         | FB: HALAWA SHAFT VIEWING POOL | Total/NA  | Water  | 537.1 DW |            |
| MBL 380-140692/20-A  | Method Blank                  | Total/NA  | Water  | 537.1 DW |            |
| LCS 380-140692/22-A  | Lab Control Sample            | Total/NA  | Water  | 537.1 DW |            |
| MRL 380-140692/21-A  | Lab Control Sample            | Total/NA  | Water  | 537.1 DW |            |
| 380-139166-A-1-B MS  | Matrix Spike                  | Total/NA  | Water  | 537.1 DW |            |
| 380-139166-A-1-C MSD | Matrix Spike Duplicate        | Total/NA  | Water  | 537.1 DW |            |

### Analysis Batch: 140731

| Lab Sample ID        | Client Sample ID              | Prep Type | Matrix | Method | Prep Batch |
|----------------------|-------------------------------|-----------|--------|--------|------------|
| 380-139320-1         | HALAWA SHAFT VIEWING POOL     | Total/NA  | Water  | 537.1  | 140692     |
| 380-139320-2         | FB: HALAWA SHAFT VIEWING POOL | Total/NA  | Water  | 537.1  | 140692     |
| MBL 380-140692/20-A  | Method Blank                  | Total/NA  | Water  | 537.1  | 140692     |
| LCS 380-140692/22-A  | Lab Control Sample            | Total/NA  | Water  | 537.1  | 140692     |
| MRL 380-140692/21-A  | Lab Control Sample            | Total/NA  | Water  | 537.1  | 140692     |
| 380-139166-A-1-B MS  | Matrix Spike                  | Total/NA  | Water  | 537.1  | 140692     |
| 380-139166-A-1-C MSD | Matrix Spike Duplicate        | Total/NA  | Water  | 537.1  | 140692     |

### Prep Batch: 141021

| Lab Sample ID        | Client Sample ID              | Prep Type | Matrix | Method | Prep Batch |
|----------------------|-------------------------------|-----------|--------|--------|------------|
| 380-139320-1         | HALAWA SHAFT VIEWING POOL     | Total/NA  | Water  | 533    |            |
| 380-139320-2         | FB: HALAWA SHAFT VIEWING POOL | Total/NA  | Water  | 533    |            |
| MBL 380-141021/20-A  | Method Blank                  | Total/NA  | Water  | 533    |            |
| LCS 380-141021/22-A  | Lab Control Sample            | Total/NA  | Water  | 533    |            |
| MRL 380-141021/21-A  | Lab Control Sample            | Total/NA  | Water  | 533    |            |
| 380-139230-E-1-A MS  | Matrix Spike                  | Total/NA  | Water  | 533    |            |
| 380-139230-F-1-A MSD | Matrix Spike Duplicate        | Total/NA  | Water  | 533    |            |

### Analysis Batch: 141076

| Lab Sample ID        | Client Sample ID              | Prep Type | Matrix | Method | Prep Batch |
|----------------------|-------------------------------|-----------|--------|--------|------------|
| 380-139320-1         | HALAWA SHAFT VIEWING POOL     | Total/NA  | Water  | 533    | 141021     |
| 380-139320-2         | FB: HALAWA SHAFT VIEWING POOL | Total/NA  | Water  | 533    | 141021     |
| MBL 380-141021/20-A  | Method Blank                  | Total/NA  | Water  | 533    | 141021     |
| LCS 380-141021/22-A  | Lab Control Sample            | Total/NA  | Water  | 533    | 141021     |
| MRL 380-141021/21-A  | Lab Control Sample            | Total/NA  | Water  | 533    | 141021     |
| 380-139230-E-1-A MS  | Matrix Spike                  | Total/NA  | Water  | 533    | 141021     |
| 380-139230-F-1-A MSD | Matrix Spike Duplicate        | Total/NA  | Water  | 533    | 141021     |

# Lab Chronicle

Client: City & County of Honolulu  
Project/Site: RED-HILL

Job ID: 380-139320-1  
SDG: Weekly PFAS

**Client Sample ID: HALAWA SHAFT VIEWING POOL**

**Lab Sample ID: 380-139320-1**

**Date Collected: 03/04/25 10:00**

**Matrix: Water**

**Date Received: 03/06/25 10:12**

| Prep Type | Batch Type | Batch Method | Run | Dilution Factor | Batch Number | Analyst | Lab    | Prepared or Analyzed |
|-----------|------------|--------------|-----|-----------------|--------------|---------|--------|----------------------|
| Total/NA  | Prep       | 533          |     |                 | 141021       | N8NE    | EA POM | 03/10/25 19:02       |
| Total/NA  | Analysis   | 533          |     | 1               | 141076       | SZ9R    | EA POM | 03/11/25 19:40       |
| Total/NA  | Prep       | 537.1 DW     |     |                 | 140692       | N8NE    | EA POM | 03/08/25 13:49       |
| Total/NA  | Analysis   | 537.1        |     | 1               | 140731       | SZ9R    | EA POM | 03/10/25 06:56       |

**Client Sample ID: FB: HALAWA SHAFT VIEWING POOL**

**Lab Sample ID: 380-139320-2**

**Date Collected: 03/04/25 10:00**

**Matrix: Water**

**Date Received: 03/06/25 10:12**

| Prep Type | Batch Type | Batch Method | Run | Dilution Factor | Batch Number | Analyst | Lab    | Prepared or Analyzed |
|-----------|------------|--------------|-----|-----------------|--------------|---------|--------|----------------------|
| Total/NA  | Prep       | 533          |     |                 | 141021       | N8NE    | EA POM | 03/10/25 19:02       |
| Total/NA  | Analysis   | 533          |     | 1               | 141076       | SZ9R    | EA POM | 03/11/25 19:49       |
| Total/NA  | Prep       | 537.1 DW     |     |                 | 140692       | N8NE    | EA POM | 03/08/25 13:49       |
| Total/NA  | Analysis   | 537.1        |     | 1               | 140731       | SZ9R    | EA POM | 03/10/25 07:06       |

## Laboratory References:

EA POM = Eurofins Eaton Analytical Pomona, 941 Corporate Center Drive, Pomona, CA 91768-2642, TEL (626)386-1100

Accreditation/Certification Summary

Client: City & County of Honolulu  
Project/Site: RED-HILL

Job ID: 380-139320-1  
SDG: Weekly PFAS

Laboratory: Eurofins Eaton Analytical Pomona

The accreditations/certifications listed below are applicable to this report.

| Authority | Program | Identification Number | Expiration Date |
|-----------|---------|-----------------------|-----------------|
| Hawaii    | State   | CA00006               | 01-31-25 *      |

\* Accreditation/Certification renewal pending - accreditation/certification considered valid.

# Method Summary

Client: City & County of Honolulu  
Project/Site: RED-HILL

Job ID: 380-139320-1  
SDG: Weekly PFAS

| Method   | Method Description                                                    | Protocol | Laboratory |
|----------|-----------------------------------------------------------------------|----------|------------|
| 533      | Perfluorinated and Polyfluorinated Alkyl Substances in Drinking Water | EPA      | EA POM     |
| 537.1    | Perfluorinated Alkyl Acids (LC/MS)                                    | EPA      | EA POM     |
| 533      | Extraction of Perfluorinated and Polyfluorinated Alkyl Acids          | EPA      | EA POM     |
| 537.1 DW | Extraction of Perfluorinated Alkyl Acids                              | EPA      | EA POM     |

**Protocol References:**

EPA = US Environmental Protection Agency

**Laboratory References:**

EA POM = Eurofins Eaton Analytical Pomona, 941 Corporate Center Drive, Pomona, CA 91768-2642, TEL (626)386-1100

# Sample Summary

Client: City & County of Honolulu  
Project/Site: RED-HILL

Job ID: 380-139320-1  
SDG: Weekly PFAS

| Lab Sample ID | Client Sample ID              | Matrix | Collected      | Received       |
|---------------|-------------------------------|--------|----------------|----------------|
| 380-139320-1  | HALAWA SHAFT VIEWING POOL     | Water  | 03/04/25 10:00 | 03/06/25 10:12 |
| 380-139320-2  | FB: HALAWA SHAFT VIEWING POOL | Water  | 03/04/25 10:00 | 03/06/25 10:12 |

- 1
- 2
- 3
- 4
- 5
- 6
- 7
- 8
- 9
- 10
- 11
- 12
- 13
- 14
- 15
- 16
- 17

# Chain of Custody Record



COC No: 380-28005-2757 1  
Page: 1 of 1  
Job #:

Carrier Tracking No(s)

Lab PM: Arada, Rachelle  
E-Mail: Rachelle.Arada@eurofins.com

Sampler: Ryan Greer  
Phone: 808-748-5840

Client Information  
Client Contact: Dr Ron Fenstermacher  
Company: City & County of Honolulu

Address: 630 South Beretania Street Chemistry Lab  
City: Honolulu  
State: HI  
Zip: 96843  
Phone: 808-748-5091 (Tel)  
Email: RFENSTERMACHER@hbws.org

Due Date Requested: TAT Requested (days):  
Compliance Project: ☐ Yes ☒ No  
PO #: C20525101 exp 05312023  
WO #:  
Project #: 38001111  
SSOW#:

Project Name: RED-HILL/HBWS Sites Event Desc: RUSH Weekly Red Hill  
Site: Hawaii

Analysis Requested

State of Origin: HI

Preservation Codes:  
R - NaThioSO4  
RA - NaThio/HCl  
Q - Na2SO3  
QA - Na2SO3/HCl  
Y - Trizma  
I - NH4 Acetate  
Other:

Special Instructions/Note:

Field Filtered Sample (Yes or No)

Perform MS/MSD (Yes or No)

625.1, 625.1 SIM

6015B GRO.LL (MOD) GRO

6015B DRO.LL CS - HNL Ranges C10-C24/C24-C36/C8-C18

625.2 PREC - (MOD) 526plus Plus TICs

637.1 DW PREC - 637.1 Full List

633 - All Analytes

Total Number of Containers

Sample Identification

Sample Date

Sample Time

Matrix (W=water, S=solid, O=overstuffed, BT=Tissue, A=Air)

Sample Type (C=Comp, G=grab)

Preservation Code

Water

Water

Water

Halawa Shaft Viewing Pool

FB Halawa Shaft Viewing Pool

3/4/25

1000

1000

3/4/25

1000

3/4/25

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

1000

## Login Sample Receipt Checklist

Client: City & County of Honolulu

Job Number: 380-139320-1

SDG Number: Weekly PFAS

**Login Number: 139320**

**List Source: Eurofins Eaton Analytical Pomona**

**List Number: 1**

**Creator: Edrosa, Rey**

| Question                                                                         | Answer | Comment |
|----------------------------------------------------------------------------------|--------|---------|
| The coolers custody seal, if present, is intact.                                 | N/A    |         |
| Sample custody seals, if present, are intact.                                    | N/A    |         |
| Samples were received on ice.                                                    | True   |         |
| Cooler(s) Temperature is acceptable.                                             | True   |         |
| Cooler(s) Temperature is recorded.                                               | True   |         |
| COC is present.                                                                  | True   |         |
| COC is filled out in ink and is legible.                                         | True   |         |
| COC is filled out with all pertinent information.                                | True   |         |
| There are no discrepancies between the containers received and the COC.          | True   |         |
| Samples are received within Holding Time (excluding tests with immediate HTs)    | True   |         |
| Sample containers have legible labels.                                           | True   |         |
| Containers are not broken or leaking.                                            | True   |         |
| Sample collection date/times are provided.                                       | True   |         |
| There is sufficient vol. for all requested analyses, incl. any requested MS/MSDs | True   |         |
| Containers requiring zero headspace have no headspace or bubble is <6mm (1/4").  | N/A    |         |
| CIO4 headspace requirement met (>50% for CA, >30% for other states).             | N/A    |         |
| Samples do not require splitting or compositing.                                 | True   |         |
| Container provided by EEA                                                        | True   |         |